



Fascure Ultra

Formulation Guide

Item # FG-ULT Version 2.2 February 1, 2006

SERICOL
More than ink...Solutions.[™]
FUJIFILM

The formulations used in this guide are predictive simulations of the PANTONE®* references using Fascure Ultra Series SMS (Seritone Matching System) Colors. Predictive simulations were performed via a spectrophotometer simulating Cool White Florescent (CWF) lighting, ink deposit of 380 PW on white substrate.

Please remember that these are starting formulations only, and variations in substrates and printing conditions may affect the color achieved. Fujifilm Sericol USA Inc. assumes no responsibility for actual color achieved versus the Pantone standard print. For this reason, all formulations must be proofed prior to a production run to ensure color accuracy.

All formulations are percentages by weight using the following Fascure Ultra Series SMS Colors:

ULT-064	SMS Yellow (Green Shade)
ULT-066	SMS Yellow (Red Shade)
ULT-114	SMS Orange
ULT-121	SMS Red (Yellow Shade)
ULT-127	SMS Violet
ULT-164	SMS Red (Blue Shade)
ULT-165	SMS Magenta
ULT-230	SMS Blue
ULT-325	SMS Green
ULT-SB	SMS Shading Black
ULT-TW	SMS Tinting White
ULT-MX	Mixing Clear

Fujifilm Sericol USA Inc. color mixing ink formulations produce only simulations of PANTONE Colors in this color reproduction method due to differences in ink film, opacity and pigment selection. The selection used in blending inks may cause metamerism. Pantone Inc. assumes no responsibility for formula accuracy.

* PANTONE® is the property of Pantone Inc.

Fascure ULT

Starting Point	Formula
Yellow C	
ULT-064 92.00	
ULT-TW 8.00	

Starting Point	Formula
Yellow 012 C	
ULT-064 76.35	
ULT-TW 16.00	
ULT-066 7.65	

Starting Point	Formula
Orange 021 C	
ULT-114 51.06	
ULT-066 48.94	

Starting Point	Formula
Warm Red C	
ULT-121 40.09	
ULT-TW 33.36	
ULT-114 26.55	

Starting Point	Formula
Red 032 C	
ULT-MX 57.41	
ULT-114 20.37	
ULT-164 12.96	
ULT-TW 9.26	

Starting Point	Formula
Rubine Red C	
ULT-165 53.93	
ULT-164 19.23	
ULT-MX 14.71	
ULT-TW 12.13	

Starting Point	Formula
Rhodamine Red C	
ULT-MX 60.00	
ULT-165 40.00	

Starting Point	Formula
Purple C	
ULT-MX 73.56	
ULT-165 20.69	
ULT-127 5.75	

Starting Point	Formula
Violet C	
ULT-MX 70.26	
ULT-127 25.10	
ULT-230 4.64	

Starting Point	Formula
Blue 072 C	
ULT-230 63.22	
ULT-127 19.83	
ULT-MX 16.95	

Starting Point	Formula
Reflex Blue C	
ULT-230 69.50	
ULT-127 16.95	
ULT-MX 13.55	

Starting Point	Formula
Process Blue C	
ULT-MX 57.89	
ULT-230 37.60	
ULT-TW 4.51	

Starting Point	Formula
Green C	
ULT-325 55.55	
ULT-TW 27.78	
ULT-MX 16.67	

Starting Point	Formula
Black C	
ULT-SB 99.50	
ULT-230 0.50	

Starting Point	Formula
100 C	
ULT-MX 60.00	
ULT-064 20.00	
ULT-TW 20.00	

Starting Point	Formula
101 C	
ULT-TW 65.60	
ULT-064 34.40	

Fascure ULT

Starting Point	Formula
102 C	
ULT-064	100.00

Starting Point	Formula
103 C	
ULT-064	91.32
ULT-114	5.25
ULT-325	3.43

Starting Point	Formula
104 C	
ULT-064	85.04
ULT-114	7.43
ULT-325	6.56
ULT-164	0.97

Starting Point	Formula
105 C	
ULT-064	75.95
ULT-SB	15.19
ULT-TW	8.86

Starting Point	Formula
106 C	
ULT-TW	66.50
ULT-064	33.50

Starting Point	Formula
107 C	
ULT-064	55.04
ULT-TW	44.96

Starting Point	Formula
108 C	
ULT-064	85.31
ULT-TW	14.69

Starting Point	Formula
109 C	
ULT-064	88.65
ULT-TW	9.96
ULT-121	1.39

Starting Point	Formula
110 C	
ULT-064	90.73
ULT-114	6.81
ULT-325	2.46

Starting Point	Formula
111 C	
ULT-064	77.25
ULT-114	14.81
ULT-325	7.94

Starting Point	Formula
112 C	
ULT-064	74.81
ULT-114	12.86
ULT-325	10.31
ULT-164	2.02

Starting Point	Formula
113 C	
ULT-TW	66.55
ULT-064	33.45

Starting Point	Formula
114 C	
ULT-TW	60.66
ULT-064	39.34

Starting Point	Formula
115 C	
ULT-TW	52.93
ULT-064	46.73
ULT-114	0.34

Starting Point	Formula
116 C	
ULT-064	82.40
ULT-TW	16.06
ULT-114	1.54

Starting Point	Formula
117 C	
ULT-064	85.06
ULT-114	11.01
ULT-325	3.93

Fascure ULT

Starting Point	Formula
118 C	
ULT-064 78.62	
ULT-114 13.98	
ULT-325 6.75	
ULT-164 0.65	

Starting Point	Formula
119 C	
ULT-064 77.87	
ULT-325 11.14	
ULT-164 6.54	
ULT-114 4.45	

Starting Point	Formula
120 C	
ULT-TW 77.84	
ULT-064 21.43	
ULT-114 0.73	

Starting Point	Formula
121 C	
ULT-TW 74.62	
ULT-064 24.46	
ULT-114 0.92	

Starting Point	Formula
122 C	
ULT-TW 61.41	
ULT-064 37.10	
ULT-114 1.49	

Starting Point	Formula
123 C	
ULT-064 56.24	
ULT-TW 41.10	
ULT-114 2.66	

Starting Point	Formula
124 C	
ULT-064 81.97	
ULT-TW 11.63	
ULT-114 4.71	
ULT-325 1.05	
ULT-164 0.64	

Starting Point	Formula
125 C	
ULT-064 84.33	
ULT-114 8.73	
ULT-325 4.70	
ULT-164 2.24	

Starting Point	Formula
126 C	
ULT-064 80.73	
ULT-114 8.17	
ULT-325 7.39	
ULT-164 3.71	

Starting Point	Formula
1205 C	
ULT-TW 86.11	
ULT-064 7.25	
ULT-066 6.64	

Starting Point	Formula
1215 C	
ULT-TW 86.79	
ULT-064 12.16	
ULT-114 1.05	

Starting Point	Formula
1225 C	
ULT-TW 53.57	
ULT-064 43.24	
ULT-114 3.19	

Starting Point	Formula
1235 C	
ULT-066 73.36	
ULT-TW 25.53	
ULT-114 1.11	

Starting Point	Formula
1245 C	
ULT-064 75.27	
ULT-TW 12.42	
ULT-114 7.16	
ULT-325 3.27	
ULT-164 1.88	

Starting Point	Formula
1255 C	
ULT-064 72.11	
ULT-TW 10.33	
ULT-114 8.46	
ULT-325 5.98	
ULT-164 3.12	

Starting Point	Formula
1265 C	
ULT-066 83.90	
ULT-SB 15.08	
ULT-114 1.02	

Fascure ULT

Starting Point	Formula
127 C	
ULT-TW 81.41	
ULT-064 18.42	
ULT-164 0.17	

Starting Point	Formula
128 C	
ULT-TW 68.34	
ULT-064 31.28	
ULT-164 0.38	

Starting Point	Formula
129 C	
ULT-TW 54.98	
ULT-064 44.42	
ULT-164 0.60	

Starting Point	Formula
130 C	
ULT-064 97.66	
ULT-164 2.34	

Starting Point	Formula
131 C	
ULT-064 94.08	
ULT-164 4.37	
ULT-325 1.55	

Starting Point	Formula
132 C	
ULT-064 79.03	
ULT-114 9.44	
ULT-325 7.21	
ULT-164 4.32	

Starting Point	Formula
133 C	
ULT-064 47.40	
ULT-114 25.97	
ULT-325 21.07	
ULT-164 5.56	

Starting Point	Formula
134 C	
ULT-TW 81.70	
ULT-064 16.43	
ULT-114 1.87	

Starting Point	Formula
135 C	
ULT-TW 64.82	
ULT-064 31.45	
ULT-114 3.73	

Starting Point	Formula
136 C	
ULT-064 48.30	
ULT-TW 46.30	
ULT-114 5.40	

Starting Point	Formula
137 C	
ULT-064 76.43	
ULT-TW 13.03	
ULT-114 10.54	

Starting Point	Formula
138 C	
ULT-064 74.77	
ULT-114 23.42	
ULT-325 1.81	

Starting Point	Formula
139 C	
ULT-064 70.26	
ULT-114 22.40	
ULT-325 5.65	
ULT-164 1.69	

Starting Point	Formula
140 C	
ULT-064 47.05	
ULT-114 31.01	
ULT-325 17.57	
ULT-164 4.37	

Starting Point	Formula
1345 C	
ULT-TW 79.37	
ULT-064 18.61	
ULT-114 2.02	

Starting Point	Formula
1355 C	
ULT-TW 80.80	
ULT-064 15.36	
ULT-114 3.84	

Fascure ULT

Starting Point	Formula
1365 C	
ULT-TW 63.46	
ULT-064 30.00	
ULT-114 6.54	

Starting Point	Formula
1375 C	
ULT-064 56.86	
ULT-TW 33.76	
ULT-114 9.38	

Starting Point	Formula
1385 C	
ULT-064 74.13	
ULT-114 21.87	
ULT-325 2.50	
ULT-164 1.50	

Starting Point	Formula
1395 C	
ULT-064 62.04	
ULT-114 25.04	
ULT-325 8.79	
ULT-164 4.13	

Starting Point	Formula
1405 C	
ULT-064 56.76	
ULT-SB 24.60	
ULT-114 18.64	

Starting Point	Formula
141 C	
ULT-TW 70.90	
ULT-064 28.11	
ULT-164 0.99	

Starting Point	Formula
142 C	
ULT-TW 51.73	
ULT-064 46.68	
ULT-164 1.59	

Starting Point	Formula
143 C	
ULT-064 67.05	
ULT-TW 30.52	
ULT-164 2.43	

Starting Point	Formula
144 C	
ULT-064 94.37	
ULT-164 5.63	

Starting Point	Formula
145 C	
ULT-064 91.21	
ULT-164 7.22	
ULT-325 1.57	

Starting Point	Formula
146 C	
ULT-064 70.13	
ULT-114 21.43	
ULT-230 5.06	
ULT-164 3.38	

Starting Point	Formula
147 C	
ULT-064 63.58	
ULT-325 16.83	
ULT-164 11.39	
ULT-114 8.20	

Starting Point	Formula
148 C	
ULT-TW 90.11	
ULT-064 6.78	
ULT-114 3.11	

Starting Point	Formula
149 C	
ULT-TW 85.28	
ULT-064 10.13	
ULT-114 4.59	

Starting Point	Formula
150 C	
ULT-TW 60.98	
ULT-064 29.12	
ULT-114 9.90	

Starting Point	Formula
151 C	
ULT-064 66.78	
ULT-114 33.22	

Fascure ULT

Starting Point	Formula
152 C	
ULT-064 69.14	
ULT-114 28.00	
ULT-164 1.49	
ULT-325 1.37	

Starting Point	Formula
153 C	
ULT-064 67.32	
ULT-114 25.11	
ULT-325 4.27	
ULT-164 3.30	

Starting Point	Formula
154 C	
ULT-064 49.57	
ULT-114 36.21	
ULT-325 9.85	
ULT-164 4.37	

Starting Point	Formula
1485 C	
ULT-TW 75.14	
ULT-066 19.68	
ULT-114 5.18	

Starting Point	Formula
1495 C	
ULT-TW 46.32	
ULT-064 34.44	
ULT-114 19.24	

Starting Point	Formula
1505 C	
ULT-064 65.85	
ULT-114 34.15	

Starting Point	Formula
1525 C	
ULT-114 65.99	
ULT-064 30.88	
ULT-325 3.13	

Starting Point	Formula
1535 C	
ULT-114 87.84	
ULT-325 12.16	

Starting Point	Formula
1545 C	
ULT-114 59.46	
ULT-SB 34.88	
ULT-TW 5.66	

Starting Point	Formula
155 C	
ULT-TW 91.00	
ULT-064 7.93	
ULT-164 0.90	
ULT-325 0.17	

Starting Point	Formula
156 C	
ULT-TW 81.12	
ULT-064 17.15	
ULT-164 1.73	

Starting Point	Formula
157 C	
ULT-TW 49.98	
ULT-064 45.86	
ULT-164 4.16	

Starting Point	Formula
158 C	
ULT-064 90.57	
ULT-164 9.43	

Starting Point	Formula
159 C	
ULT-064 86.07	
ULT-164 12.64	
ULT-325 1.29	

Starting Point	Formula
160 C	
ULT-064 58.40	
ULT-114 24.97	
ULT-164 9.61	
ULT-325 7.02	

Starting Point	Formula
161 C	
ULT-114 64.17	
ULT-325 28.78	
ULT-164 7.05	

Fascure ULT

Starting Point	Formula
1555 C	
ULT-TW 92.76	
ULT-114 6.47	
ULT-064 0.77	

Starting Point	Formula
1565 C	
ULT-TW 83.82	
ULT-114 12.27	
ULT-064 3.91	

Starting Point	Formula
1575 C	
ULT-TW 53.48	
ULT-114 26.27	
ULT-064 20.25	

Starting Point	Formula
1585 C	
ULT-064 44.36	
ULT-114 41.46	
ULT-TW 14.18	

Starting Point	Formula
1595 C	
ULT-114 45.75	
ULT-064 41.90	
ULT-TW 8.86	
ULT-325 2.18	
ULT-164 1.31	

Starting Point	Formula
1605 C	
ULT-064 48.10	
ULT-114 37.97	
ULT-325 7.60	
ULT-164 6.33	

Starting Point	Formula
1615 C	
ULT-114 82.09	
ULT-325 15.89	
ULT-164 2.02	

Starting Point	Formula
162 C	
ULT-TW 93.54	
ULT-114 4.17	
ULT-066 2.29	

Starting Point	Formula
163 C	
ULT-TW 82.14	
ULT-114 17.86	

Starting Point	Formula
164 C	
ULT-TW 53.23	
ULT-114 33.58	
ULT-064 13.19	

Starting Point	Formula
165 C	
ULT-114 48.39	
ULT-TW 32.26	
ULT-066 19.35	

Starting Point	Formula
166 C	
ULT-114 60.55	
ULT-064 32.92	
ULT-TW 4.10	
ULT-325 1.37	
ULT-164 1.06	

Starting Point	Formula
167 C	
ULT-114 52.00	
ULT-064 34.58	
ULT-TW 6.65	
ULT-325 4.03	
ULT-164 2.74	

Starting Point	Formula
168 C	
ULT-114 65.76	
ULT-SB 21.58	
ULT-121 12.66	

Starting Point	Formula
1625 C	
ULT-TW 87.15	
ULT-114 11.73	
ULT-164 1.12	

Starting Point	Formula
1635 C	
ULT-TW 80.34	
ULT-114 18.56	
ULT-164 1.10	

Fascure ULT

Starting Point	Formula
1645 C	
ULT-TW 50.55	
ULT-114 49.45	

Starting Point	Formula
1655 C	
ULT-114 76.07	
ULT-164 17.19	
ULT-TW 6.74	

Starting Point	Formula
1665 C	
ULT-114 71.25	
ULT-064 22.24	
ULT-164 3.03	
ULT-TW 2.34	
ULT-325 1.14	

Starting Point	Formula
1675 C	
ULT-114 69.66	
ULT-064 18.85	
ULT-325 7.23	
ULT-164 4.26	

Starting Point	Formula
1685 C	
ULT-114 81.03	
ULT-325 14.66	
ULT-164 4.31	

Starting Point	Formula
169 C	
ULT-TW 94.20	
ULT-114 4.31	
ULT-164 1.49	

Starting Point	Formula
170 C	
ULT-TW 80.32	
ULT-114 16.99	
ULT-164 2.69	

Starting Point	Formula
171 C	
ULT-114 49.90	
ULT-TW 47.77	
ULT-164 2.33	

Starting Point	Formula
172 C	
ULT-114 84.47	
ULT-TW 15.22	
ULT-164 0.31	

Starting Point	Formula
173 C	
ULT-114 74.81	
ULT-TW 21.43	
ULT-325 2.01	
ULT-164 1.75	

Starting Point	Formula
174 C	
ULT-114 59.94	
ULT-064 23.70	
ULT-325 8.76	
ULT-164 7.60	

Starting Point	Formula
175 C	
ULT-114 64.47	
ULT-325 19.72	
ULT-164 7.94	
ULT-TW 7.87	

Starting Point	Formula
176 C	
ULT-MX 51.05	
ULT-TW 45.58	
ULT-121 2.73	
ULT-164 0.64	

Starting Point	Formula
177 C	
ULT-TW 82.84	
ULT-114 10.96	
ULT-164 6.20	

Starting Point	Formula
178 C	
ULT-TW 60.66	
ULT-114 30.98	
ULT-164 8.36	

Starting Point	Formula
179 C	
ULT-114 63.70	
ULT-TW 30.37	
ULT-164 5.09	
ULT-325 0.84	

Fascure ULT

Starting Point	Formula
180 C	
ULT-114	60.73
ULT-TW	27.99
ULT-164	8.41
ULT-325	2.87

Starting Point	Formula
181 C	
ULT-121	62.20
ULT-SB	16.96
ULT-TW	14.54
ULT-114	6.30

Starting Point	Formula
1765 C	
ULT-TW	91.87
ULT-164	4.46
ULT-114	3.67

Starting Point	Formula
1775 C	
ULT-TW	85.45
ULT-164	7.29
ULT-114	7.26

Starting Point	Formula
1785 C	
ULT-TW	54.13
ULT-114	30.51
ULT-164	15.36

Starting Point	Formula
1788 C	
ULT-114	60.05
ULT-TW	27.65
ULT-164	12.30

Starting Point	Formula
1795 C	
ULT-114	60.98
ULT-TW	25.24
ULT-164	12.88
ULT-325	0.90

Starting Point	Formula
1805 C	
ULT-114	64.73
ULT-TW	16.76
ULT-164	14.58
ULT-325	3.93

Starting Point	Formula
1815 C	
ULT-114	71.80
ULT-164	10.05
ULT-064	9.30
ULT-230	8.85

Starting Point	Formula
1767 C	
ULT-TW	48.78
ULT-MX	48.78
ULT-164	1.46
ULT-114	0.98

Starting Point	Formula
1777 C	
ULT-TW	76.30
ULT-121	15.78
ULT-164	7.92

Starting Point	Formula
1787 C	
ULT-TW	56.26
ULT-114	23.63
ULT-164	20.11

Starting Point	Formula
1797 C	
ULT-114	42.43
ULT-164	28.68
ULT-TW	28.32
ULT-325	0.57

Starting Point	Formula
1807 C	
ULT-114	41.70
ULT-164	32.53
ULT-TW	21.76
ULT-325	4.01

Starting Point	Formula
1817 C	
ULT-MX	25.26
ULT-SB	23.77
ULT-114	23.33
ULT-TW	14.86
ULT-164	12.78

Starting Point	Formula
182 C	
ULT-TW	96.64
ULT-164	2.50
ULT-114	0.86

Fascure ULT

Starting Point	Formula
183 C	
ULT-TW 90.22	
ULT-164 6.41	
ULT-114 3.37	

Starting Point	Formula
184 C	
ULT-TW 75.92	
ULT-164 14.34	
ULT-114 9.74	

Starting Point	Formula
185 C	
ULT-121 55.56	
ULT-164 25.93	
ULT-TW 18.51	

Starting Point	Formula
186 C	
ULT-114 43.16	
ULT-164 28.34	
ULT-TW 28.03	
ULT-325 0.47	

Starting Point	Formula
187 C	
ULT-114 41.73	
ULT-164 29.96	
ULT-TW 25.51	
ULT-325 2.80	

Starting Point	Formula
188 C	
ULT-114 45.78	
ULT-164 31.63	
ULT-TW 11.31	
ULT-325 11.28	

Starting Point	Formula
189 C	
ULT-TW 93.30	
ULT-164 5.12	
ULT-114 1.58	

Starting Point	Formula
190 C	
ULT-TW 84.59	
ULT-164 11.62	
ULT-114 3.79	

Starting Point	Formula
191 C	
ULT-TW 64.23	
ULT-164 25.94	
ULT-114 9.83	

Starting Point	Formula
192 C	
ULT-TW 36.60	
ULT-164 32.42	
ULT-114 30.98	

Starting Point	Formula
193 C	
ULT-164 37.03	
ULT-TW 34.08	
ULT-114 27.94	
ULT-325 0.95	

Starting Point	Formula
194 C	
ULT-164 35.09	
ULT-114 30.29	
ULT-TW 29.90	
ULT-325 4.72	

Starting Point	Formula
195 C	
ULT-114 35.73	
ULT-164 26.81	
ULT-TW 25.37	
ULT-325 12.09	

Starting Point	Formula
1895 C	
ULT-TW 96.59	
ULT-165 2.17	
ULT-121 1.24	

Starting Point	Formula
1905 C	
ULT-TW 93.64	
ULT-164 5.63	
ULT-114 0.73	

Starting Point	Formula
1915 C	
ULT-TW 74.70	
ULT-164 22.70	
ULT-114 2.60	

Fascure ULT

Starting Point	Formula
1925 C	
ULT-MX 47.30	
ULT-165 32.43	
ULT-121 20.27	

Starting Point	Formula
1935 C	
ULT-164 43.58	
ULT-TW 37.05	
ULT-114 18.97	
ULT-325 0.40	

Starting Point	Formula
1945 C	
ULT-164 46.77	
ULT-TW 27.87	
ULT-114 22.62	
ULT-325 2.74	

Starting Point	Formula
1955 C	
ULT-165 52.99	
ULT-121 27.35	
ULT-SB 7.69	
ULT-TW 6.84	
ULT-MX 5.13	

Starting Point	Formula
196 C	
ULT-TW 97.81	
ULT-164 1.70	
ULT-064 0.49	

Starting Point	Formula
197 C	
ULT-TW 91.67	
ULT-164 5.36	
ULT-064 2.97	

Starting Point	Formula
198 C	
ULT-TW 70.77	
ULT-164 19.21	
ULT-114 10.02	

Starting Point	Formula
199 C	
ULT-164 37.90	
ULT-114 31.62	
ULT-TW 30.48	

Starting Point	Formula
200 C	
ULT-164 42.15	
ULT-114 39.29	
ULT-TW 17.18	
ULT-325 1.38	

Starting Point	Formula
201 C	
ULT-064 47.70	
ULT-164 41.60	
ULT-TW 6.50	
ULT-325 4.20	

Starting Point	Formula
202 C	
ULT-164 42.25	
ULT-064 41.00	
ULT-325 8.50	
ULT-114 8.25	

Starting Point	Formula
203 C	
ULT-TW 96.23	
ULT-164 3.77	

Starting Point	Formula
204 C	
ULT-TW 90.20	
ULT-164 9.80	

Starting Point	Formula
205 C	
ULT-TW 74.95	
ULT-164 25.05	

Starting Point	Formula
206 C	
ULT-164 51.75	
ULT-TW 38.10	
ULT-114 10.15	

Starting Point	Formula
207 C	
ULT-164 59.25	
ULT-TW 27.20	
ULT-114 11.55	
ULT-325 2.00	

Fascure ULT

Starting Point	Formula
208 C	
ULT-164	46.93
ULT-TW	32.11
ULT-114	14.88
ULT-325	6.08

Starting Point	Formula
209 C	
ULT-164	43.68
ULT-TW	24.67
ULT-114	20.27
ULT-325	11.38

Starting Point	Formula
210 C	
ULT-TW	93.60
ULT-164	6.40

Starting Point	Formula
211 C	
ULT-TW	88.14
ULT-164	11.86

Starting Point	Formula
212 C	
ULT-TW	78.60
ULT-164	21.40

Starting Point	Formula
213 C	
ULT-TW	62.80
ULT-164	37.20

Starting Point	Formula
214 C	
ULT-TW	56.15
ULT-164	43.85

Starting Point	Formula
215 C	
ULT-164	51.70
ULT-TW	40.50
ULT-114	5.10
ULT-325	2.70

Starting Point	Formula
216 C	
ULT-164	44.50
ULT-TW	23.10
ULT-114	21.60
ULT-325	10.80

Starting Point	Formula
217 C	
ULT-TW	96.91
ULT-165	3.09

Starting Point	Formula
218 C	
ULT-TW	76.95
ULT-165	23.05

Starting Point	Formula
219 C	
ULT-165	55.65
ULT-TW	39.55
ULT-164	4.80

Starting Point	Formula
220 C	
ULT-165	85.40
ULT-114	13.00
ULT-325	1.60

Starting Point	Formula
221 C	
ULT-165	63.90
ULT-164	19.10
ULT-114	12.60
ULT-325	4.40

Starting Point	Formula
222 C	
ULT-165	44.63
ULT-164	25.03
ULT-SB	17.72
ULT-TW	12.62

Starting Point	Formula
223 C	
ULT-TW	86.35
ULT-165	13.65

Fascure ULT

Starting Point	Formula
224 C	
ULT-TW 72.35	
ULT-165 27.65	

Starting Point	Formula
225 C	
ULT-165 58.40	
ULT-TW 41.60	

Starting Point	Formula
226 C	
ULT-165 97.80	
ULT-114 2.20	

Starting Point	Formula
227 C	
ULT-165 91.60	
ULT-114 7.20	
ULT-325 1.20	

Starting Point	Formula
228 C	
ULT-165 67.90	
ULT-164 16.10	
ULT-114 9.65	
ULT-325 6.35	

Starting Point	Formula
229 C	
ULT-165 39.95	
ULT-164 25.75	
ULT-114 19.00	
ULT-325 15.30	

Starting Point	Formula
230 C	
ULT-MX 93.35	
ULT-165 6.35	
ULT-164 0.30	

Starting Point	Formula
231 C	
ULT-TW 76.65	
ULT-165 23.35	

Starting Point	Formula
232 C	
ULT-TW 57.90	
ULT-165 42.10	

Starting Point	Formula
233 C	
ULT-165 70.70	
ULT-TW 29.30	

Starting Point	Formula
234 C	
ULT-165 85.45	
ULT-TW 10.65	
ULT-114 2.25	
ULT-325 1.65	

Starting Point	Formula
235 C	
ULT-165 59.98	
ULT-TW 22.39	
ULT-SB 9.11	
ULT-164 8.52	

Starting Point	Formula
236 C	
ULT-TW 91.80	
ULT-165 8.20	

Starting Point	Formula
237 C	
ULT-TW 82.40	
ULT-165 17.60	

Starting Point	Formula
238 C	
ULT-TW 65.90	
ULT-165 34.10	

Starting Point	Formula
239 C	
ULT-TW 54.70	
ULT-165 45.30	

Fascure ULT

Starting Point	Formula
240 C	
ULT-165 54.00	
ULT-TW 46.00	

Starting Point	Formula
241 C	
ULT-165 76.70	
ULT-TW 22.10	
ULT-230 1.20	

Starting Point	Formula
242 C	
ULT-165 77.45	
ULT-114 11.75	
ULT-325 9.25	
ULT-TW 1.55	

Starting Point	Formula
2365 C	
ULT-TW 95.50	
ULT-165 4.50	

Starting Point	Formula
2375 C	
ULT-TW 72.85	
ULT-165 26.75	
ULT-230 0.40	

Starting Point	Formula
2385 C	
ULT-TW 81.85	
ULT-165 17.90	
ULT-230 0.25	

Starting Point	Formula
2395 C	
ULT-165 99.25	
ULT-230 0.75	

Starting Point	Formula
2405 C	
ULT-165 97.90	
ULT-230 2.10	

Starting Point	Formula
2415 C	
ULT-165 96.55	
ULT-230 2.95	
ULT-164 0.50	

Starting Point	Formula
2425 C	
ULT-165 70.65	
ULT-164 21.85	
ULT-325 4.95	
ULT-230 2.55	

Starting Point	Formula
243 C	
ULT-TW 93.15	
ULT-165 6.45	
ULT-230 0.40	

Starting Point	Formula
244 C	
ULT-TW 88.25	
ULT-165 11.15	
ULT-230 0.60	

Starting Point	Formula
245 C	
ULT-TW 78.10	
ULT-165 21.20	
ULT-230 0.70	

Starting Point	Formula
246 C	
ULT-165 56.25	
ULT-TW 43.15	
ULT-230 0.60	

Starting Point	Formula
247 C	
ULT-165 62.65	
ULT-TW 36.05	
ULT-230 1.30	

Starting Point	Formula
248 C	
ULT-165 79.05	
ULT-TW 18.25	
ULT-230 2.70	

Fascure ULT

Starting Point	Formula
249 C	
ULT-165 77.35	
ULT-114 10.00	
ULT-230 7.25	
ULT-TW 5.40	

Starting Point	Formula
250 C	
ULT-TW 70.56	
ULT-MX 27.12	
ULT-165 1.87	
ULT-127 0.45	

Starting Point	Formula
251 C	
ULT-TW 85.25	
ULT-165 13.50	
ULT-230 1.25	

Starting Point	Formula
252 C	
ULT-TW 66.00	
ULT-165 32.10	
ULT-230 1.90	

Starting Point	Formula
253 C	
ULT-165 56.70	
ULT-TW 40.60	
ULT-230 2.70	

Starting Point	Formula
254 C	
ULT-165 65.55	
ULT-TW 30.00	
ULT-230 4.45	

Starting Point	Formula
255 C	
ULT-165 54.19	
ULT-TW 25.76	
ULT-127 7.60	
ULT-SB 6.94	
ULT-MX 5.51	

Starting Point	Formula
256 C	
ULT-TW 95.20	
ULT-165 4.00	
ULT-230 0.80	

Starting Point	Formula
257 C	
ULT-TW 91.15	
ULT-165 7.65	
ULT-230 1.20	

Starting Point	Formula
258 C	
ULT-TW 50.35	
ULT-165 44.95	
ULT-230 4.70	

Starting Point	Formula
259 C	
ULT-165 88.40	
ULT-325 5.75	
ULT-230 5.30	
ULT-164 0.55	

Starting Point	Formula
260 C	
ULT-165 71.50	
ULT-325 15.80	
ULT-164 9.40	
ULT-TW 3.30	

Starting Point	Formula
261 C	
ULT-165 42.15	
ULT-164 28.70	
ULT-325 18.55	
ULT-TW 10.60	

Starting Point	Formula
262 C	
ULT-165 58.80	
ULT-114 25.85	
ULT-230 15.35	

Starting Point	Formula
2562 C	
ULT-TW 88.80	
ULT-165 9.60	
ULT-230 1.60	

Starting Point	Formula
2572 C	
ULT-TW 78.10	
ULT-165 19.20	
ULT-230 2.70	

Fascure ULT

Starting Point	Formula
2582 C	
ULT-TW 53.30	
ULT-165 41.90	
ULT-230 4.80	

Starting Point	Formula
2592 C	
ULT-165 91.30	
ULT-230 8.70	

Starting Point	Formula
2602 C	
ULT-165 90.20	
ULT-230 9.80	

Starting Point	Formula
2612 C	
ULT-165 89.70	
ULT-230 10.30	

Starting Point	Formula
2622 C	
ULT-165 69.90	
ULT-114 15.60	
ULT-230 13.40	
ULT-325 1.10	

Starting Point	Formula
2563 C	
ULT-TW 88.70	
ULT-165 9.65	
ULT-230 1.65	

Starting Point	Formula
2573 C	
ULT-TW 77.60	
ULT-165 19.50	
ULT-230 2.90	

Starting Point	Formula
2583 C	
ULT-TW 58.30	
ULT-165 37.05	
ULT-230 4.65	

Starting Point	Formula
2593 C	
ULT-165 90.40	
ULT-230 9.60	

Starting Point	Formula
2603 C	
ULT-165 89.75	
ULT-230 10.25	

Starting Point	Formula
2613 C	
ULT-165 87.35	
ULT-230 10.60	
ULT-114 2.05	

Starting Point	Formula
2623 C	
ULT-165 80.40	
ULT-230 12.20	
ULT-114 7.40	

Starting Point	Formula
2567 C	
ULT-TW 88.40	
ULT-MX 9.00	
ULT-127 2.60	

Starting Point	Formula
2577 C	
ULT-TW 89.90	
ULT-127 6.90	
ULT-165 3.20	

Starting Point	Formula
2587 C	
ULT-TW 48.80	
ULT-165 43.30	
ULT-230 7.90	

Starting Point	Formula
2597 C	
ULT-MX 67.31	
ULT-127 26.92	
ULT-165 5.77	

Fascure ULT

Starting Point	Formula
2607 C	
ULT-165 85.50	
ULT-230 14.50	

Starting Point	Formula
2617 C	
ULT-165 81.30	
ULT-230 12.35	
ULT-127 5.00	
ULT-114 1.35	

Starting Point	Formula
2627 C	
ULT-MX 60.50	
ULT-127 19.75	
ULT-SB 13.58	
ULT-165 6.17	

Starting Point	Formula
263 C	
ULT-TW 95.95	
ULT-165 3.10	
ULT-230 0.95	

Starting Point	Formula
264 C	
ULT-TW 88.95	
ULT-165 8.55	
ULT-230 2.50	

Starting Point	Formula
265 C	
ULT-TW 76.05	
ULT-165 14.95	
ULT-127 5.00	
ULT-230 4.00	

Starting Point	Formula
266 C	
ULT-TW 52.00	
ULT-165 33.70	
ULT-230 9.30	
ULT-127 5.00	

Starting Point	Formula
267 C	
ULT-165 81.30	
ULT-230 18.70	

Starting Point	Formula
268 C	
ULT-165 82.30	
ULT-230 17.70	

Starting Point	Formula
269 C	
ULT-165 35.95	
ULT-164 31.05	
ULT-230 19.05	
ULT-TW 13.95	

Starting Point	Formula
2635 C	
ULT-TW 98.20	
ULT-127 1.34	
ULT-230 0.46	

Starting Point	Formula
2645 C	
ULT-TW 94.50	
ULT-127 5.00	
ULT-230 0.50	

Starting Point	Formula
2655 C	
ULT-TW 79.70	
ULT-165 11.70	
ULT-127 5.00	
ULT-230 3.60	

Starting Point	Formula
2665 C	
ULT-TW 63.35	
ULT-165 24.60	
ULT-230 7.05	
ULT-127 5.00	

Starting Point	Formula
2685 C	
ULT-165 80.80	
ULT-230 19.20	

Starting Point	Formula
2695 C	
ULT-MX 45.93	
ULT-127 28.39	
ULT-SB 21.71	
ULT-230 3.97	

Fascure ULT

Starting Point	Formula
270 C	
ULT-165 62.50	
ULT-230 18.60	
ULT-114 13.90	
ULT-127 5.00	

Starting Point	Formula
271 C	
ULT-TW 90.80	
ULT-165 6.25	
ULT-230 2.95	

Starting Point	Formula
272 C	
ULT-TW 90.60	
ULT-127 3.50	
ULT-230 3.00	
ULT-165 2.90	

Starting Point	Formula
273 C	
ULT-165 72.50	
ULT-230 22.50	
ULT-127 5.00	

Starting Point	Formula
274 C	
ULT-165 52.70	
ULT-230 22.30	
ULT-164 20.00	
ULT-127 5.00	

Starting Point	Formula
275 C	
ULT-164 40.60	
ULT-165 29.95	
ULT-230 24.45	
ULT-127 5.00	

Starting Point	Formula
276 C	
ULT-164 51.05	
ULT-230 26.95	
ULT-114 15.10	
ULT-165 6.90	

Starting Point	Formula
2705 C	
ULT-TW 86.80	
ULT-165 9.00	
ULT-230 4.20	

Starting Point	Formula
2715 C	
ULT-TW 88.00	
ULT-127 5.00	
ULT-230 3.90	
ULT-165 3.10	

Starting Point	Formula
2725 C	
ULT-TW 61.90	
ULT-165 20.80	
ULT-230 12.30	
ULT-127 5.00	

Starting Point	Formula
2735 C	
ULT-165 74.15	
ULT-230 25.85	

Starting Point	Formula
2745 C	
ULT-165 70.85	
ULT-230 24.15	
ULT-127 5.00	

Starting Point	Formula
2755 C	
ULT-165 58.70	
ULT-230 25.15	
ULT-164 11.15	
ULT-127 5.00	

Starting Point	Formula
2765 C	
ULT-164 41.35	
ULT-230 32.05	
ULT-165 21.60	
ULT-127 5.00	

Starting Point	Formula
2706 C	
ULT-TW 95.80	
ULT-165 2.60	
ULT-230 1.60	

Starting Point	Formula
2716 C	
ULT-TW 86.45	
ULT-165 8.35	
ULT-230 5.20	

Fascure ULT

Starting Point	Formula
2726 C	
ULT-TW 58.20	
ULT-230 19.20	
ULT-165 17.60	
ULT-127 5.00	

Starting Point	Formula
2736 C	
ULT-165 65.90	
ULT-230 34.10	

Starting Point	Formula
2746 C	
ULT-165 70.50	
ULT-230 29.50	

Starting Point	Formula
2756 C	
ULT-165 58.05	
ULT-230 29.35	
ULT-164 12.60	

Starting Point	Formula
2766 C	
ULT-164 54.05	
ULT-230 36.50	
ULT-127 5.00	
ULT-TW 4.45	

Starting Point	Formula
2707 C	
ULT-TW 58.61	
ULT-MX 39.81	
ULT-230 0.92	
ULT-127 0.66	

Starting Point	Formula
2717 C	
ULT-TW 92.60	
ULT-165 3.80	
ULT-230 3.60	

Starting Point	Formula
2727 C	
ULT-TW 62.00	
ULT-230 22.75	
ULT-165 15.25	

Starting Point	Formula
2747 C	
ULT-165 55.45	
ULT-230 39.55	
ULT-127 5.00	

Starting Point	Formula
2757 C	
ULT-230 47.10	
ULT-164 27.50	
ULT-165 20.40	
ULT-127 5.00	

Starting Point	Formula
2767 C	
ULT-230 33.43	
ULT-SB 32.67	
ULT-127 19.00	
ULT-TW 14.90	

Starting Point	Formula
2708 C	
ULT-TW 94.25	
ULT-165 3.15	
ULT-230 2.60	

Starting Point	Formula
2718 C	
ULT-TW 67.80	
ULT-165 15.90	
ULT-230 16.30	

Starting Point	Formula
2728 C	
ULT-TW 41.60	
ULT-230 33.25	
ULT-165 20.15	
ULT-127 5.00	

Starting Point	Formula
2738 C	
ULT-165 67.00	
ULT-230 33.00	

Starting Point	Formula
2748 C	
ULT-165 66.30	
ULT-230 28.70	
ULT-127 5.00	

Fascure ULT

Starting Point	Formula
2758 C	
ULT-165 42.85	
ULT-230 31.70	
ULT-164 20.45	
ULT-127 5.00	

Starting Point	Formula
2768 C	
ULT-164 59.40	
ULT-230 34.90	
ULT-165 3.20	
ULT-114 2.50	

Starting Point	Formula
277 C	
ULT-TW 97.90	
ULT-230 1.44	
ULT-127 0.66	

Starting Point	Formula
278 C	
ULT-TW 90.10	
ULT-230 5.40	
ULT-165 4.50	

Starting Point	Formula
279 C	
ULT-TW 73.00	
ULT-230 16.70	
ULT-165 10.30	

Starting Point	Formula
280 C	
ULT-165 56.30	
ULT-230 38.70	
ULT-127 5.00	

Starting Point	Formula
281 C	
ULT-230 44.00	
ULT-165 26.25	
ULT-164 24.75	
ULT-127 5.00	

Starting Point	Formula
282 C	
ULT-230 53.22	
ULT-SB 32.26	
ULT-127 14.52	

Starting Point	Formula
283 C	
ULT-TW 93.00	
ULT-230 4.10	
ULT-165 2.90	

Starting Point	Formula
284 C	
ULT-TW 87.75	
ULT-230 7.55	
ULT-165 4.70	

Starting Point	Formula
285 C	
ULT-TW 57.60	
ULT-230 31.00	
ULT-165 11.40	

Starting Point	Formula
286 C	
ULT-230 91.26	
ULT-127 8.74	

Starting Point	Formula
287 C	
ULT-230 57.30	
ULT-165 42.70	

Starting Point	Formula
288 C	
ULT-230 52.40	
ULT-165 47.60	

Starting Point	Formula
289 C	
ULT-230 39.95	
ULT-121 30.90	
ULT-165 24.15	
ULT-127 5.00	

Starting Point	Formula
290 C	
ULT-TW 97.20	
ULT-230 1.70	
ULT-165 1.10	

Fascure ULT

Starting Point	Formula
291 C	
ULT-TW 95.30	
ULT-230 3.00	
ULT-165 1.70	

Starting Point	Formula
292 C	
ULT-TW 88.70	
ULT-230 7.65	
ULT-165 3.65	

Starting Point	Formula
293 C	
ULT-230 61.00	
ULT-TW 25.30	
ULT-165 8.70	
ULT-127 5.00	

Starting Point	Formula
294 C	
ULT-230 69.35	
ULT-165 21.40	
ULT-164 9.25	

Starting Point	Formula
295 C	
ULT-230 41.05	
ULT-165 36.55	
ULT-064 17.40	
ULT-127 5.00	

Starting Point	Formula
296 C	
ULT-230 43.00	
ULT-114 29.75	
ULT-165 22.25	
ULT-127 5.00	

Starting Point	Formula
2905 C	
ULT-TW 94.30	
ULT-230 3.90	
ULT-165 1.80	

Starting Point	Formula
2915 C	
ULT-TW 89.30	
ULT-230 7.80	
ULT-165 2.90	

Starting Point	Formula
2925 C	
ULT-TW 72.90	
ULT-230 22.50	
ULT-165 4.60	

Starting Point	Formula
2935 C	
ULT-230 54.40	
ULT-TW 40.60	
ULT-127 5.00	

Starting Point	Formula
2945 C	
ULT-230 75.30	
ULT-TW 19.70	
ULT-127 5.00	

Starting Point	Formula
2955 C	
ULT-230 62.30	
ULT-165 27.30	
ULT-114 10.40	

Starting Point	Formula
2965 C	
ULT-230 64.05	
ULT-114 18.00	
ULT-164 17.95	

Starting Point	Formula
297 C	
ULT-TW 93.00	
ULT-230 5.65	
ULT-165 1.35	

Starting Point	Formula
298 C	
ULT-TW 87.95	
ULT-230 10.20	
ULT-165 1.85	

Starting Point	Formula
299 C	
ULT-TW 76.85	
ULT-230 21.00	
ULT-165 2.15	

Fascure ULT

Starting Point	Formula
300 C	
ULT-230 75.47	
ULT-TW 24.53	

Starting Point	Formula
301 C	
ULT-230 88.80	
ULT-165 11.20	

Starting Point	Formula
302 C	
ULT-230 75.50	
ULT-114 12.30	
ULT-165 12.20	

Starting Point	Formula
303 C	
ULT-230 67.60	
ULT-114 22.30	
ULT-165 10.10	

Starting Point	Formula
2975 C	
ULT-TW 97.30	
ULT-230 2.70	

Starting Point	Formula
2985 C	
ULT-TW 90.20	
ULT-230 8.80	
ULT-165 1.00	

Starting Point	Formula
2995 C	
ULT-TW 74.80	
ULT-230 25.20	

Starting Point	Formula
3005 C	
ULT-230 63.80	
ULT-TW 36.20	

Starting Point	Formula
3015 C	
ULT-230 98.70	
ULT-114 1.30	

Starting Point	Formula
3025 C	
ULT-230 84.20	
ULT-114 12.90	
ULT-165 2.90	

Starting Point	Formula
3035 C	
ULT-230 73.40	
ULT-114 22.75	
ULT-164 3.85	

Starting Point	Formula
304 C	
ULT-TW 86.00	
ULT-MX 11.80	
ULT-230 2.20	

Starting Point	Formula
305 C	
ULT-TW 93.00	
ULT-230 7.00	

Starting Point	Formula
306 C	
ULT-TW 83.80	
ULT-230 16.20	

Starting Point	Formula
307 C	
ULT-230 65.80	
ULT-TW 34.20	

Starting Point	Formula
308 C	
ULT-230 85.80	
ULT-064 10.70	
ULT-164 3.50	

Fascure ULT

Starting Point	Formula
309 C	
ULT-230 44.60	
ULT-SB 31.08	
ULT-MX 24.32	

Starting Point	Formula
310 C	
ULT-TW 94.70	
ULT-230 5.30	

Starting Point	Formula
311 C	
ULT-TW 91.00	
ULT-230 9.00	

Starting Point	Formula
312 C	
ULT-TW 72.50	
ULT-230 22.30	
ULT-325 5.20	

Starting Point	Formula
313 C	
ULT-TW 58.75	
ULT-230 34.75	
ULT-325 6.50	

Starting Point	Formula
314 C	
ULT-230 48.75	
ULT-TW 39.40	
ULT-325 11.85	

Starting Point	Formula
315 C	
ULT-230 63.10	
ULT-TW 17.70	
ULT-325 15.50	
ULT-114 3.70	

Starting Point	Formula
316 C	
ULT-230 66.70	
ULT-114 24.60	
ULT-325 8.70	

Starting Point	Formula
3105 C	
ULT-TW 95.60	
ULT-230 4.40	

Starting Point	Formula
3115 C	
ULT-TW 89.20	
ULT-230 8.00	
ULT-325 2.80	

Starting Point	Formula
3125 C	
ULT-TW 76.15	
ULT-230 16.05	
ULT-325 7.80	

Starting Point	Formula
3135 C	
ULT-TW 56.65	
ULT-230 30.80	
ULT-325 12.55	

Starting Point	Formula
3145 C	
ULT-230 49.30	
ULT-TW 29.45	
ULT-325 21.25	

Starting Point	Formula
3155 C	
ULT-230 57.40	
ULT-325 22.25	
ULT-TW 15.65	
ULT-114 4.70	

Starting Point	Formula
3165 C	
ULT-230 64.80	
ULT-325 18.85	
ULT-114 16.35	

Starting Point	Formula
317 C	
ULT-TW 98.70	
ULT-230 1.30	

Fascure ULT

Starting Point	Formula
318 C	
ULT-TW 96.15	
ULT-230 2.90	
ULT-325 0.95	

Starting Point	Formula
319 C	
ULT-TW 89.95	
ULT-230 5.85	
ULT-325 4.20	

Starting Point	Formula
320 C	
ULT-TW 47.80	
ULT-230 26.10	
ULT-325 26.10	

Starting Point	Formula
321 C	
ULT-230 40.50	
ULT-325 32.90	
ULT-TW 26.60	

Starting Point	Formula
322 C	
ULT-230 45.55	
ULT-325 32.60	
ULT-TW 17.00	
ULT-114 4.85	

Starting Point	Formula
323 C	
ULT-230 47.55	
ULT-325 28.65	
ULT-114 12.10	
ULT-TW 11.70	

Starting Point	Formula
324 C	
ULT-TW 96.50	
ULT-230 2.25	
ULT-325 1.25	

Starting Point	Formula
325 C	
ULT-TW 90.85	
ULT-325 4.90	
ULT-230 4.25	

Starting Point	Formula
326 C	
ULT-TW 74.35	
ULT-325 15.65	
ULT-230 10.00	

Starting Point	Formula
327 C	
ULT-325 56.70	
ULT-230 31.75	
ULT-TW 11.55	

Starting Point	Formula
328 C	
ULT-325 55.70	
ULT-230 38.80	
ULT-114 5.50	

Starting Point	Formula
329 C	
ULT-230 56.50	
ULT-064 26.30	
ULT-325 12.40	
ULT-114 4.80	

Starting Point	Formula
330 C	
ULT-230 40.85	
ULT-325 25.05	
ULT-114 23.70	
ULT-TW 10.40	

Starting Point	Formula
3242 C	
ULT-TW 93.32	
ULT-325 2.95	
ULT-230 1.40	
ULT-MX 2.33	

Starting Point	Formula
3252 C	
ULT-TW 90.20	
ULT-325 6.45	
ULT-230 3.35	

Starting Point	Formula
3262 C	
ULT-TW 71.55	
ULT-325 20.30	
ULT-230 8.15	

Fascure ULT

Starting Point	Formula
3272 C	
ULT-MX 64.10	
ULT-325 22.50	
ULT-230 12.05	
ULT-064 1.35	

Starting Point	Formula
3282 C	
ULT-325 44.00	
ULT-TW 30.80	
ULT-230 23.40	
ULT-114 1.80	

Starting Point	Formula
3292 C	
ULT-325 45.70	
ULT-230 37.00	
ULT-114 17.30	

Starting Point	Formula
3302 C	
ULT-SB 31.52	
ULT-MX 30.29	
ULT-325 26.55	
ULT-230 11.64	

Starting Point	Formula
3245 C	
ULT-TW 94.00	
ULT-325 4.45	
ULT-230 1.55	

Starting Point	Formula
3255 C	
ULT-TW 88.00	
ULT-325 9.55	
ULT-230 2.45	

Starting Point	Formula
3265 C	
ULT-TW 74.75	
ULT-325 20.90	
ULT-230 4.35	

Starting Point	Formula
3275 C	
ULT-TW 52.00	
ULT-325 41.70	
ULT-230 6.30	

Starting Point	Formula
3285 C	
ULT-TW 44.90	
ULT-325 41.80	
ULT-230 11.50	
ULT-114 1.80	

Starting Point	Formula
3295 C	
ULT-325 49.35	
ULT-TW 27.80	
ULT-230 16.75	
ULT-114 6.10	

Starting Point	Formula
3305 C	
ULT-325 35.60	
ULT-230 34.70	
ULT-114 29.70	

Starting Point	Formula
3248 C	
ULT-TW 92.40	
ULT-325 4.85	
ULT-230 2.05	
ULT-114 0.70	

Starting Point	Formula
3258 C	
ULT-TW 86.00	
ULT-325 9.90	
ULT-230 3.15	
ULT-114 0.95	

Starting Point	Formula
3268 C	
ULT-TW 60.95	
ULT-325 31.30	
ULT-230 6.75	
ULT-114 1.00	

Starting Point	Formula
3278 C	
ULT-325 53.00	
ULT-TW 35.90	
ULT-230 9.90	
ULT-114 1.20	

Starting Point	Formula
3288 C	
ULT-325 63.00	
ULT-230 16.40	
ULT-TW 15.40	
ULT-114 5.20	

Fascure ULT

Starting Point	Formula
3298 C	
ULT-066 41.70	
ULT-230 27.35	
ULT-325 26.35	
ULT-164 4.60	

Starting Point	Formula
3308 C	
ULT-230 39.60	
ULT-114 36.30	
ULT-325 24.10	

Starting Point	Formula
331 C	
ULT-TW 97.00	
ULT-325 3.00	

Starting Point	Formula
332 C	
ULT-TW 95.50	
ULT-325 4.50	

Starting Point	Formula
333 C	
ULT-TW 88.50	
ULT-325 10.80	
ULT-230 0.70	

Starting Point	Formula
334 C	
ULT-325 64.70	
ULT-TW 29.55	
ULT-230 4.85	
ULT-114 0.90	

Starting Point	Formula
335 C	
ULT-325 57.60	
ULT-TW 24.10	
ULT-230 10.80	
ULT-114 7.50	

Starting Point	Formula
336 C	
ULT-325 57.56	
ULT-TW 17.08	
ULT-SB 17.03	
ULT-MX 8.33	

Starting Point	Formula
337 C	
ULT-TW 93.60	
ULT-325 4.80	
ULT-114 0.85	
ULT-230 0.75	

Starting Point	Formula
338 C	
ULT-TW 90.50	
ULT-325 7.35	
ULT-230 1.20	
ULT-114 0.95	

Starting Point	Formula
339 C	
ULT-TW 61.60	
ULT-325 35.55	
ULT-114 1.85	
ULT-230 1.00	

Starting Point	Formula
340 C	
ULT-325 87.70	
ULT-TW 9.70	
ULT-114 2.60	

Starting Point	Formula
341 C	
ULT-064 36.50	
ULT-230 34.50	
ULT-325 14.20	
ULT-TW 12.65	
ULT-114 2.15	

Starting Point	Formula
342 C	
ULT-230 38.15	
ULT-064 37.65	
ULT-TW 10.05	
ULT-114 7.85	
ULT-325 6.3	

Starting Point	Formula
343 C	
ULT-325 45.80	
ULT-114 29.90	
ULT-230 24.30	

Starting Point	Formula
3375 C	
ULT-TW 92.00	
ULT-325 7.00	
ULT-064 1.00	

Fascure ULT

Starting Point	Formula
3385 C	
ULT-TW 83.90	
ULT-325 13.70	
ULT-064 2.40	

Starting Point	Formula
3395 C	
ULT-TW 62.00	
ULT-325 32.40	
ULT-064 5.60	

Starting Point	Formula
3405 C	
ULT-325 61.15	
ULT-TW 26.45	
ULT-064 12.40	

Starting Point	Formula
3415 C	
ULT-325 82.30	
ULT-114 11.00	
ULT-064 4.60	
ULT-230 2.10	

Starting Point	Formula
3425 C	
ULT-325 72.80	
ULT-114 19.70	
ULT-230 7.50	

Starting Point	Formula
3435 C	
ULT-325 45.00	
ULT-114 32.90	
ULT-230 22.10	

Starting Point	Formula
344 C	
ULT-TW 93.90	
ULT-325 4.80	
ULT-114 1.30	

Starting Point	Formula
345 C	
ULT-TW 89.30	
ULT-325 7.50	
ULT-064 2.10	
ULT-114 1.10	

Starting Point	Formula
346 C	
ULT-TW 79.30	
ULT-064 10.80	
ULT-325 6.30	
ULT-230 3.60	

Starting Point	Formula
347 C	
ULT-325 61.60	
ULT-064 33.30	
ULT-230 5.10	

Starting Point	Formula
348 C	
ULT-064 58.15	
ULT-230 25.95	
ULT-325 15.90	

Starting Point	Formula
349 C	
ULT-064 46.30	
ULT-230 27.90	
ULT-325 14.40	
ULT-114 11.40	

Starting Point	Formula
350 C	
ULT-325 41.70	
ULT-114 39.40	
ULT-230 18.90	

Starting Point	Formula
351 C	
ULT-TW 93.26	
ULT-064 3.63	
ULT-325 3.11	

Starting Point	Formula
352 C	
ULT-TW 87.25	
ULT-325 7.30	
ULT-064 5.45	

Starting Point	Formula
353 C	
ULT-TW 82.20	
ULT-325 10.20	
ULT-064 7.60	

Fascure ULT

Starting Point	Formula
354 C	
ULT-064 51.05	
ULT-325 39.73	
ULT-TW 9.22	

Starting Point	Formula
355 C	
ULT-064 48.90	
ULT-325 44.60	
ULT-230 6.50	

Starting Point	Formula
356 C	
ULT-064 45.10	
ULT-325 32.70	
ULT-230 14.60	
ULT-114 7.60	

Starting Point	Formula
357 C	
ULT-064 39.25	
ULT-325 27.34	
ULT-SB 23.29	
ULT-TW 10.12	

Starting Point	Formula
358 C	
ULT-TW 82.45	
ULT-064 12.50	
ULT-325 5.05	

Starting Point	Formula
359 C	
ULT-TW 79.75	
ULT-064 14.45	
ULT-325 5.80	

Starting Point	Formula
360 C	
ULT-064 45.50	
ULT-TW 38.65	
ULT-325 14.50	
ULT-230 1.35	

Starting Point	Formula
361 C	
ULT-064 61.40	
ULT-325 24.85	
ULT-TW 11.40	
ULT-230 2.35	

Starting Point	Formula
362 C	
ULT-064 84.00	
ULT-230 16.00	

Starting Point	Formula
363 C	
ULT-064 75.25	
ULT-325 13.25	
ULT-230 9.30	
ULT-164 2.20	

Starting Point	Formula
364 C	
ULT-325 47.80	
ULT-064 33.35	
ULT-114 18.85	

Starting Point	Formula
365 C	
ULT-TW 89.10	
ULT-064 8.95	
ULT-325 1.95	

Starting Point	Formula
366 C	
ULT-TW 83.70	
ULT-064 13.40	
ULT-325 2.90	

Starting Point	Formula
367 C	
ULT-TW 69.25	
ULT-064 25.55	
ULT-325 5.20	

Starting Point	Formula
368 C	
ULT-064 69.20	
ULT-TW 16.50	
ULT-325 13.35	
ULT-230 0.95	

Starting Point	Formula
369 C	
ULT-064 73.95	
ULT-325 23.30	
ULT-114 2.75	

Fascure ULT

Starting Point	Formula
370 C	
ULT-064 69.50	
ULT-325 24.50	
ULT-114 3.85	
ULT-164 2.15	

Starting Point	Formula
371 C	
ULT-064 60.00	
ULT-325 26.65	
ULT-164 8.35	
ULT-114 5.00	

Starting Point	Formula
372 C	
ULT-TW 87.70	
ULT-064 10.85	
ULT-325 1.45	

Starting Point	Formula
373 C	
ULT-TW 77.80	
ULT-064 19.80	
ULT-325 2.40	

Starting Point	Formula
374 C	
ULT-TW 56.50	
ULT-064 39.35	
ULT-325 4.15	

Starting Point	Formula
375 C	
ULT-064 85.35	
ULT-325 9.00	
ULT-TW 5.65	

Starting Point	Formula
376 C	
ULT-064 87.00	
ULT-325 12.25	
ULT-114 0.75	

Starting Point	Formula
377 C	
ULT-064 76.00	
ULT-325 17.65	
ULT-114 5.00	
ULT-164 1.35	

Starting Point	Formula
378 C	
ULT-064 61.10	
ULT-325 24.40	
ULT-164 9.50	
ULT-114 5.00	

Starting Point	Formula
379 C	
ULT-MX 66.10	
ULT-064 20.47	
ULT-TW 8.36	
ULT-066 4.13	
ULT-325 0.94	

Starting Point	Formula
380 C	
ULT-064 53.10	
ULT-TW 44.60	
ULT-325 2.30	

Starting Point	Formula
381 C	
ULT-064 79.50	
ULT-TW 17.20	
ULT-325 3.30	

Starting Point	Formula
382 C	
ULT-064 65.00	
ULT-MX 24.52	
ULT-066 7.54	
ULT-325 2.94	

Starting Point	Formula
383 C	
ULT-064 91.25	
ULT-325 7.00	
ULT-164 1.75	

Starting Point	Formula
384 C	
ULT-064 83.10	
ULT-325 10.30	
ULT-114 5.00	
ULT-164 1.60	

Starting Point	Formula
385 C	
ULT-064 79.25	
ULT-SB 16.00	
ULT-325 3.17	
ULT-114 1.58	

Fascure ULT

Starting Point	Formula
386 C	
ULT-TW 66.80	
ULT-064 32.00	
ULT-325 1.20	

Starting Point	Formula
387 C	
ULT-064 61.40	
ULT-TW 36.70	
ULT-325 1.90	

Starting Point	Formula
388 C	
ULT-064 94.10	
ULT-TW 3.30	
ULT-325 2.60	

Starting Point	Formula
389 C	
ULT-064 97.00	
ULT-325 3.00	

Starting Point	Formula
390 C	
ULT-064 92.55	
ULT-325 5.30	
ULT-114 2.15	

Starting Point	Formula
391 C	
ULT-064 83.85	
ULT-325 9.20	
ULT-114 5.00	
ULT-164 1.95	

Starting Point	Formula
392 C	
ULT-064 61.65	
ULT-325 17.60	
ULT-114 20.75	

Starting Point	Formula
393 C	
ULT-TW 81.50	
ULT-064 17.90	
ULT-325 0.60	

Starting Point	Formula
394 C	
ULT-064 51.60	
ULT-TW 47.25	
ULT-325 1.15	

Starting Point	Formula
395 C	
ULT-064 93.90	
ULT-TW 4.45	
ULT-325 1.65	

Starting Point	Formula
396 C	
ULT-064 98.30	
ULT-325 1.70	

Starting Point	Formula
397 C	
ULT-064 93.10	
ULT-325 4.05	
ULT-114 2.85	

Starting Point	Formula
398 C	
ULT-064 86.35	
ULT-114 7.00	
ULT-325 6.65	

Starting Point	Formula
399 C	
ULT-064 77.75	
ULT-114 12.25	
ULT-325 10.00	

Starting Point	Formula
3935 C	
ULT-TW 74.20	
ULT-064 25.25	
ULT-325 0.55	

Starting Point	Formula
3945 C	
ULT-064 82.25	
ULT-TW 16.65	
ULT-325 1.10	

Fascure ULT

Starting Point	Formula
3955 C	
ULT-064 99.00	
ULT-325 1.00	

Starting Point	Formula
3965 C	
ULT-064 100.00	

Starting Point	Formula
3975 C	
ULT-064 88.45	
ULT-114 6.35	
ULT-325 5.20	

Starting Point	Formula
3985 C	
ULT-064 77.70	
ULT-114 11.40	
ULT-325 9.90	
ULT-164 1.00	

Starting Point	Formula
3995 C	
ULT-064 40.65	
ULT-114 32.75	
ULT-325 25.20	
ULT-164 1.40	

Starting Point	Formula
400 C	
ULT-TW 96.04	
ULT-SB 2.61	
ULT-064 1.23	
ULT-127 0.12	

Starting Point	Formula
401 C	
ULT-TW 93.80	
ULT-SB 5.40	
ULT-114 0.50	
ULT-064 0.30	

Starting Point	Formula
402 C	
ULT-TW 90.95	
ULT-SB 7.80	
ULT-064 0.50	
ULT-114 0.75	

Starting Point	Formula
403 C	
ULT-TW 84.10	
ULT-SB 12.70	
ULT-064 1.90	
ULT-114 1.30	

Starting Point	Formula
404 C	
ULT-TW 70.65	
ULT-SB 21.85	
ULT-064 4.70	
ULT-114 2.80	

Starting Point	Formula
405 C	
ULT-TW 50.15	
ULT-SB 35.35	
ULT-064 8.90	
ULT-114 5.60	

Starting Point	Formula
406 C	
ULT-TW 95.10	
ULT-SB 3.55	
ULT-064 0.80	
ULT-165 0.55	

Starting Point	Formula
407 C	
ULT-TW 91.75	
ULT-SB 5.80	
ULT-064 1.40	
ULT-165 1.05	

Starting Point	Formula
408 C	
ULT-TW 85.00	
ULT-SB 9.85	
ULT-064 3.30	
ULT-165 1.85	

Starting Point	Formula
409 C	
ULT-TW 77.80	
ULT-SB 14.15	
ULT-064 5.10	
ULT-165 2.95	

Starting Point	Formula
410 C	
ULT-TW 61.20	
ULT-SB 22.90	
ULT-064 10.20	
ULT-165 5.70	

Fascure ULT

Starting Point	Formula
411 C	
ULT-TW 41.25	
ULT-SB 33.00	
ULT-064 16.20	
ULT-165 9.55	

Starting Point	Formula
412 C	
ULT-SB 66.70	
ULT-064 19.75	
ULT-165 11.10	
ULT-114 2.45	

Starting Point	Formula
413 C	
ULT-TW 96.30	
ULT-SB 3.30	
ULT-064 0.20	
ULT-325 0.20	

Starting Point	Formula
414 C	
ULT-TW 93.40	
ULT-SB 5.50	
ULT-064 0.80	
ULT-325 0.30	

Starting Point	Formula
415 C	
ULT-TW 87.10	
ULT-SB 10.10	
ULT-064 2.30	
ULT-325 0.50	

Starting Point	Formula
416 C	
ULT-TW 78.80	
ULT-SB 15.80	
ULT-064 4.60	
ULT-325 0.80	

Starting Point	Formula
417 C	
ULT-TW 65.30	
ULT-SB 25.00	
ULT-064 8.40	
ULT-325 1.30	

Starting Point	Formula
418 C	
ULT-TW 49.45	
ULT-SB 36.45	
ULT-064 12.70	
ULT-325 1.40	

Starting Point	Formula
419 C	
ULT-SB 96.30	
ULT-064 3.70	

Starting Point	Formula
420 C	
ULT-TW 97.21	
ULT-SB 2.33	
ULT-230 0.25	
ULT-127 0.21	

Starting Point	Formula
421 C	
ULT-TW 95.20	
ULT-SB 4.03	
ULT-230 0.46	
ULT-127 0.31	

Starting Point	Formula
422 C	
ULT-TW 92.31	
ULT-SB 6.49	
ULT-230 0.73	
ULT-127 0.47	

Starting Point	Formula
423 C	
ULT-TW 88.41	
ULT-SB 9.97	
ULT-230 1.05	
ULT-127 0.57	

Starting Point	Formula
424 C	
ULT-MX 78.96	
ULT-SB 17.83	
ULT-230 1.99	
ULT-127 1.22	

Starting Point	Formula
425 C	
ULT-MX 63.82	
ULT-SB 31.67	
ULT-230 2.79	
ULT-127 1.72	

Starting Point	Formula
426 C	
ULT-SB 94.58	
ULT-230 3.57	
ULT-127 1.85	

Fascure ULT

Starting Point	Formula
427 C	
ULT-TW 97.87	
ULT-SB 0.89	
ULT-325 0.69	
ULT-127 0.55	

Starting Point	Formula
428 C	
ULT-TW 96.52	
ULT-SB 1.86	
ULT-325 0.95	
ULT-127 0.67	

Starting Point	Formula
429 C	
ULT-TW 93.20	
ULT-SB 3.97	
ULT-325 1.71	
ULT-127 1.12	

Starting Point	Formula
430 C	
ULT-TW 85.54	
ULT-SB 9.36	
ULT-325 3.32	
ULT-127 1.78	

Starting Point	Formula
431 C	
ULT-TW 66.54	
ULT-SB 20.40	
ULT-325 8.73	
ULT-127 4.33	

Starting Point	Formula
432 C	
ULT-TW 39.53	
ULT-SB 36.11	
ULT-325 15.60	
ULT-127 8.76	

Starting Point	Formula
433 C	
ULT-SB 80.43	
ULT-MX 10.16	
ULT-127 9.41	

Starting Point	Formula
434 C	
ULT-TW 96.67	
ULT-SB 1.95	
ULT-165 1.38	

Starting Point	Formula
435 C	
ULT-TW 95.81	
ULT-SB 2.29	
ULT-165 1.90	

Starting Point	Formula
436 C	
ULT-TW 92.43	
ULT-114 4.58	
ULT-127 1.65	
ULT-325 1.34	

Starting Point	Formula
437 C	
ULT-TW 71.22	
ULT-114 16.37	
ULT-127 6.21	
ULT-325 6.20	

Starting Point	Formula
438 C	
ULT-114 41.38	
ULT-TW 26.48	
ULT-325 20.69	
ULT-127 11.45	

Starting Point	Formula
439 C	
ULT-114 44.11	
ULT-325 27.87	
ULT-TW 15.82	
ULT-127 12.20	

Starting Point	Formula
440 C	
ULT-114 48.18	
ULT-325 38.23	
ULT-127 13.59	

Starting Point	Formula
441 C	
ULT-TW 96.54	
ULT-325 1.68	
ULT-121 1.35	
ULT-127 0.43	

Starting Point	Formula
442 C	
ULT-TW 92.66	
ULT-325 3.63	
ULT-121 3.01	
ULT-127 0.70	

Fascure ULT

Starting Point	Formula
443 C	
ULT-TW 87.53	
ULT-325 6.11	
ULT-121 5.27	
ULT-127 1.09	

Starting Point	Formula
444 C	
ULT-TW 74.13	
ULT-325 13.18	
ULT-121 10.79	
ULT-127 1.90	

Starting Point	Formula
445 C	
ULT-TW 37.81	
ULT-325 31.73	
ULT-121 26.68	
ULT-127 3.78	

Starting Point	Formula
446 C	
ULT-325 42.72	
ULT-121 36.42	
ULT-TW 16.66	
ULT-127 4.20	

Starting Point	Formula
447 C	
ULT-325 49.76	
ULT-121 46.07	
ULT-127 4.17	

Starting Point	Formula
WARM GRAY 1 C	
ULT-TW 99.02	
ULT-SB 0.93	
ULT-127 0.05	

Starting Point	Formula
WARM GRAY 2 C	
ULT-TW 98.33	
ULT-SB 1.48	
ULT-127 0.19	

Starting Point	Formula
WARM GRAY 3 C	
ULT-TW 96.60	
ULT-SB 3.24	
ULT-127 0.16	

Starting Point	Formula
WARM GRAY 4 C	
ULT-TW 93.90	
ULT-SB 5.50	
ULT-121 0.60	

Starting Point	Formula
WARM GRAY 5 C	
ULT-TW 91.45	
ULT-SB 7.30	
ULT-121 0.70	
ULT-066 0.55	

Starting Point	Formula
WARM GRAY 6 C	
ULT-TW 90.66	
ULT-SB 8.19	
ULT-121 0.88	
ULT-066 0.27	

Starting Point	Formula
WARM GRAY 7 C	
ULT-TW 85.47	
ULT-SB 11.00	
ULT-066 2.25	
ULT-121 1.28	

Starting Point	Formula
WARM GRAY 8 C	
ULT-TW 79.75	
ULT-SB 14.83	
ULT-066 3.59	
ULT-121 1.83	

Starting Point	Formula
WARM GRAY 9 C	
ULT-TW 74.45	
ULT-SB 17.86	
ULT-066 5.34	
ULT-121 2.35	

Starting Point	Formula
WARM GRAY 10 C	
ULT-TW 61.48	
ULT-SB 24.93	
ULT-066 10.05	
ULT-121 3.54	

Starting Point	Formula
WARM GRAY 11 C	
ULT-TW 42.50	
ULT-SB 24.38	
ULT-MX 18.24	
ULT-064 8.52	
ULT-114 6.36	

Fascure ULT

Starting Point	Formula
COOL GRAY 1 C	
ULT-TW 99.32	
ULT-SB 0.56	
ULT-127 0.06	
ULT-230 0.06	

Starting Point	Formula
COOL GRAY 2 C	
ULT-TW 98.18	
ULT-SB 1.50	
ULT-127 0.18	
ULT-230 0.14	

Starting Point	Formula
COOL GRAY 3 C	
ULT-TW 97.07	
ULT-SB 2.37	
ULT-127 0.30	
ULT-230 0.26	

Starting Point	Formula
COOL GRAY 4 C	
ULT-TW 95.83	
ULT-SB 3.41	
ULT-127 0.39	
ULT-230 0.37	

Starting Point	Formula
COOL GRAY 5 C	
ULT-TW 94.26	
ULT-SB 4.83	
ULT-230 0.47	
ULT-127 0.44	

Starting Point	Formula
COOL GRAY 6 C	
ULT-TW 93.62	
ULT-SB 5.30	
ULT-127 0.57	
ULT-230 0.51	

Starting Point	Formula
COOL GRAY 7 C	
ULT-TW 91.29	
ULT-SB 7.45	
ULT-230 0.63	
ULT-127 0.63	

Starting Point	Formula
COOL GRAY 8 C	
ULT-TW 88.12	
ULT-SB 10.35	
ULT-127 0.77	
ULT-230 0.76	

Starting Point	Formula
COOL GRAY 9 C	
ULT-TW 83.42	
ULT-SB 14.72	
ULT-230 0.97	
ULT-127 0.89	

Starting Point	Formula
COOL GRAY 10 C	
ULT-TW 75.13	
ULT-SB 21.97	
ULT-230 1.59	
ULT-164 1.31	

Starting Point	Formula
COOL GRAY 11 C	
ULT-TW 63.26	
ULT-SB 30.83	
ULT-064 4.69	
ULT-164 0.90	
ULT-230 0.32	

Starting Point	Formula
448 C	
ULT-066 59.28	
ULT-SB 40.72	

Starting Point	Formula
449 C	
ULT-066 65.49	
ULT-SB 34.51	

Starting Point	Formula
450 C	
ULT-066 69.25	
ULT-SB 30.75	

Starting Point	Formula
451 C	
ULT-TW 61.20	
ULT-066 25.58	
ULT-114 7.98	
ULT-230 5.24	

Starting Point	Formula
452 C	
ULT-TW 64.33	
ULT-MX 20.00	
ULT-066 10.75	
ULT-SB 4.92	

Fascure ULT

Starting Point	Formula
453 C	
ULT-TW 88.09	
ULT-066 8.56	
ULT-SB 2.81	
ULT-230 0.54	

Starting Point	Formula
454 C	
ULT-TW 94.07	
ULT-066 4.01	
ULT-SB 1.64	
ULT-230 0.28	

Starting Point	Formula
4485 C	
ULT-064 68.71	
ULT-SB 31.29	

Starting Point	Formula
4495 C	
ULT-064 82.98	
ULT-SB 17.02	

Starting Point	Formula
4505 C	
ULT-064 79.46	
ULT-165 12.06	
ULT-325 8.48	

Starting Point	Formula
4515 C	
ULT-064 66.61	
ULT-MX 20.01	
ULT-SB 12.41	
ULT-127 0.97	

Starting Point	Formula
4525 C	
ULT-TW 80.76	
ULT-064 14.50	
ULT-SB 4.74	

Starting Point	Formula
4535 C	
ULT-TW 85.27	
ULT-064 10.54	
ULT-165 2.49	
ULT-325 1.70	

Starting Point	Formula
4545 C	
ULT-TW 92.65	
ULT-064 4.93	
ULT-165 1.43	
ULT-325 0.99	

Starting Point	Formula
455 C	
ULT-064 76.17	
ULT-SB 22.04	
ULT-114 1.79	

Starting Point	Formula
456 C	
ULT-064 89.95	
ULT-SB 9.47	
ULT-114 0.58	

Starting Point	Formula
457 C	
ULT-064 93.87	
ULT-SB 4.93	
ULT-114 1.20	

Starting Point	Formula
458 C	
ULT-066 54.46	
ULT-TW 24.37	
ULT-MX 20.00	
ULT-230 1.17	

Starting Point	Formula
459 C	
ULT-TW 54.54	
ULT-064 23.71	
ULT-MX 20.00	
ULT-SB 1.75	

Starting Point	Formula
460 C	
ULT-TW 63.60	
ULT-MX 20.00	
ULT-064 15.25	
ULT-SB 1.15	

Starting Point	Formula
461 C	
ULT-TW 71.50	
ULT-MX 20.00	
ULT-064 7.90	
ULT-SB 0.60	

Fascure ULT

Starting Point	Formula
462 C	
ULT-064	44.53
ULT-SB	41.11
ULT-MX	9.81
ULT-164	4.55

Starting Point	Formula
463 C	
ULT-064	62.27
ULT-SB	27.72
ULT-164	6.83
ULT-TW	3.18

Starting Point	Formula
464 C	
ULT-064	68.52
ULT-SB	17.04
ULT-TW	8.16
ULT-164	6.28

Starting Point	Formula
465 C	
ULT-TW	65.34
ULT-064	23.91
ULT-SB	7.54
ULT-114	3.21

Starting Point	Formula
466 C	
ULT-TW	53.01
ULT-066	23.80
ULT-MX	20.00
ULT-164	1.61
ULT-230	1.58

Starting Point	Formula
467 C	
ULT-TW	69.84
ULT-MX	20.00
ULT-064	7.15
ULT-SB	2.59
ULT-164	0.42

Starting Point	Formula
468 C	
ULT-TW	93.27
ULT-066	4.90
ULT-SB	1.83

Starting Point	Formula
4625 C	
ULT-SB	44.81
ULT-064	28.04
ULT-114	27.15

Starting Point	Formula
4635 C	
ULT-TW	35.36
ULT-114	25.04
ULT-064	24.88
ULT-SB	14.72

Starting Point	Formula
4645 C	
ULT-TW	67.01
ULT-114	13.74
ULT-064	10.43
ULT-SB	8.82

Starting Point	Formula
4655 C	
ULT-TW	78.15
ULT-114	8.09
ULT-066	7.63
ULT-SB	6.13

Starting Point	Formula
4665 C	
ULT-TW	90.47
ULT-114	4.63
ULT-SB	3.57
ULT-064	1.33

Starting Point	Formula
4675 C	
ULT-TW	95.88
ULT-114	2.17
ULT-SB	1.95

Starting Point	Formula
4685 C	
ULT-TW	96.62
ULT-066	1.28
ULT-SB	1.08
ULT-121	1.02

Starting Point	Formula
469 C	
ULT-066	37.03
ULT-SB	33.31
ULT-114	24.96
ULT-164	4.70

Starting Point	Formula
470 C	
ULT-066	37.06
ULT-114	34.99
ULT-TW	15.75
ULT-SB	12.20

Fascure ULT

Starting Point	Formula
471 C	
ULT-066	53.96
ULT-114	37.94
ULT-SB	8.10

Starting Point	Formula
472 C	
ULT-TW	73.71
ULT-066	13.88
ULT-114	10.19
ULT-SB	2.22

Starting Point	Formula
473 C	
ULT-TW	92.38
ULT-114	4.88
ULT-064	1.63
ULT-SB	1.11

Starting Point	Formula
474 C	
ULT-TW	96.24
ULT-114	3.21
ULT-SB	0.55

Starting Point	Formula
475 C	
ULT-TW	93.54
ULT-064	3.84
ULT-114	2.32
ULT-SB	0.30

Starting Point	Formula
4695 C	
ULT-SB	43.15
ULT-114	42.24
ULT-TW	9.56
ULT-121	5.05

Starting Point	Formula
4705 C	
ULT-121	26.87
ULT-TW	25.58
ULT-064	24.26
ULT-SB	23.29

Starting Point	Formula
4715 C	
ULT-TW	61.51
ULT-064	22.15
ULT-SB	10.42
ULT-164	5.92

Starting Point	Formula
4725 C	
ULT-TW	74.60
ULT-064	12.53
ULT-SB	7.01
ULT-165	5.86

Starting Point	Formula
4735 C	
ULT-TW	87.51
ULT-064	5.62
ULT-SB	3.98
ULT-165	2.89

Starting Point	Formula
4745 C	
ULT-TW	93.69
ULT-064	2.51
ULT-SB	2.24
ULT-165	1.56

Starting Point	Formula
4755 C	
ULT-TW	95.83
ULT-066	1.97
ULT-SB	1.76
ULT-164	0.44

Starting Point	Formula
476 C	
ULT-066	56.46
ULT-SB	36.39
ULT-164	7.15

Starting Point	Formula
477 C	
ULT-064	56.35
ULT-SB	29.45
ULT-164	14.20

Starting Point	Formula
478 C	
ULT-064	62.36
ULT-SB	22.94
ULT-164	14.70

Starting Point	Formula
479 C	
ULT-TW	58.34
ULT-066	27.91
ULT-SB	8.04
ULT-165	5.71

Fascure ULT

Starting Point	Formula
480 C	
ULT-TW	86.79
ULT-066	8.29
ULT-SB	3.68
ULT-164	1.24

Starting Point	Formula
481 C	
ULT-TW	94.74
ULT-064	2.49
ULT-SB	2.03
ULT-164	0.74

Starting Point	Formula
482 C	
ULT-TW	96.74
ULT-064	1.46
ULT-SB	1.39
ULT-164	0.41

Starting Point	Formula
483 C	
ULT-114	30.44
ULT-SB	26.59
ULT-165	22.38
ULT-064	20.59

Starting Point	Formula
484 C	
ULT-064	69.79
ULT-164	22.39
ULT-SB	7.82

Starting Point	Formula
485 C	
ULT-114	46.85
ULT-165	36.94
ULT-064	16.21

Starting Point	Formula
486 C	
ULT-TW	74.00
ULT-064	16.67
ULT-165	8.97
ULT-SB	0.36

Starting Point	Formula
487 C	
ULT-TW	81.91
ULT-066	14.59
ULT-164	2.92
ULT-SB	0.58

Starting Point	Formula
488 C	
ULT-TW	90.48
ULT-064	6.87
ULT-164	2.24
ULT-SB	0.41

Starting Point	Formula
489 C	
ULT-TW	93.31
ULT-064	4.40
ULT-165	1.76
ULT-114	0.53

Starting Point	Formula
490 C	
ULT-SB	38.78
ULT-114	27.81
ULT-TW	18.96
ULT-121	14.45

Starting Point	Formula
491 C	
ULT-121	48.50
ULT-TW	23.05
ULT-114	19.57
ULT-230	8.88

Starting Point	Formula
492 C	
ULT-121	52.57
ULT-TW	30.19
ULT-114	11.22
ULT-230	6.02

Starting Point	Formula
493 C	
ULT-TW	85.05
ULT-121	7.60
ULT-165	6.78
ULT-230	0.57

Starting Point	Formula
494 C	
ULT-TW	92.47
ULT-165	4.70
ULT-121	2.83

Starting Point	Formula
495 C	
ULT-TW	94.90
ULT-165	3.39
ULT-121	1.71

Fascure ULT

Starting Point	Formula
496 C	
ULT-TW 96.21	
ULT-165 2.62	
ULT-121 1.17	

Starting Point	Formula
497 C	
ULT-SB 44.90	
ULT-114 31.88	
ULT-TW 23.22	

Starting Point	Formula
498 C	
ULT-121 53.40	
ULT-325 21.55	
ULT-TW 16.28	
ULT-114 8.77	

Starting Point	Formula
499 C	
ULT-121 47.62	
ULT-TW 22.14	
ULT-325 16.37	
ULT-114 13.87	

Starting Point	Formula
500 C	
ULT-TW 80.13	
ULT-165 10.41	
ULT-114 7.33	
ULT-325 2.13	

Starting Point	Formula
501 C	
ULT-TW 90.73	
ULT-121 4.60	
ULT-165 3.57	
ULT-325 1.10	

Starting Point	Formula
502 C	
ULT-TW 94.89	
ULT-165 2.38	
ULT-121 2.18	
ULT-325 0.55	

Starting Point	Formula
503 C	
ULT-TW 96.63	
ULT-165 1.79	
ULT-121 1.26	
ULT-325 0.32	

Starting Point	Formula
4975 C	
ULT-SB 50.51	
ULT-165 28.15	
ULT-114 21.34	

Starting Point	Formula
4985 C	
ULT-TW 45.10	
ULT-165 20.05	
ULT-114 18.07	
ULT-SB 16.78	

Starting Point	Formula
4995 C	
ULT-TW 66.47	
ULT-165 14.02	
ULT-SB 10.08	
ULT-114 9.43	

Starting Point	Formula
5005 C	
ULT-TW 81.39	
ULT-SB 6.33	
ULT-121 7.47	
ULT-165 4.81	

Starting Point	Formula
5015 C	
ULT-TW 91.51	
ULT-SB 3.00	
ULT-121 2.80	
ULT-165 2.69	

Starting Point	Formula
5025 C	
ULT-TW 94.78	
ULT-SB 1.89	
ULT-165 1.80	
ULT-121 1.53	

Starting Point	Formula
5035 C	
ULT-TW 96.40	
ULT-064 1.71	
ULT-165 1.20	
ULT-SB 0.69	

Starting Point	Formula
504 C	
ULT-SB 41.80	
ULT-114 20.18	
ULT-121 19.26	
ULT-TW 18.76	

Fascure ULT

Starting Point	Formula
505 C	
ULT-121 64.61	
ULT-TW 24.67	
ULT-230 10.72	

Starting Point	Formula
506 C	
ULT-121 35.73	
ULT-TW 34.21	
ULT-SB 18.57	
ULT-165 11.49	

Starting Point	Formula
507 C	
ULT-TW 87.44	
ULT-165 7.45	
ULT-121 4.37	
ULT-230 0.74	

Starting Point	Formula
508 C	
ULT-TW 94.13	
ULT-165 4.39	
ULT-121 1.27	
ULT-230 0.21	

Starting Point	Formula
509 C	
ULT-TW 97.64	
ULT-164 2.36	

Starting Point	Formula
510 C	
ULT-TW 96.77	
ULT-165 2.92	
ULT-121 0.31	

Starting Point	Formula
511 C	
ULT-165 43.20	
ULT-121 29.02	
ULT-TW 16.61	
ULT-230 11.17	

Starting Point	Formula
512 C	
ULT-165 64.36	
ULT-TW 25.59	
ULT-230 5.31	
ULT-121 4.74	

Starting Point	Formula
513 C	
ULT-165 55.85	
ULT-TW 41.02	
ULT-230 3.13	

Starting Point	Formula
514 C	
ULT-TW 84.73	
ULT-165 14.51	
ULT-230 0.76	

Starting Point	Formula
515 C	
ULT-TW 90.91	
ULT-165 8.64	
ULT-230 0.45	

Starting Point	Formula
516 C	
ULT-TW 94.75	
ULT-165 4.98	
ULT-230 0.27	

Starting Point	Formula
517 C	
ULT-TW 96.76	
ULT-165 3.05	
ULT-230 0.19	

Starting Point	Formula
5115 C	
ULT-165 41.67	
ULT-SB 41.66	
ULT-TW 8.33	
ULT-127 4.17	
ULT-121 4.17	

Starting Point	Formula
5125 C	
ULT-TW 54.29	
ULT-164 28.81	
ULT-SB 11.77	
ULT-230 5.13	

Starting Point	Formula
5135 C	
ULT-TW 73.39	
ULT-164 15.31	
ULT-SB 7.94	
ULT-230 3.36	

Fascure ULT

Starting Point	Formula
5145 C	
ULT-TW 86.46	
ULT-164 6.73	
ULT-SB 5.15	
ULT-230 1.66	

Starting Point	Formula
5155 C	
ULT-TW 94.08	
ULT-164 2.97	
ULT-SB 2.03	
ULT-230 0.92	

Starting Point	Formula
5165 C	
ULT-TW 97.54	
ULT-164 1.48	
ULT-230 0.64	
ULT-SB 0.34	

Starting Point	Formula
5175 C	
ULT-TW 96.96	
ULT-SB 1.49	
ULT-165 1.00	
ULT-127 0.30	
ULT-121 0.25	

Starting Point	Formula
518 C	
ULT-164 44.29	
ULT-325 27.79	
ULT-TW 20.65	
ULT-114 7.27	

Starting Point	Formula
519 C	
ULT-165 69.74	
ULT-325 19.53	
ULT-064 10.73	

Starting Point	Formula
520 C	
ULT-165 64.73	
ULT-TW 20.97	
ULT-325 14.30	

Starting Point	Formula
521 C	
ULT-TW 87.29	
ULT-164 5.22	
ULT-165 4.60	
ULT-230 2.89	

Starting Point	Formula
522 C	
ULT-TW 92.77	
ULT-165 3.02	
ULT-164 2.49	
ULT-230 1.72	

Starting Point	Formula
523 C	
ULT-TW 94.98	
ULT-165 2.81	
ULT-164 1.11	
ULT-230 1.10	

Starting Point	Formula
524 C	
ULT-TW 96.74	
ULT-165 2.58	
ULT-230 0.68	

Starting Point	Formula
5185 C	
ULT-SB 35.64	
ULT-TW 34.84	
ULT-121 22.54	
ULT-127 6.98	

Starting Point	Formula
5195 C	
ULT-TW 47.57	
ULT-121 23.36	
ULT-SB 16.84	
ULT-127 12.23	

Starting Point	Formula
5205 C	
ULT-TW 77.88	
ULT-114 8.37	
ULT-127 7.26	
ULT-SB 6.49	

Starting Point	Formula
5215 C	
ULT-TW 90.37	
ULT-114 4.67	
ULT-127 3.41	
ULT-325 1.55	

Starting Point	Formula
5225 C	
ULT-TW 95.51	
ULT-SB 1.61	
ULT-127 1.57	
ULT-114 1.31	

Fascure ULT

Starting Point	Formula
5235 C	
ULT-TW 97.22	
ULT-SB 1.00	
ULT-127 1.00	
ULT-114 0.78	

Starting Point	Formula
5245 C	
ULT-TW 97.53	
ULT-121 1.54	
ULT-230 0.53	
ULT-127 0.40	

Starting Point	Formula
525 C	
ULT-165 38.06	
ULT-SB 23.29	
ULT-127 18.79	
ULT-MX 12.67	
ULT-TW 7.19	

Starting Point	Formula
526 C	
ULT-165 71.41	
ULT-MX 16.46	
ULT-230 12.13	

Starting Point	Formula
527 C	
ULT-165 58.80	
ULT-MX 31.04	
ULT-230 10.16	

Starting Point	Formula
528 C	
ULT-TW 88.79	
ULT-127 7.19	
ULT-165 4.02	

Starting Point	Formula
529 C	
ULT-TW 82.02	
ULT-MX 15.00	
ULT-127 2.21	
ULT-165 0.77	

Starting Point	Formula
530 C	
ULT-MX 76.73	
ULT-TW 20.00	
ULT-127 2.16	
ULT-165 1.11	

Starting Point	Formula
531 C	
ULT-MX 86.71	
ULT-TW 11.61	
ULT-127 0.92	
ULT-165 0.76	

Starting Point	Formula
5255 C	
ULT-SB 44.02	
ULT-MX 27.49	
ULT-127 19.40	
ULT-230 9.09	

Starting Point	Formula
5265 C	
ULT-TW 48.82	
ULT-127 25.69	
ULT-SB 21.18	
ULT-230 4.31	

Starting Point	Formula
5275 C	
ULT-TW 65.87	
ULT-SB 15.33	
ULT-127 14.12	
ULT-230 4.68	

Starting Point	Formula
5285 C	
ULT-TW 65.87	
ULT-SB 15.33	
ULT-127 14.12	
ULT-230 4.68	

Starting Point	Formula
5295 C	
ULT-TW 94.89	
ULT-SB 2.47	
ULT-127 1.84	
ULT-230 0.80	

Starting Point	Formula
5305 C	
ULT-TW 97.05	
ULT-127 1.33	
ULT-SB 0.87	
ULT-325 0.75	

Starting Point	Formula
5315 C	
ULT-TW 98.46	
ULT-SB 0.90	
ULT-127 0.38	
ULT-230 0.26	

Fascure ULT

Starting Point	Formula
532 C	
ULT-SB 45.22	
ULT-165 33.56	
ULT-325 21.22	

Starting Point	Formula
533 C	
ULT-165 50.62	
ULT-325 36.30	
ULT-SB 13.08	

Starting Point	Formula
534 C	
ULT-165 46.94	
ULT-325 44.15	
ULT-127 4.51	
ULT-MX 4.40	

Starting Point	Formula
535 C	
ULT-TW 91.37	
ULT-164 3.82	
ULT-230 2.75	
ULT-325 2.06	

Starting Point	Formula
536 C	
ULT-TW 93.39	
ULT-164 2.83	
ULT-230 1.91	
ULT-325 1.87	

Starting Point	Formula
537 C	
ULT-TW 96.03	
ULT-165 2.31	
ULT-230 0.99	
ULT-325 0.67	

Starting Point	Formula
538 C	
ULT-TW 97.33	
ULT-165 1.61	
ULT-230 0.73	
ULT-325 0.33	

Starting Point	Formula
539 C	
ULT-230 46.95	
ULT-SB 20.23	
ULT-064 16.49	
ULT-164 16.33	

Starting Point	Formula
540 C	
ULT-230 40.06	
ULT-164 23.40	
ULT-MX 20.01	
ULT-SB 16.53	

Starting Point	Formula
541 C	
ULT-230 86.18	
ULT-164 7.54	
ULT-SB 6.28	

Starting Point	Formula
542 C	
ULT-TW 87.78	
ULT-230 8.04	
ULT-165 2.87	
ULT-164 1.31	

Starting Point	Formula
543 C	
ULT-TW 93.86	
ULT-230 3.40	
ULT-165 2.74	

Starting Point	Formula
544 C	
ULT-TW 96.06	
ULT-230 2.07	
ULT-165 1.87	

Starting Point	Formula
545 C	
ULT-TW 98.04	
ULT-230 1.08	
ULT-165 0.88	

Starting Point	Formula
5395 C	
ULT-SB 62.58	
ULT-165 28.94	
ULT-230 8.48	

Starting Point	Formula
5405 C	
ULT-TW 48.53	
ULT-MX 20.01	
ULT-230 12.08	
ULT-SB 11.95	
ULT-165 7.43	

Fascure ULT

Starting Point	Formula
5415 C	
ULT-TW 77.98	
ULT-230 8.59	
ULT-SB 8.47	
ULT-165 4.96	

Starting Point	Formula
5425 C	
ULT-TW 69.05	
ULT-MX 19.99	
ULT-230 4.10	
ULT-SB 3.89	
ULT-165 2.97	

Starting Point	Formula
5435 C	
ULT-TW 94.82	
ULT-230 2.02	
ULT-165 1.97	
ULT-SB 1.19	

Starting Point	Formula
5445 C	
ULT-TW 97.13	
ULT-165 1.57	
ULT-230 1.30	

Starting Point	Formula
5455 C	
ULT-TW 97.97	
ULT-165 1.18	
ULT-230 0.85	

Starting Point	Formula
546 C	
ULT-230 52.21	
ULT-SB 37.18	
ULT-TW 10.61	

Starting Point	Formula
547 C	
ULT-SB 41.16	
ULT-230 31.25	
ULT-MX 20.00	
ULT-165 7.59	

Starting Point	Formula
548 C	
ULT-230 52.21	
ULT-SB 37.18	
ULT-TW 10.61	

Starting Point	Formula
549 C	
ULT-TW 66.68	
ULT-MX 20.00	
ULT-230 7.72	
ULT-064 2.97	
ULT-164 2.63	

Starting Point	Formula
550 C	
ULT-TW 73.36	
ULT-MX 20.00	
ULT-230 3.98	
ULT-164 1.55	
ULT-064 1.11	

Starting Point	Formula
551 C	
ULT-TW 95.08	
ULT-230 2.44	
ULT-165 1.79	
ULT-064 0.69	

Starting Point	Formula
552 C	
ULT-TW 84.76	
ULT-MX 12.66	
ULT-230 1.46	
ULT-165 1.12	

Starting Point	Formula
5463 C	
ULT-SB 58.83	
ULT-230 38.23	
ULT-066 2.94	

Starting Point	Formula
5473 C	
ULT-TW 37.50	
ULT-230 31.66	
ULT-MX 16.15	
ULT-114 14.69	

Starting Point	Formula
5483 C	
ULT-TW 81.24	
ULT-230 10.59	
ULT-SB 4.75	
ULT-114 3.42	

Starting Point	Formula
5493 C	
ULT-TW 90.51	
ULT-230 5.74	
ULT-114 1.90	
ULT-121 1.85	

Fascure ULT

Starting Point	Formula
5503 C	
ULT-TW 70.38	
ULT-MX 25.00	
ULT-230 2.82	
ULT-121 1.80	

Starting Point	Formula
5513 C	
ULT-TW 97.12	
ULT-230 1.75	
ULT-121 1.13	

Starting Point	Formula
5523 C	
ULT-TW 97.90	
ULT-SB 1.12	
ULT-230 0.75	
ULT-066 0.23	

Starting Point	Formula
5467 C	
ULT-SB 67.17	
ULT-230 13.34	
ULT-064 10.88	
ULT-TW 8.61	

Starting Point	Formula
5477 C	
ULT-SB 30.58	
ULT-MX 25.00	
ULT-TW 20.92	
ULT-230 13.60	
ULT-064 9.9	

Starting Point	Formula
5487 C	
ULT-TW 58.23	
ULT-MX 17.36	
ULT-SB 14.26	
ULT-230 5.61	
ULT-064 4.54	

Starting Point	Formula
5497 C	
ULT-TW 66.52	
ULT-MX 25.00	
ULT-SB 6.69	
ULT-230 1.79	

Starting Point	Formula
5507 C	
ULT-TW 95.19	
ULT-SB 3.69	
ULT-230 1.12	

Starting Point	Formula
5517 C	
ULT-TW 96.58	
ULT-SB 2.00	
ULT-230 0.99	
ULT-121 0.43	

Starting Point	Formula
5527 C	
ULT-TW 97.76	
ULT-SB 1.66	
ULT-230 0.58	

Starting Point	Formula
553 C	
ULT-SB 53.67	
ULT-325 25.56	
ULT-064 14.70	
ULT-TW 6.07	

Starting Point	Formula
554 C	
ULT-325 35.04	
ULT-SB 30.82	
ULT-MX 20.00	
ULT-064 14.14	

Starting Point	Formula
555 C	
ULT-066 66.11	
ULT-230 24.50	
ULT-SB 9.39	

Starting Point	Formula
556 C	
ULT-TW 78.51	
ULT-064 11.22	
ULT-230 5.77	
ULT-SB 4.50	

Starting Point	Formula
557 C	
ULT-TW 68.46	
ULT-MX 20.00	
ULT-066 6.78	
ULT-230 2.82	
ULT-SB 1.94	

Starting Point	Formula
558 C	
ULT-TW 89.84	
ULT-066 7.09	
ULT-230 2.54	
ULT-164 0.53	

Fascure ULT

Starting Point	Formula
559 C	
ULT-TW	76.03
ULT-MX	20.01
ULT-064	1.56
ULT-230	1.49
ULT-121	0.91

Starting Point	Formula
5535 C	
ULT-325	28.79
ULT-SB	27.34
ULT-066	17.38
ULT-MX	14.27
ULT-164	6.7
ULT-TW	5.52

Starting Point	Formula
5545 C	
ULT-TW	56.64
ULT-SB	20.42
ULT-325	19.44
ULT-114	3.50

Starting Point	Formula
5555 C	
ULT-TW	78.65
ULT-SB	12.22
ULT-325	8.14
ULT-114	0.99

Starting Point	Formula
5565 C	
ULT-TW	88.93
ULT-SB	7.39
ULT-325	3.68

Starting Point	Formula
5575 C	
ULT-TW	93.59
ULT-SB	3.39
ULT-325	2.56
ULT-164	0.46

Starting Point	Formula
5585 C	
ULT-TW	96.17
ULT-SB	1.64
ULT-325	1.54
ULT-165	0.65

Starting Point	Formula
5595 C	
ULT-MX	51.48
ULT-TW	46.26
ULT-114	1.05
ULT-325	0.64
ULT-230	0.57

Starting Point	Formula
560 C	
ULT-MX	51.95
ULT-325	34.63
ULT-TW	13.42

Starting Point	Formula
561 C	
ULT-325	58.62
ULT-TW	22.78
ULT-121	16.07
ULT-127	2.53

Starting Point	Formula
562 C	
ULT-325	39.03
ULT-TW	30.04
ULT-MX	19.99
ULT-121	8.90
ULT-127	2.04

Starting Point	Formula
563 C	
ULT-TW	88.37
ULT-325	8.46
ULT-SB	2.63
ULT-127	0.54

Starting Point	Formula
564 C	
ULT-TW	94.92
ULT-325	2.50
ULT-SB	1.64
ULT-230	0.94

Starting Point	Formula
565 C	
ULT-TW	97.23
ULT-325	2.37
ULT-127	0.40

Starting Point	Formula
566 C	
ULT-TW	97.96
ULT-325	1.75
ULT-127	0.29

Starting Point	Formula
5605 C	
ULT-SB	73.21
ULT-066	15.51
ULT-325	11.28

Fascure ULT

Starting Point	Formula
5615 C	
ULT-TW 53.71	
ULT-SB 24.02	
ULT-064 11.30	
ULT-325 10.97	

Starting Point	Formula
5625 C	
ULT-TW 75.72	
ULT-SB 14.56	
ULT-325 5.83	
ULT-064 3.89	

Starting Point	Formula
5635 C	
ULT-TW 88.79	
ULT-SB 7.39	
ULT-325 2.53	
ULT-064 1.29	

Starting Point	Formula
5645 C	
ULT-TW 94.43	
ULT-SB 4.21	
ULT-325 1.36	

Starting Point	Formula
5655 C	
ULT-TW 95.84	
ULT-325 3.16	
ULT-SB 1.00	

Starting Point	Formula
5665 C	
ULT-TW 97.12	
ULT-325 2.22	
ULT-SB 0.66	

Starting Point	Formula
567 C	
ULT-325 60.49	
ULT-121 18.07	
ULT-TW 10.91	
ULT-SB 10.53	

Starting Point	Formula
568 C	
ULT-325 56.34	
ULT-TW 18.02	
ULT-121 17.51	
ULT-230 8.13	

Starting Point	Formula
569 C	
ULT-TW 56.12	
ULT-325 37.67	
ULT-121 6.21	

Starting Point	Formula
570 C	
ULT-TW 90.16	
ULT-325 6.75	
ULT-230 1.60	
ULT-121 1.49	

Starting Point	Formula
571 C	
ULT-TW 95.83	
ULT-325 2.35	
ULT-230 1.25	
ULT-121 0.57	

Starting Point	Formula
572 C	
ULT-TW 97.25	
ULT-325 1.39	
ULT-230 1.03	
ULT-121 0.33	

Starting Point	Formula
573 C	
ULT-TW 98.23	
ULT-325 1.41	
ULT-121 0.27	
ULT-230 0.09	

Starting Point	Formula
574 C	
ULT-064 59.26	
ULT-SB 32.00	
ULT-230 8.74	

Starting Point	Formula
575 C	
ULT-064 81.31	
ULT-230 13.55	
ULT-164 5.14	

Starting Point	Formula
576 C	
ULT-064 62.45	
ULT-TW 26.71	
ULT-230 8.76	
ULT-164 2.08	

Fascure ULT

Starting Point	Formula
577 C	
ULT-TW 83.37	
ULT-064 13.93	
ULT-230 2.19	
ULT-164 0.51	

Starting Point	Formula
578 C	
ULT-TW 70.32	
ULT-MX 20.00	
ULT-064 7.50	
ULT-230 1.15	
ULT-SB 1.03	

Starting Point	Formula
579 C	
ULT-TW 90.22	
ULT-064 7.66	
ULT-230 1.43	
ULT-121 0.69	

Starting Point	Formula
580 C	
ULT-TW 75.33	
ULT-MX 19.99	
ULT-064 3.57	
ULT-230 0.62	
ULT-SB 0.49	

Starting Point	Formula
5743 C	
ULT-064 48.17	
ULT-SB 40.22	
ULT-230 6.66	
ULT-TW 4.95	

Starting Point	Formula
5753 C	
ULT-066 68.95	
ULT-SB 16.90	
ULT-230 7.34	
ULT-MX 6.81	

Starting Point	Formula
5763 C	
ULT-066 76.68	
ULT-230 10.31	
ULT-165 7.80	
ULT-MX 5.21	

Starting Point	Formula
5773 C	
ULT-066 65.35	
ULT-MX 19.99	
ULT-230 8.21	
ULT-165 6.45	

Starting Point	Formula
5783 C	
ULT-TW 57.91	
ULT-MX 20.00	
ULT-066 18.05	
ULT-230 2.67	
ULT-164 1.37	

Starting Point	Formula
5793 C	
ULT-TW 90.87	
ULT-064 4.70	
ULT-SB 3.61	
ULT-325 0.82	

Starting Point	Formula
5803 C	
ULT-TW 73.60	
ULT-MX 19.99	
ULT-066 4.45	
ULT-SB 1.50	
ULT-230 0.46	

Starting Point	Formula
5747 C	
ULT-064 49.52	
ULT-SB 40.22	
ULT-325 10.26	

Starting Point	Formula
5757 C	
ULT-064 56.73	
ULT-MX 18.67	
ULT-SB 18.48	
ULT-325 6.12	

Starting Point	Formula
5767 C	
ULT-TW 35.27	
ULT-064 32.40	
ULT-MX 20.00	
ULT-SB 9.53	
ULT-325 2.8	

Starting Point	Formula
5777 C	
ULT-TW 44.60	
ULT-066 28.34	
ULT-MX 20.00	
ULT-325 5.18	
ULT-164 1.88	

Starting Point	Formula
5787 C	
ULT-TW 69.98	
ULT-MX 20.00	
ULT-064 6.60	
ULT-SB 2.67	
ULT-325 0.75	

Fascure ULT

Starting Point	Formula
5797 C	
ULT-TW 90.09	
ULT-066 7.47	
ULT-SB 1.55	
ULT-325 0.89	

Starting Point	Formula
5807 C	
ULT-TW 93.30	
ULT-066 4.88	
ULT-114 0.97	
ULT-230 0.85	

Starting Point	Formula
581 C	
ULT-064 64.61	
ULT-SB 30.65	
ULT-325 4.74	

Starting Point	Formula
582 C	
ULT-064 78.14	
ULT-SB 9.80	
ULT-MX 7.82	
ULT-325 4.24	

Starting Point	Formula
583 C	
ULT-064 73.60	
ULT-MX 20.00	
ULT-325 3.95	
ULT-SB 2.45	

Starting Point	Formula
584 C	
ULT-064 39.72	
ULT-TW 37.70	
ULT-MX 19.99	
ULT-325 1.89	
ULT-SB 0.7	

Starting Point	Formula
585 C	
ULT-TW 57.20	
ULT-064 21.30	
ULT-MX 20.00	
ULT-325 1.20	
ULT-SB 0.3	

Starting Point	Formula
586 C	
ULT-TW 63.88	
ULT-MX 20.00	
ULT-064 15.04	
ULT-325 0.90	
ULT-SB 0.18	

Starting Point	Formula
587 C	
ULT-TW 88.02	
ULT-064 11.21	
ULT-325 0.66	
ULT-SB 0.11	

Starting Point	Formula
5815 C	
ULT-064 47.20	
ULT-SB 41.49	
ULT-MX 6.69	
ULT-325 4.62	

Starting Point	Formula
5825 C	
ULT-064 66.53	
ULT-SB 18.34	
ULT-TW 12.77	
ULT-325 2.36	

Starting Point	Formula
5835 C	
ULT-TW 35.41	
ULT-064 33.99	
ULT-MX 20.00	
ULT-SB 9.37	
ULT-325 1.23	

Starting Point	Formula
5845 C	
ULT-TW 44.34	
ULT-066 28.90	
ULT-MX 20.00	
ULT-SB 4.72	
ULT-325 2.04	

Starting Point	Formula
5855 C	
ULT-TW 82.77	
ULT-066 13.71	
ULT-SB 2.52	
ULT-325 1.00	

Starting Point	Formula
5865 C	
ULT-TW 68.39	
ULT-MX 20.00	
ULT-066 9.15	
ULT-SB 1.75	
ULT-325 0.71	

Starting Point	Formula
5875 C	
ULT-TW 94.00	
ULT-064 4.15	
ULT-SB 1.62	
ULT-325 0.23	

Fascure ULT

Starting Point	Formula
600 C	
ULT-MX 71.43	
ULT-TW 21.43	
ULT-064 7.14	

Starting Point	Formula
601 C	
ULT-MX 56.25	
ULT-TW 36.13	
ULT-064 7.62	

Starting Point	Formula
602 C	
ULT-TW 73.42	
ULT-064 13.22	
ULT-MX 13.12	
ULT-325 0.24	

Starting Point	Formula
603 C	
ULT-TW 34.72	
ULT-064 33.94	
ULT-MX 30.76	
ULT-325 0.58	

Starting Point	Formula
604 C	
ULT-064 60.05	
ULT-MX 39.18	
ULT-325 0.77	

Starting Point	Formula
605 C	
ULT-064 98.57	
ULT-SB 0.76	
ULT-325 0.67	

Starting Point	Formula
606 C	
ULT-064 83.61	
ULT-MX 13.20	
ULT-SB 3.19	

Starting Point	Formula
607 C	
ULT-TW 92.76	
ULT-064 6.82	
ULT-325 0.32	
ULT-164 0.10	

Starting Point	Formula
608 C	
ULT-TW 71.23	
ULT-MX 20.00	
ULT-064 8.18	
ULT-325 0.38	
ULT-165 0.21	

Starting Point	Formula
609 C	
ULT-TW 62.87	
ULT-MX 20.01	
ULT-064 15.93	
ULT-325 0.72	
ULT-165 0.47	

Starting Point	Formula
610 C	
ULT-TW 51.60	
ULT-064 26.48	
ULT-MX 20.00	
ULT-325 1.11	
ULT-165 0.81	

Starting Point	Formula
611 C	
ULT-064 43.84	
ULT-TW 34.34	
ULT-MX 20.00	
ULT-230 0.92	
ULT-165 0.9	

Starting Point	Formula
612 C	
ULT-064 95.47	
ULT-SB 3.84	
ULT-230 0.69	

Starting Point	Formula
613 C	
ULT-064 92.77	
ULT-SB 7.23	

Starting Point	Formula
614 C	
ULT-TW 91.19	
ULT-066 8.16	
ULT-230 0.37	
ULT-SB 0.28	

Starting Point	Formula
615 C	
ULT-TW 72.43	
ULT-MX 20.00	
ULT-064 6.13	
ULT-121 0.82	
ULT-230 0.62	

Fascure ULT

Starting Point	Formula
616 C	
ULT-TW 88.68	
ULT-064 9.24	
ULT-121 1.22	
ULT-230 0.86	

Starting Point	Formula
617 C	
ULT-TW 59.16	
ULT-MX 20.00	
ULT-064 17.58	
ULT-SB 2.99	
ULT-230 0.27	

Starting Point	Formula
618 C	
ULT-066 54.96	
ULT-TW 21.22	
ULT-MX 19.99	
ULT-230 2.73	
ULT-165 1.1	

Starting Point	Formula
619 C	
ULT-064 68.75	
ULT-MX 20.00	
ULT-SB 10.38	
ULT-230 0.87	

Starting Point	Formula
620 C	
ULT-064 76.97	
ULT-SB 16.03	
ULT-MX 5.67	
ULT-325 1.33	

Starting Point	Formula
621 C	
ULT-TW 98.10	
ULT-325 1.00	
ULT-SB 0.90	

Starting Point	Formula
622 C	
ULT-TW 96.30	
ULT-325 2.10	
ULT-SB 1.60	

Starting Point	Formula
623 C	
ULT-TW 92.53	
ULT-SB 4.21	
ULT-325 3.26	

Starting Point	Formula
624 C	
ULT-TW 83.21	
ULT-SB 8.30	
ULT-325 6.72	
ULT-066 1.77	

Starting Point	Formula
625 C	
ULT-TW 50.37	
ULT-MX 19.99	
ULT-SB 13.88	
ULT-325 13.45	
ULT-066 2.31	

Starting Point	Formula
626 C	
ULT-325 31.94	
ULT-SB 31.13	
ULT-MX 20.00	
ULT-TW 16.93	

Starting Point	Formula
627 C	
ULT-SB 61.86	
ULT-325 34.31	
ULT-127 3.83	

Starting Point	Formula
628 C	
ULT-TW 98.42	
ULT-230 1.45	
ULT-127 0.13	

Starting Point	Formula
629 C	
ULT-TW 97.79	
ULT-230 2.00	
ULT-127 0.21	

Starting Point	Formula
630 C	
ULT-TW 75.28	
ULT-MX 20.00	
ULT-230 4.29	
ULT-SB 0.43	

Starting Point	Formula
631 C	
ULT-TW 70.29	
ULT-MX 19.99	
ULT-230 8.36	
ULT-SB 1.36	

Fascure ULT

Starting Point	Formula
632 C	
ULT-TW	59.38
ULT-MX	20.00
ULT-230	17.31
ULT-066	1.92
ULT-SB	1.39

Starting Point	Formula
633 C	
ULT-230	49.22
ULT-TW	28.79
ULT-MX	13.46
ULT-066	8.53

Starting Point	Formula
634 C	
ULT-230	88.01
ULT-064	7.31
ULT-121	4.68

Starting Point	Formula
635 C	
ULT-TW	69.70
ULT-MX	28.48
ULT-230	1.82

Starting Point	Formula
636 C	
ULT-TW	96.10
ULT-230	3.75
ULT-127	0.15

Starting Point	Formula
637 C	
ULT-TW	93.05
ULT-230	6.83
ULT-127	0.12

Starting Point	Formula
638 C	
ULT-TW	66.41
ULT-MX	20.00
ULT-230	13.59

Starting Point	Formula
639 C	
ULT-TW	54.53
ULT-230	25.47
ULT-MX	20.00

Starting Point	Formula
640 C	
ULT-230	42.03
ULT-TW	37.97
ULT-MX	20.00

Starting Point	Formula
641 C	
ULT-230	65.22
ULT-MX	24.66
ULT-325	6.68
ULT-TW	3.44

Starting Point	Formula
642 C	
ULT-TW	98.22
ULT-325	0.99
ULT-127	0.79

Starting Point	Formula
643 C	
ULT-TW	78.52
ULT-MX	20.00
ULT-230	0.95
ULT-127	0.53

Starting Point	Formula
644 C	
ULT-TW	92.93
ULT-230	3.06
ULT-066	2.37
ULT-127	1.64

Starting Point	Formula
645 C	
ULT-TW	88.00
ULT-230	7.32
ULT-164	3.34
ULT-SB	1.34

Starting Point	Formula
646 C	
ULT-TW	60.67
ULT-MX	20.00
ULT-230	12.10
ULT-164	5.78
ULT-064	1.45

Starting Point	Formula
647 C	
ULT-230	28.38
ULT-165	23.23
ULT-TW	21.59
ULT-MX	19.99
ULT-064	6.81

Fascure ULT

Starting Point	Formula
648 C	
ULT-230	56.98
ULT-164	32.61
ULT-SB	5.63
ULT-MX	4.78

Starting Point	Formula
649 C	
ULT-TW	98.89
ULT-127	0.59
ULT-230	0.52

Starting Point	Formula
650 C	
ULT-TW	83.48
ULT-MX	14.73
ULT-230	0.98
ULT-127	0.81

Starting Point	Formula
651 C	
ULT-TW	74.51
ULT-MX	20.01
ULT-230	3.24
ULT-164	2.24

Starting Point	Formula
652 C	
ULT-TW	65.67
ULT-MX	20.00
ULT-230	8.03
ULT-164	5.08
ULT-064	1.22

Starting Point	Formula
653 C	
ULT-TW	25.25
ULT-230	24.07
ULT-165	23.43
ULT-MX	20.00
ULT-064	7.25

Starting Point	Formula
654 C	
ULT-165	43.04
ULT-230	42.24
ULT-SB	14.72

Starting Point	Formula
655 C	
ULT-230	41.12
ULT-127	32.28
ULT-SB	26.60

Starting Point	Formula
656 C	
ULT-TW	98.77
ULT-230	0.63
ULT-127	0.60

Starting Point	Formula
657 C	
ULT-TW	97.98
ULT-230	1.14
ULT-127	0.88

Starting Point	Formula
658 C	
ULT-TW	96.23
ULT-230	2.23
ULT-127	1.54

Starting Point	Formula
659 C	
ULT-TW	90.76
ULT-230	6.05
ULT-127	3.19

Starting Point	Formula
660 C	
ULT-TW	56.14
ULT-MX	20.00
ULT-230	17.35
ULT-127	6.51

Starting Point	Formula
661 C	
ULT-230	70.26
ULT-127	19.19
ULT-MX	10.55

Starting Point	Formula
662 C	
ULT-230	61.89
ULT-127	33.91
ULT-SB	4.20

Starting Point	Formula
663 C	
ULT-TW	99.30
ULT-127	0.70

Fascure ULT

Starting Point	Formula
664 C	
ULT-TW 98.94	
ULT-127 0.87	
ULT-230 0.19	

Starting Point	Formula
665 C	
ULT-TW 97.88	
ULT-127 1.51	
ULT-SB 0.40	
ULT-230 0.21	

Starting Point	Formula
666 C	
ULT-TW 93.31	
ULT-127 3.44	
ULT-SB 3.25	

Starting Point	Formula
667 C	
ULT-TW 70.74	
ULT-MX 12.25	
ULT-127 8.79	
ULT-SB 8.22	

Starting Point	Formula
668 C	
ULT-MX 39.99	
ULT-TW 34.92	
ULT-127 13.38	
ULT-SB 11.71	

Starting Point	Formula
669 C	
ULT-TW 36.75	
ULT-127 33.44	
ULT-SB 15.00	
ULT-164 14.81	

Starting Point	Formula
670 C	
ULT-TW 98.95	
ULT-164 0.55	
ULT-127 0.50	

Starting Point	Formula
671 C	
ULT-TW 97.95	
ULT-164 1.34	
ULT-127 0.71	

Starting Point	Formula
672 C	
ULT-TW 96.15	
ULT-164 2.90	
ULT-127 0.95	

Starting Point	Formula
673 C	
ULT-TW 85.55	
ULT-MX 7.49	
ULT-164 5.82	
ULT-127 1.14	

Starting Point	Formula
674 C	
ULT-MX 40.00	
ULT-TW 45.27	
ULT-164 12.44	
ULT-127 2.29	

Starting Point	Formula
675 C	
ULT-MX 40.00	
ULT-164 29.93	
ULT-TW 26.32	
ULT-127 3.75	

Starting Point	Formula
676 C	
ULT-164 52.64	
ULT-MX 39.47	
ULT-127 7.89	

Starting Point	Formula
677 C	
ULT-TW 97.60	
ULT-165 2.12	
ULT-230 0.28	

Starting Point	Formula
678 C	
ULT-TW 96.97	
ULT-165 2.18	
ULT-164 0.46	
ULT-230 0.39	

Starting Point	Formula
679 C	
ULT-TW 96.38	
ULT-165 1.60	
ULT-164 1.48	
ULT-230 0.54	

Fascure ULT

Starting Point	Formula
680 C	
ULT-TW 53.19	
ULT-MX 40.00	
ULT-164 5.06	
ULT-230 1.12	
ULT-064 0.63	

Starting Point	Formula
681 C	
ULT-TW 53.65	
ULT-MX 24.49	
ULT-165 16.68	
ULT-SB 5.18	

Starting Point	Formula
682 C	
ULT-165 48.06	
ULT-MX 34.02	
ULT-064 11.98	
ULT-325 5.94	

Starting Point	Formula
683 C	
ULT-165 58.81	
ULT-SB 22.84	
ULT-121 18.35	

Starting Point	Formula
684 C	
ULT-TW 77.39	
ULT-MX 20.00	
ULT-165 2.16	
ULT-SB 0.45	

Starting Point	Formula
685 C	
ULT-TW 94.96	
ULT-165 3.69	
ULT-SB 1.08	
ULT-121 0.27	

Starting Point	Formula
686 C	
ULT-TW 73.26	
ULT-MX 20.00	
ULT-165 5.19	
ULT-SB 1.55	

Starting Point	Formula
687 C	
ULT-TW 63.08	
ULT-MX 20.00	
ULT-165 11.92	
ULT-SB 3.65	
ULT-121 1.35	

Starting Point	Formula
688 C	
ULT-TW 50.84	
ULT-165 22.16	
ULT-MX 20.00	
ULT-SB 5.43	
ULT-114 1.57	

Starting Point	Formula
689 C	
ULT-165 44.42	
ULT-TW 22.32	
ULT-MX 20.00	
ULT-SB 9.34	
ULT-114 3.92	

Starting Point	Formula
690 C	
ULT-165 33.45	
ULT-SB 23.65	
ULT-MX 19.99	
ULT-121 17.07	
ULT-TW 5.84	

Starting Point	Formula
691 C	
ULT-TW 98.19	
ULT-165 1.81	

Starting Point	Formula
692 C	
ULT-TW 72.57	
ULT-MX 23.67	
ULT-165 1.76	
ULT-121 1.59	
ULT-230 0.41	

Starting Point	Formula
693 C	
ULT-TW 53.22	
ULT-MX 39.99	
ULT-121 3.62	
ULT-165 2.37	
ULT-230 0.8	

Starting Point	Formula
694 C	
ULT-TW 85.42	
ULT-121 6.63	
ULT-165 5.73	
ULT-325 2.22	

Starting Point	Formula
695 C	
ULT-TW 48.91	
ULT-MX 26.93	
ULT-121 14.43	
ULT-165 7.10	
ULT-230 2.63	

Fascure ULT

Starting Point	Formula
696 C	
ULT-MX	32.00
ULT-165	30.22
ULT-066	27.33
ULT-SB	10.45

Starting Point	Formula
697 C	
ULT-121	38.56
ULT-MX	30.41
ULT-165	20.90
ULT-325	10.13

Starting Point	Formula
698 C	
ULT-TW	98.00
ULT-165	1.58
ULT-121	0.42

Starting Point	Formula
699 C	
ULT-TW	96.26
ULT-165	2.81
ULT-114	0.93

Starting Point	Formula
700 C	
ULT-TW	93.54
ULT-165	3.49
ULT-121	2.77
ULT-325	0.20

Starting Point	Formula
701 C	
ULT-TW	86.27
ULT-165	8.96
ULT-114	4.09
ULT-SB	0.68

Starting Point	Formula
702 C	
ULT-TW	69.86
ULT-165	19.66
ULT-114	9.04
ULT-SB	1.44

Starting Point	Formula
703 C	
ULT-MX	36.37
ULT-121	34.77
ULT-165	25.90
ULT-325	2.96

Starting Point	Formula
704 C	
ULT-121	56.89
ULT-165	21.61
ULT-MX	18.26
ULT-230	3.24

Starting Point	Formula
705 C	
ULT-TW	79.70
ULT-MX	19.32
ULT-165	0.98

Starting Point	Formula
706 C	
ULT-TW	96.82
ULT-165	2.08
ULT-121	1.10

Starting Point	Formula
707 C	
ULT-TW	93.45
ULT-165	3.49
ULT-121	3.06

Starting Point	Formula
708 C	
ULT-TW	48.06
ULT-MX	40.01
ULT-165	6.06
ULT-121	5.87

Starting Point	Formula
709 C	
ULT-TW	41.61
ULT-MX	39.99
ULT-121	10.34
ULT-164	8.06

Starting Point	Formula
710 C	
ULT-MX	40.00
ULT-165	27.19
ULT-121	18.33
ULT-066	14.48

Starting Point	Formula
711 C	
ULT-MX	56.82
ULT-121	34.09
ULT-164	7.95
ULT-230	1.14

Fascure ULT

Starting Point	Formula
712 C	
ULT-TW 53.48	
ULT-MX 40.01	
ULT-066 3.33	
ULT-114 3.18	

Starting Point	Formula
713 C	
ULT-TW 49.87	
ULT-MX 40.00	
ULT-066 5.64	
ULT-114 4.49	

Starting Point	Formula
714 C	
ULT-TW 40.19	
ULT-MX 40.01	
ULT-066 12.12	
ULT-114 7.36	
ULT-SB 0.32	

Starting Point	Formula
715 C	
ULT-066 44.62	
ULT-MX 40.00	
ULT-114 14.07	
ULT-SB 1.31	

Starting Point	Formula
716 C	
ULT-066 75.68	
ULT-114 22.56	
ULT-SB 1.76	

Starting Point	Formula
717 C	
ULT-064 56.10	
ULT-114 41.43	
ULT-SB 2.47	

Starting Point	Formula
718 C	
ULT-114 53.12	
ULT-064 42.72	
ULT-SB 4.16	

Starting Point	Formula
719 C	
ULT-TW 95.58	
ULT-114 3.74	
ULT-325 0.68	

Starting Point	Formula
720 C	
ULT-TW 92.74	
ULT-114 6.13	
ULT-325 1.13	

Starting Point	Formula
721 C	
ULT-TW 78.78	
ULT-066 12.29	
ULT-114 6.56	
ULT-SB 2.37	

Starting Point	Formula
722 C	
ULT-TW 49.06	
ULT-066 34.05	
ULT-114 12.34	
ULT-SB 4.55	

Starting Point	Formula
723 C	
ULT-066 60.31	
ULT-114 20.53	
ULT-TW 11.52	
ULT-SB 7.64	

Starting Point	Formula
724 C	
ULT-066 50.91	
ULT-114 36.11	
ULT-SB 12.98	

Starting Point	Formula
725 C	
ULT-114 42.92	
ULT-064 32.74	
ULT-SB 24.34	

Starting Point	Formula
726 C	
ULT-TW 94.91	
ULT-114 3.86	
ULT-230 0.74	
ULT-066 0.49	

Starting Point	Formula
727 C	
ULT-TW 89.91	
ULT-114 6.37	
ULT-066 2.58	
ULT-230 1.14	

Fascure ULT

Starting Point	Formula
728 C	
ULT-TW 81.62	
ULT-114 10.25	
ULT-066 6.31	
ULT-230 1.82	

Starting Point	Formula
729 C	
ULT-TW 63.09	
ULT-114 17.57	
ULT-066 16.31	
ULT-230 3.03	

Starting Point	Formula
730 C	
ULT-066 38.24	
ULT-114 34.49	
ULT-TW 21.62	
ULT-230 5.65	

Starting Point	Formula
731 C	
ULT-114 75.70	
ULT-325 12.84	
ULT-SB 11.46	

Starting Point	Formula
732 C	
ULT-114 63.88	
ULT-SB 19.87	
ULT-325 16.25	

Starting Point	Formula
7401 C	
ULT-TW 95.42	
ULT-064 3.91	
ULT-121 0.67	

Starting Point	Formula
7402 C	
ULT-TW 89.00	
ULT-064 10.24	
ULT-164 0.49	
ULT-325 0.27	

Starting Point	Formula
7403 C	
ULT-TW 77.71	
ULT-064 20.76	
ULT-164 0.95	
ULT-325 0.58	

Starting Point	Formula
7404 C	
ULT-064 67.73	
ULT-TW 31.61	
ULT-164 0.34	
ULT-325 0.32	

Starting Point	Formula
7405 C	
ULT-064 97.63	
ULT-165 1.70	
ULT-325 0.67	

Starting Point	Formula
7406 C	
ULT-064 95.68	
ULT-114 3.07	
ULT-SB 1.25	

Starting Point	Formula
7407 C	
ULT-066 68.17	
ULT-TW 25.22	
ULT-121 4.69	
ULT-230 1.92	

Starting Point	Formula
7408 C	
ULT-064 82.00	
ULT-TW 13.53	
ULT-121 4.08	
ULT-325 0.39	

Starting Point	Formula
7409 C	
ULT-064 91.15	
ULT-TW 5.92	
ULT-164 2.62	
ULT-325 0.31	

Starting Point	Formula
7410 C	
ULT-TW 73.18	
ULT-066 13.55	
ULT-114 12.84	
ULT-325 0.43	

Starting Point	Formula
7411 C	
ULT-TW 48.31	
ULT-064 46.50	
ULT-164 4.29	
ULT-325 0.90	

Fascure ULT

Starting Point	Formula
7412 C	
ULT-066 55.84	
ULT-114 26.44	
ULT-TW 15.57	
ULT-230 2.15	

Starting Point	Formula
7413 C	
ULT-064 89.87	
ULT-164 8.82	
ULT-325 1.31	

Starting Point	Formula
7414 C	
ULT-064 55.41	
ULT-114 36.77	
ULT-SB 7.82	

Starting Point	Formula
7415 C	
ULT-TW 88.96	
ULT-064 8.16	
ULT-164 2.55	
ULT-230 0.33	

Starting Point	Formula
7416 C	
ULT-064 49.59	
ULT-TW 36.39	
ULT-164 13.76	
ULT-325 0.26	

Starting Point	Formula
7417 C	
ULT-064 61.47	
ULT-TW 20.20	
ULT-164 18.11	
ULT-325 0.22	

Starting Point	Formula
7418 C	
ULT-TW 57.73	
ULT-114 24.26	
ULT-164 14.67	
ULT-SB 3.34	

Starting Point	Formula
7419 C	
ULT-TW 42.52	
ULT-165 30.35	
ULT-114 24.72	
ULT-230 2.41	

Starting Point	Formula
7420 C	
ULT-121 46.53	
ULT-165 39.94	
ULT-TW 10.14	
ULT-230 3.39	

Starting Point	Formula
7421 C	
ULT-121 47.76	
ULT-SB 26.80	
ULT-165 25.44	

Starting Point	Formula
7422 C	
ULT-TW 97.43	
ULT-165 1.45	
ULT-121 1.12	

Starting Point	Formula
7423 C	
ULT-TW 71.66	
ULT-165 18.03	
ULT-121 10.31	

Starting Point	Formula
7424 C	
ULT-165 44.63	
ULT-TW 42.13	
ULT-121 13.24	

Starting Point	Formula
7425 C	
ULT-165 47.25	
ULT-TW 28.45	
ULT-121 23.05	
ULT-325 1.25	

Starting Point	Formula
7426 C	
ULT-165 42.76	
ULT-121 38.30	
ULT-TW 17.33	
ULT-230 1.61	

Starting Point	Formula
7427 C	
ULT-121 57.61	
ULT-165 22.37	
ULT-TW 12.49	
ULT-SB 7.53	

Fascure ULT

Starting Point	Formula
7428 C	
ULT-165 44.98	
ULT-066 34.60	
ULT-SB 20.42	

Starting Point	Formula
7429 C	
ULT-TW 98.46	
ULT-164 1.10	
ULT-127 0.44	

Starting Point	Formula
7430 C	
ULT-TW 96.36	
ULT-164 2.89	
ULT-325 0.75	

Starting Point	Formula
7431 C	
ULT-TW 90.59	
ULT-164 6.34	
ULT-064 2.12	
ULT-230 0.95	

Starting Point	Formula
7432 C	
ULT-TW 60.34	
ULT-165 28.19	
ULT-064 9.13	
ULT-325 2.34	

Starting Point	Formula
7433 C	
ULT-165 47.40	
ULT-TW 27.93	
ULT-066 21.91	
ULT-325 2.76	

Starting Point	Formula
7434 C	
ULT-165 53.45	
ULT-066 34.87	
ULT-TW 8.85	
ULT-230 2.83	

Starting Point	Formula
7435 C	
ULT-165 68.31	
ULT-064 25.41	
ULT-325 6.28	

Starting Point	Formula
7436 C	
ULT-TW 98.66	
ULT-165 0.67	
ULT-127 0.67	

Starting Point	Formula
7437 C	
ULT-TW 94.30	
ULT-165 3.85	
ULT-230 1.03	
ULT-164 0.82	

Starting Point	Formula
7438 C	
ULT-TW 92.68	
ULT-165 5.06	
ULT-127 2.26	

Starting Point	Formula
7439 C	
ULT-TW 89.75	
ULT-165 4.43	
ULT-164 3.75	
ULT-230 2.07	

Starting Point	Formula
7440 C	
ULT-TW 90.21	
ULT-127 3.87	
ULT-SB 3.13	
ULT-164 2.79	

Starting Point	Formula
7441 C	
ULT-TW 87.04	
ULT-127 12.96	

Starting Point	Formula
7442 C	
ULT-TW 78.52	
ULT-127 21.48	

Starting Point	Formula
7443 C	
ULT-TW 98.88	
ULT-127 0.74	
ULT-230 0.38	

Fascure ULT

Starting Point	Formula
7444 C	
ULT-TW 97.54	
ULT-127 1.65	
ULT-230 0.81	

Starting Point	Formula
7445 C	
ULT-TW 94.57	
ULT-127 2.62	
ULT-230 1.75	
ULT-SB 1.06	

Starting Point	Formula
7446 C	
ULT-TW 92.52	
ULT-127 5.19	
ULT-230 2.29	

Starting Point	Formula
7447 C	
ULT-TW 70.27	
ULT-127 17.62	
ULT-SB 12.11	

Starting Point	Formula
7448 C	
ULT-TW 50.78	
ULT-SB 23.40	
ULT-127 15.40	
ULT-121 10.42	

Starting Point	Formula
7449 C	
ULT-121 60.04	
ULT-230 22.68	
ULT-165 17.28	

Starting Point	Formula
7450 C	
ULT-TW 98.23	
ULT-127 0.97	
ULT-230 0.80	

Starting Point	Formula
7451 C	
ULT-TW 94.46	
ULT-230 3.31	
ULT-127 2.23	

Starting Point	Formula
7452 C	
ULT-TW 91.14	
ULT-127 4.63	
ULT-230 4.23	

Starting Point	Formula
7453 C	
ULT-TW 93.02	
ULT-230 4.45	
ULT-127 2.53	

Starting Point	Formula
7454 C	
ULT-TW 86.71	
ULT-230 8.61	
ULT-164 3.58	
ULT-SB 1.10	

Starting Point	Formula
7455 C	
ULT-TW 72.29	
ULT-230 17.13	
ULT-127 10.58	

Starting Point	Formula
7456 C	
ULT-TW 88.20	
ULT-127 5.67	
ULT-230 4.93	
ULT-SB 1.20	

Starting Point	Formula
7457 C	
ULT-TW 98.50	
ULT-230 1.30	
ULT-127 0.20	

Starting Point	Formula
7458 C	
ULT-TW 93.23	
ULT-230 4.92	
ULT-SB 1.17	
ULT-127 0.68	

Starting Point	Formula
7459 C	
ULT-TW 84.26	
ULT-230 11.82	
ULT-SB 3.12	
ULT-127 0.80	

Fascure ULT

Starting Point	Formula
7460 C	
ULT-TW 62.66	
ULT-230 37.34	

Starting Point	Formula
7461 C	
ULT-TW 71.02	
ULT-230 26.23	
ULT-127 1.76	
ULT-SB 0.99	

Starting Point	Formula
7462 C	
ULT-TW 46.72	
ULT-230 40.96	
ULT-SB 6.43	
ULT-127 5.89	

Starting Point	Formula
7463 C	
ULT-230 31.11	
ULT-165 29.71	
ULT-TW 20.21	
ULT-SB 18.97	

Starting Point	Formula
7464 C	
ULT-TW 97.11	
ULT-230 2.08	
ULT-064 0.81	

Starting Point	Formula
7465 C	
ULT-TW 87.93	
ULT-230 5.43	
ULT-064 3.62	
ULT-325 3.02	

Starting Point	Formula
7466 C	
ULT-TW 74.54	
ULT-230 12.79	
ULT-325 12.67	

Starting Point	Formula
7467 C	
ULT-TW 66.46	
ULT-230 16.99	
ULT-325 16.55	

Starting Point	Formula
7468 C	
ULT-TW 61.94	
ULT-230 31.10	
ULT-SB 6.19	
ULT-127 0.77	

Starting Point	Formula
7469 C	
ULT-230 57.14	
ULT-TW 33.98	
ULT-121 8.88	

Starting Point	Formula
7470 C	
ULT-230 40.95	
ULT-066 26.61	
ULT-TW 21.65	
ULT-165 10.79	

Starting Point	Formula
7471 C	
ULT-TW 96.33	
ULT-325 2.05	
ULT-230 1.62	

Starting Point	Formula
7472 C	
ULT-TW 86.62	
ULT-230 6.89	
ULT-066 6.08	
ULT-114 0.41	

Starting Point	Formula
7473 C	
ULT-TW 70.08	
ULT-066 17.24	
ULT-230 11.95	
ULT-SB 0.73	

Starting Point	Formula
7474 C	
ULT-TW 61.97	
ULT-230 20.00	
ULT-325 11.69	
ULT-SB 6.34	

Starting Point	Formula
7475 C	
ULT-TW 73.62	
ULT-230 14.46	
ULT-114 9.33	
ULT-066 2.59	

Fascure ULT

Starting Point	Formula
7476 C	
ULT-TW 36.41	
ULT-230 29.46	
ULT-SB 21.90	
ULT-066 12.23	

Starting Point	Formula
7477 C	
ULT-TW 47.57	
ULT-SB 26.19	
ULT-230 23.58	
ULT-164 2.66	

Starting Point	Formula
7478 C	
ULT-TW 93.99	
ULT-325 4.21	
ULT-064 1.80	

Starting Point	Formula
7479 C	
ULT-TW 73.64	
ULT-325 14.73	
ULT-064 11.63	

Starting Point	Formula
7480 C	
ULT-TW 55.92	
ULT-325 29.26	
ULT-064 14.82	

Starting Point	Formula
7481 C	
ULT-325 52.48	
ULT-064 47.52	

Starting Point	Formula
7482 C	
ULT-325 35.48	
ULT-TW 34.18	
ULT-064 26.15	
ULT-230 4.19	

Starting Point	Formula
7483 C	
ULT-325 37.60	
ULT-064 29.49	
ULT-SB 29.12	
ULT-TW 3.79	

Starting Point	Formula
7484 C	
ULT-325 58.28	
ULT-114 26.68	
ULT-230 15.04	

Starting Point	Formula
7485 C	
ULT-TW 96.81	
ULT-064 2.37	
ULT-230 0.58	
ULT-165 0.24	

Starting Point	Formula
7486 C	
ULT-TW 89.90	
ULT-064 8.12	
ULT-325 1.45	
ULT-230 0.53	

Starting Point	Formula
7487 C	
ULT-TW 58.36	
ULT-064 33.17	
ULT-325 8.47	

Starting Point	Formula
7488 C	
ULT-064 57.84	
ULT-TW 28.42	
ULT-325 13.74	

Starting Point	Formula
7489 C	
ULT-064 52.95	
ULT-TW 37.75	
ULT-230 8.08	
ULT-165 1.22	

Starting Point	Formula
7490 C	
ULT-066 89.55	
ULT-230 10.45	

Starting Point	Formula
7491 C	
ULT-066 76.64	
ULT-325 13.29	
ULT-SB 10.07	

Fascure ULT

Starting Point	Formula
7492 C	
ULT-TW 75.65	
ULT-066 22.60	
ULT-230 1.75	

Starting Point	Formula
7493 C	
ULT-TW 79.32	
ULT-066 17.85	
ULT-230 2.06	
ULT-165 0.77	

Starting Point	Formula
7494 C	
ULT-TW 84.28	
ULT-064 7.53	
ULT-SB 5.39	
ULT-325 2.80	

Starting Point	Formula
7495 C	
ULT-066 92.55	
ULT-230 7.23	
ULT-164 0.22	

Starting Point	Formula
7496 C	
ULT-064 74.09	
ULT-SB 14.39	
ULT-325 11.52	

Starting Point	Formula
7497 C	
ULT-TW 39.07	
ULT-066 37.10	
ULT-SB 22.82	
ULT-230 1.01	

Starting Point	Formula
7498 C	
ULT-064 60.18	
ULT-SB 33.76	
ULT-230 6.06	

Starting Point	Formula
7499 C	
ULT-TW 97.05	
ULT-064 2.79	
ULT-164 0.16	

Starting Point	Formula
7500 C	
ULT-TW 95.64	
ULT-064 2.86	
ULT-SB 1.08	
ULT-121 0.42	

Starting Point	Formula
7501 C	
ULT-TW 91.85	
ULT-066 6.22	
ULT-SB 1.68	
ULT-165 0.25	

Starting Point	Formula
7502 C	
ULT-TW 85.18	
ULT-066 11.47	
ULT-SB 2.76	
ULT-121 0.59	

Starting Point	Formula
7503 C	
ULT-TW 59.29	
ULT-066 34.99	
ULT-230 3.19	
ULT-164 2.53	

Starting Point	Formula
7504 C	
ULT-066 55.45	
ULT-TW 26.55	
ULT-165 12.62	
ULT-230 5.38	

Starting Point	Formula
7505 C	
ULT-TW 33.72	
ULT-064 27.80	
ULT-SB 22.31	
ULT-114 16.17	

Starting Point	Formula
7506 C	
ULT-TW 96.06	
ULT-064 3.40	
ULT-164 0.54	

Starting Point	Formula
7507 C	
ULT-TW 95.59	
ULT-064 2.61	
ULT-114 1.80	

Fascure ULT

Starting Point	Formula
7508 C	
ULT-TW 86.61	
ULT-064 8.45	
ULT-114 3.05	
ULT-SB 1.89	

Starting Point	Formula
7509 C	
ULT-TW 60.26	
ULT-066 33.95	
ULT-121 4.62	
ULT-230 1.17	

Starting Point	Formula
7510 C	
ULT-066 61.34	
ULT-TW 29.60	
ULT-121 7.20	
ULT-230 1.86	

Starting Point	Formula
7511 C	
ULT-064 63.17	
ULT-114 17.29	
ULT-TW 11.15	
ULT-SB 8.39	

Starting Point	Formula
7512 C	
ULT-064 60.84	
ULT-114 26.76	
ULT-SB 12.40	

Starting Point	Formula
7513 C	
ULT-TW 95.17	
ULT-114 4.04	
ULT-127 0.48	
ULT-230 0.31	

Starting Point	Formula
7514 C	
ULT-TW 89.94	
ULT-114 6.30	
ULT-SB 2.94	
ULT-064 0.82	

Starting Point	Formula
7515 C	
ULT-TW 78.25	
ULT-114 11.14	
ULT-066 5.59	
ULT-SB 5.02	

Starting Point	Formula
7516 C	
ULT-114 35.51	
ULT-TW 27.30	
ULT-064 24.45	
ULT-SB 12.74	

Starting Point	Formula
7517 C	
ULT-114 40.34	
ULT-066 38.71	
ULT-SB 20.95	

Starting Point	Formula
7518 C	
ULT-TW 41.25	
ULT-SB 30.87	
ULT-121 18.30	
ULT-064 9.58	

Starting Point	Formula
7519 C	
ULT-066 39.21	
ULT-SB 36.76	
ULT-TW 19.27	
ULT-164 4.76	

Starting Point	Formula
7520 C	
ULT-TW 96.03	
ULT-114 3.45	
ULT-127 0.52	

Starting Point	Formula
7521 C	
ULT-TW 88.64	
ULT-121 5.91	
ULT-064 3.85	
ULT-230 1.60	

Starting Point	Formula
7522 C	
ULT-TW 62.59	
ULT-121 20.58	
ULT-064 13.90	
ULT-230 2.93	

Starting Point	Formula
7523 C	
ULT-TW 59.49	
ULT-121 30.48	
ULT-064 6.23	
ULT-230 3.80	

Fascure ULT

Starting Point	Formula
7524 C	
ULT-TW 48.51	
ULT-121 40.10	
ULT-325 6.54	
ULT-064 4.85	

Starting Point	Formula
7525 C	
ULT-064 38.06	
ULT-TW 38.02	
ULT-165 13.31	
ULT-SB 10.61	

Starting Point	Formula
7526 C	
ULT-114 65.25	
ULT-SB 17.29	
ULT-064 10.53	
ULT-TW 6.93	

Starting Point	Formula
7527 C	
ULT-TW 96.67	
ULT-SB 2.05	
ULT-066 1.28	

Starting Point	Formula
7528 C	
ULT-TW 96.47	
ULT-SB 2.89	
ULT-121 0.64	

Starting Point	Formula
7529 C	
ULT-TW 93.20	
ULT-SB 5.35	
ULT-114 1.45	

Starting Point	Formula
7530 C	
ULT-TW 83.10	
ULT-SB 10.57	
ULT-066 3.57	
ULT-114 2.76	

Starting Point	Formula
7531 C	
ULT-TW 61.94	
ULT-SB 19.67	
ULT-066 12.73	
ULT-114 5.66	

Starting Point	Formula
7532 C	
ULT-TW 35.65	
ULT-SB 31.45	
ULT-066 24.61	
ULT-114 8.29	

Starting Point	Formula
7533 C	
ULT-SB 50.96	
ULT-066 29.74	
ULT-TW 12.44	
ULT-114 6.86	

Starting Point	Formula
7534 C	
ULT-TW 97.80	
ULT-SB 2.00	
ULT-064 0.20	

Starting Point	Formula
7535 C	
ULT-TW 92.33	
ULT-SB 4.62	
ULT-066 3.05	

Starting Point	Formula
7536 C	
ULT-TW 84.70	
ULT-SB 7.75	
ULT-066 7.55	

Starting Point	Formula
7537 C	
ULT-TW 93.75	
ULT-SB 5.44	
ULT-325 0.53	
ULT-064 0.28	

Starting Point	Formula
7538 C	
ULT-TW 92.08	
ULT-SB 6.86	
ULT-325 0.93	
ULT-127 0.13	

Starting Point	Formula
7539 C	
ULT-TW 88.64	
ULT-SB 10.14	
ULT-325 0.99	
ULT-127 0.23	

Fascure ULT

Starting Point	Formula
7540 C	
ULT-TW	68.99
ULT-SB	24.68
ULT-325	3.50
ULT-127	2.83

Starting Point	Formula
7541 C	
ULT-TW	98.79
ULT-325	0.64
ULT-127	0.57

Starting Point	Formula
7542 C	
ULT-TW	95.48
ULT-SB	2.42
ULT-230	1.60
ULT-127	0.50

Starting Point	Formula
7543 C	
ULT-TW	93.28
ULT-SB	4.48
ULT-230	1.47
ULT-127	0.77

Starting Point	Formula
7544 C	
ULT-TW	85.26
ULT-SB	8.56
ULT-230	4.11
ULT-164	2.07

Starting Point	Formula
7545 C	
ULT-TW	62.97
ULT-SB	20.09
ULT-230	11.60
ULT-164	5.34

Starting Point	Formula
7546 C	
ULT-TW	45.43
ULT-SB	34.72
ULT-230	13.21
ULT-127	6.64

Starting Point	Formula
7547 C	
ULT-SB	74.20
ULT-127	19.11
ULT-TW	6.69