

UviPak UCD

Fujifilm Sericol Formulation Guide

Version 2.0

- SMS Base Colors



SERICOL
More than ink...Solutions.

FUJIFILM

February 20, 2007

UviPakUCD

Fujifilm Sericol Formulation Guide

This booklet furnishes the necessary formulas to simulate all the colors in the PANTONE® Color Guide. Predictive simulations were performed via a spectrophotometer simulating Cool White Florescent (CWF) lighting, ink deposit of 380 PW on white substrate.

All formulas are presented by weight. However, due to variations in ink film thickness, screen mesh, and other variables, some formulas may need adjustments.

Each IMS Base Color has been carefully selected for its cleanliness of tone, resistance to fading, and suitability for intermixing. In addition, each ink has been formulated to be free of lead and other heavy metals

Although every care is taken in producing these formulations, variations in substrates and printing conditions may affect the color achieved. Fujifilm Sericol USA Inc. assumes no responsibility for actual color achieved versus the Pantone standard print. For this reason, all formulations must be proofed prior to a production run to ensure color accuracy.

All formulations are percentages by weight using the following UviPak UCD Series IMS colors:

DESCRIPTION	
UCD-062 IMS Yellow	UCD-230 IMS Blue
UCD-064 IMS Yellow GS	UCD-233 IMS Blue RS
UCD-066 IMS Yellow RS	UCD-235 IMS Blue RS
UCD-114 IMS Orange	UCD-311 Opaque White
UCD-121 IMS Red YS	UCD-325 IMS Green
UCD-127 IMS Violet	UCD-SB Shading Black
UCD-164 IMS Red BS	UCD-MX Mixing Clear
UCD-165 IMS Magenta	

Fujifilm Sericol USA, Inc's color mixing ink formulations for screen process printing produce only simulations of PANTONE Colors in this color reproduction method due to differences in ink film, opacity and pigment selection. The selection used in blending inks may cause metamerism. Pantone, Inc. assumes no responsibility for formula accuracy.

*PANTONE® is the property of Pantone Inc.

UviPak UCD

Starting Point Yellow C UCD-062 68.25 UCD-064 31.75	Formula	Starting Point Yellow 012 C UCD-064 76.05 UCD-062 23.95	Formula	Starting Point Orange 021 C UCD-114 58.10 UCD-064 41.90	Formula	Starting Point Warm Red C UCD-MX 42.45 UCD-TW 22.10 UCD-121 19.95 UCD-066 15.50	Formula
Starting Point Red 032 C UCD-167 49.65 UCD-114 34.35 UCD-TW 16.00	Formula	Starting Point Rubine Red C UCD-167 70.60 UCD-165 29.40	Formula	Starting Point Rhodamine Red C UCD-165 54.20 UCD-TW 45.80	Formula	Starting Point Purple C UCD-MX 72.50 UCD-165 23.55 UCD-127 3.95	Formula
Starting Point Violet C UCD-MX 54.05 UCD-127 27.05 UCD-TW 16.20 UCD-230 2.70	Formula	Starting Point Blue 072 C UCD-TW 60.10 UCD-235 22.00 UCD-127 17.90	Formula	Starting Point Reflex Blue C UCD-TW 43.80 UCD-235 37.70 UCD-127 18.50	Formula	Starting Point Process Blue C UCD-TW 78.35 UCD-235 21.65	Formula
Starting Point Green C UCD-325 74.75 UCD-TW 25.25	Formula	Starting Point Black C UCD-SB 86.55 UCD-114 13.45	Formula	Starting Point 100 C UCD-TW 80.34 UCD-062 19.66	Formula	Starting Point 101 C UCD-TW 53.75 UCD-062 46.25	Formula

UviPak UCD

Starting Point	Formula
102 C	
UCD-062 100.00	

Starting Point	Formula
103 C	
UCD-062 48.65	
UCD-064 48.05	
UCD-SB 3.30	

Starting Point	Formula
104 C	
UCD-062 63.75	
UCD-064 30.00	
UCD-SB 6.25	

Starting Point	Formula
105 C	
UCD-062 59.25	
UCD-064 17.55	
UCD-SB 15.05	
UCD-TW 8.15	

Starting Point	Formula
106 C	
UCD-TW 54.10	
UCD-062 45.90	

Starting Point	Formula
107 C	
UCD-062 53.25	
UCD-TW 29.05	
UCD-064 17.70	

Starting Point	Formula
108 C	
UCD-062 99.05	
UCD-114 0.95	

Starting Point	Formula
109 C	
UCD-062 98.35	
UCD-114 1.65	

Starting Point	Formula
110 C	
UCD-062 75.25	
UCD-066 21.95	
UCD-325 1.90	
UCD-164 0.90	

Starting Point	Formula
111 C	
UCD-062 68.40	
UCD-066 23.70	
UCD-325 5.65	
UCD-164 2.25	

Starting Point	Formula
112 C	
UCD-062 78.80	
UCD-066 12.05	
UCD-121 6.10	
UCD-230 3.05	

Starting Point	Formula
113 C	
UCD-TW 53.00	
UCD-062 25.60	
UCD-064 21.40	

Starting Point	Formula
114 C	
UCD-TW 47.30	
UCD-064 32.20	
UCD-062 20.50	

Starting Point	Formula
115 C	
UCD-064 54.70	
UCD-TW 45.30	

Starting Point	Formula
116 C	
UCD-062 86.30	
UCD-TW 11.40	
UCD-114 2.30	

Starting Point	Formula
117 C	
UCD-062 75.50	
UCD-066 20.20	
UCD-325 2.70	
UCD-164 1.60	

UviPak UCD

Starting Point	Formula
118 C	
UCD-062 69.45	
UCD-066 22.95	
UCD-325 5.05	
UCD-164 2.55	

Starting Point	Formula
119 C	
UCD-062 75.75	
UCD-SB 13.35	
UCD-TW 8.75	
UCD-114 2.15	

Starting Point	Formula
120 C	
UCD-TW 68.55	
UCD-062 30.35	
UCD-114 1.10	

Starting Point	Formula
121 C	
UCD-TW 62.60	
UCD-062 36.00	
UCD-114 1.40	

Starting Point	Formula
122 C	
UCD-TW 51.40	
UCD-062 46.65	
UCD-114 1.95	

Starting Point	Formula
123 C	
UCD-062 58.40	
UCD-TW 38.95	
UCD-114 2.65	

Starting Point	Formula
124 C	
UCD-062 76.15	
UCD-TW 12.95	
UCD-066 7.30	
UCD-167 3.00	
UCD-325 0.60	

Starting Point	Formula
125 C	
UCD-062 92.00	
UCD-114 4.35	
UCD-127 2.05	
UCD-325 1.60	

Starting Point	Formula
126 C	
UCD-062 83.25	
UCD-114 6.50	
UCD-TW 5.65	
UCD-230 2.45	
UCD-164 2.15	

Starting Point	Formula
1205 C	
UCD-TW 88.90	
UCD-064 10.80	
UCD-114 0.30	

Starting Point	Formula
1215 C	
UCD-TW 77.60	
UCD-064 22.15	
UCD-121 0.25	

Starting Point	Formula
1225 C	
UCD-TW 58.90	
UCD-062 38.35	
UCD-114 2.75	

Starting Point	Formula
1235 C	
UCD-062 61.40	
UCD-TW 33.40	
UCD-114 5.20	

Starting Point	Formula
1245 C	
UCD-062 64.05	
UCD-TW 17.30	
UCD-066 10.90	
UCD-165 5.45	
UCD-325 2.30	

Starting Point	Formula
1255 C	
UCD-062 59.90	
UCD-TW 19.90	
UCD-066 11.90	
UCD-167 6.50	
UCD-230 1.80	

Starting Point	Formula
1265 C	
UCD-062 70.10	
UCD-TW 12.85	
UCD-SB 12.75	
UCD-114 3.55	
UCD-164 0.75	

UviPak UCD

Starting Point	Formula
127 C	
UCD-TW 70.15	
UCD-062 29.30	
UCD-121 0.55	

Starting Point	Formula
128 C	
UCD-TW 52.00	
UCD-062 47.10	
UCD-121 0.90	

Starting Point	Formula
129 C	
UCD-TW 49.95	
UCD-062 49.00	
UCD-121 1.05	

Starting Point	Formula
130 C	
UCD-062 98.25	
UCD-164 1.75	

Starting Point	Formula
131 C	
UCD-064 95.60	
UCD-164 2.70	
UCD-325 1.70	

Starting Point	Formula
132 C	
UCD-064 90.30	
UCD-325 5.40	
UCD-164 4.30	

Starting Point	Formula
133 C	
UCD-062 77.80	
UCD-SB 20.50	
UCD-164 1.70	

Starting Point	Formula
134 C	
UCD-TW 75.20	
UCD-062 22.95	
UCD-114 1.85	

Starting Point	Formula
135 C	
UCD-TW 63.50	
UCD-062 33.25	
UCD-114 3.25	

Starting Point	Formula
136 C	
UCD-TW 50.35	
UCD-062 45.10	
UCD-114 4.55	

Starting Point	Formula
137 C	
UCD-062 67.00	
UCD-TW 23.50	
UCD-114 9.50	

Starting Point	Formula
138 C	
UCD-062 83.30	
UCD-114 11.40	
UCD-121 4.00	
UCD-325 1.30	

Starting Point	Formula
139 C	
UCD-062 81.80	
UCD-114 8.15	
UCD-SB 6.60	
UCD-167 3.45	

Starting Point	Formula
140 C	
UCD-062 77.90	
UCD-114 8.50	
UCD-325 7.10	
UCD-127 6.50	

Starting Point	Formula
1345 C	
UCD-TW 85.45	
UCD-062 12.25	
UCD-114 2.30	

Starting Point	Formula
1355 C	
UCD-TW 78.30	
UCD-062 17.90	
UCD-114 3.80	

UviPak UCD

Starting Point	Formula
1365 C	
UCD-TW 63.80	
UCD-062 30.15	
UCD-114 6.05	

Starting Point	Formula
1375 C	
UCD-062 44.75	
UCD-TW 44.35	
UCD-114 10.90	

Starting Point	Formula
1385 C	
UCD-062 76.40	
UCD-114 11.00	
UCD-TW 6.40	
UCD-167 5.45	
UCD-230 0.75	

Starting Point	Formula
1395 C	
UCD-062 70.95	
UCD-114 11.40	
UCD-TW 7.50	
UCD-121 7.45	
UCD-230 2.70	

Starting Point	Formula
1405 C	
UCD-062 71.90	
UCD-114 11.30	
UCD-325 8.95	
UCD-127 7.85	

Starting Point	Formula
141 C	
UCD-TW 63.15	
UCD-062 36.05	
UCD-164 0.80	

Starting Point	Formula
142 C	
UCD-062 53.20	
UCD-TW 45.65	
UCD-164 1.15	

Starting Point	Formula
143 C	
UCD-062 71.05	
UCD-TW 27.30	
UCD-164 1.65	

Starting Point	Formula
144 C	
UCD-062 96.15	
UCD-164 3.85	

Starting Point	Formula
145 C	
UCD-062 95.00	
UCD-164 4.45	
UCD-235 0.55	

Starting Point	Formula
146 C	
UCD-062 88.60	
UCD-SB 7.05	
UCD-164 4.35	

Starting Point	Formula
147 C	
UCD-062 66.25	
UCD-SB 17.10	
UCD-TW 14.50	
UCD-164 2.15	

Starting Point	Formula
148 C	
UCD-TW 90.30	
UCD-062 7.30	
UCD-114 2.40	

Starting Point	Formula
149 C	
UCD-TW 86.00	
UCD-062 10.15	
UCD-114 3.85	

Starting Point	Formula
150 C	
UCD-TW 66.35	
UCD-062 24.20	
UCD-114 9.45	

Starting Point	Formula
151 C	
UCD-064 49.25	
UCD-114 28.25	
UCD-TW 22.50	

UviPak UCD

Starting Point	Formula
152 C	
UCD-062	68.55
UCD-TW	12.85
UCD-114	12.60
UCD-121	5.05
UCD-325	0.95

Starting Point	Formula
153 C	
UCD-062	65.40
UCD-114	13.95
UCD-TW	9.60
UCD-165	7.90
UCD-325	3.15

Starting Point	Formula
154 C	
UCD-062	64.75
UCD-114	14.50
UCD-TW	8.95
UCD-121	8.90
UCD-230	2.90

Starting Point	Formula
1485 C	
UCD-TW	83.55
UCD-114	8.65
UCD-062	7.80

Starting Point	Formula
1495 C	
UCD-TW	43.00
UCD-062	37.45
UCD-114	19.55

Starting Point	Formula
1505 C	
UCD-062	63.00
UCD-114	37.00

Starting Point	Formula
1525 C	
UCD-062	44.85
UCD-114	36.05
UCD-TW	12.20
UCD-167	5.70
UCD-230	1.20

Starting Point	Formula
1535 C	
UCD-062	45.25
UCD-114	31.75
UCD-TW	11.30
UCD-121	8.05
UCD-230	3.65

Starting Point	Formula
1545 C	
UCD-MX	48.30
UCD-114	27.20
UCD-SB	24.50

Starting Point	Formula
155 C	
UCD-TW	88.95
UCD-062	9.70
UCD-165	1.35

Starting Point	Formula
156 C	
UCD-TW	73.90
UCD-062	22.90
UCD-165	3.20

Starting Point	Formula
157 C	
UCD-062	55.70
UCD-TW	37.15
UCD-165	7.15

Starting Point	Formula
158 C	
UCD-062	83.95
UCD-165	6.60
UCD-TW	6.10
UCD-164	3.35

Starting Point	Formula
159 C	
UCD-062	90.10
UCD-164	8.00
UCD-SB	1.90

Starting Point	Formula
160 C	
UCD-062	85.20
UCD-164	7.90
UCD-SB	6.90

Starting Point	Formula
161 C	
UCD-062	70.75
UCD-SB	22.80
UCD-164	6.45

UviPak UCD

Starting Point	Formula
1555 C	
UCD-TW 95.85	
UCD-114 3.75	
UCD-121 0.40	

Starting Point	Formula
1565 C	
UCD-TW 91.40	
UCD-114 8.15	
UCD-121 0.45	

Starting Point	Formula
1575 C	
UCD-TW 72.50	
UCD-114 27.50	

Starting Point	Formula
1585 C	
UCD-TW 55.00	
UCD-114 36.50	
UCD-062 8.50	

Starting Point	Formula
1595 C	
UCD-062 49.40	
UCD-TW 23.05	
UCD-114 19.50	
UCD-167 7.45	
UCD-230 0.60	

Starting Point	Formula
1605 C	
UCD-066 54.35	
UCD-TW 20.05	
UCD-167 20.05	
UCD-325 5.55	

Starting Point	Formula
1615 C	
UCD-066 54.10	
UCD-121 22.15	
UCD-TW 14.25	
UCD-325 9.50	

Starting Point	Formula
162 C	
UCD-TW 96.10	
UCD-114 3.50	
UCD-167 0.40	

Starting Point	Formula
163 C	
UCD-TW 87.00	
UCD-114 11.85	
UCD-167 1.15	

Starting Point	Formula
164 C	
UCD-TW 66.25	
UCD-114 33.10	
UCD-167 0.65	

Starting Point	Formula
165 C	
UCD-114 54.70	
UCD-TW 45.30	

Starting Point	Formula
166 C	
UCD-062 47.30	
UCD-114 29.55	
UCD-TW 15.70	
UCD-121 6.60	
UCD-325 0.85	

Starting Point	Formula
167 C	
UCD-062 50.95	
UCD-114 29.85	
UCD-167 9.95	
UCD-TW 7.95	
UCD-230 1.30	

Starting Point	Formula
168 C	
UCD-064 36.80	
UCD-114 35.70	
UCD-SB 20.15	
UCD-121 7.35	

Starting Point	Formula
1625 C	
UCD-TW 90.75	
UCD-114 6.65	
UCD-167 2.60	

Starting Point	Formula
1635 C	
UCD-TW 84.00	
UCD-114 12.05	
UCD-167 3.95	

UviPak UCD

Starting Point	Formula
1645 C	
UCD-TW 63.75	
UCD-114 32.10	
UCD-121 4.15	

Starting Point	Formula
1655 C	
UCD-114 59.20	
UCD-TW 37.30	
UCD-167 3.50	

Starting Point	Formula
1665 C	
UCD-114 36.50	
UCD-064 30.75	
UCD-TW 21.10	
UCD-167 10.75	
UCD-325 0.90	

Starting Point	Formula
1675 C	
UCD-062 39.00	
UCD-114 29.70	
UCD-TW 15.90	
UCD-167 13.40	
UCD-230 2.00	

Starting Point	Formula
1685 C	
UCD-062 40.80	
UCD-114 28.25	
UCD-121 14.05	
UCD-TW 13.10	
UCD-230 3.80	

Starting Point	Formula
169 C	
UCD-TW 94.90	
UCD-167 2.70	
UCD-114 2.40	

Starting Point	Formula
170 C	
UCD-TW 83.30	
UCD-114 9.70	
UCD-167 7.00	

Starting Point	Formula
171 C	
UCD-TW 53.60	
UCD-114 35.70	
UCD-167 10.70	

Starting Point	Formula
172 C	
UCD-114 55.70	
UCD-TW 36.60	
UCD-167 7.70	

Starting Point	Formula
173 C	
UCD-TW 46.10	
UCD-114 43.20	
UCD-167 10.10	
UCD-230 0.60	

Starting Point	Formula
174 C	
UCD-114 58.15	
UCD-TW 27.45	
UCD-121 11.90	
UCD-230 2.50	

Starting Point	Formula
175 C	
UCD-TW 25.75	
UCD-066 23.45	
UCD-114 21.65	
UCD-SB 17.20	
UCD-167 11.95	

Starting Point	Formula
176 C	
UCD-TW 93.75	
UCD-167 4.50	
UCD-114 1.75	

Starting Point	Formula
177 C	
UCD-TW 80.75	
UCD-167 12.90	
UCD-114 6.35	

Starting Point	Formula
178 C	
UCD-TW 55.90	
UCD-167 24.55	
UCD-114 19.55	

Starting Point	Formula
179 C	
UCD-114 38.15	
UCD-TW 36.25	
UCD-167 25.40	
UCD-235 0.20	

UviPak UCD

Starting Point	Formula
180 C	
UCD-114 36.85	
UCD-TW 35.20	
UCD-167 26.95	
UCD-235 1.00	

Starting Point	Formula
181 C	
UCD-114 57.05	
UCD-165 28.35	
UCD-TW 10.25	
UCD-230 4.35	

Starting Point	Formula
1765 C	
UCD-TW 91.00	
UCD-167 7.15	
UCD-114 1.85	

Starting Point	Formula
1775 C	
UCD-TW 85.05	
UCD-167 11.70	
UCD-114 3.25	

Starting Point	Formula
1785 C	
UCD-TW 46.55	
UCD-167 37.85	
UCD-114 15.60	

Starting Point	Formula
1788 C	
UCD-167 34.30	
UCD-TW 34.10	
UCD-114 31.60	

Starting Point	Formula
1795 C	
UCD-114 37.40	
UCD-167 34.20	
UCD-TW 27.95	
UCD-235 0.45	

Starting Point	Formula
1805 C	
UCD-114 43.55	
UCD-165 27.55	
UCD-TW 26.10	
UCD-325 2.80	

Starting Point	Formula
1815 C	
UCD-066 51.15	
UCD-165 39.05	
UCD-325 9.80	

Starting Point	Formula
1767 C	
UCD-TW 94.70	
UCD-167 4.45	
UCD-114 0.85	

Starting Point	Formula
1777 C	
UCD-TW 66.45	
UCD-167 27.35	
UCD-114 6.20	

Starting Point	Formula
1787 C	
UCD-167 48.30	
UCD-TW 38.80	
UCD-114 12.90	

Starting Point	Formula
1797 C	
UCD-167 55.15	
UCD-114 31.25	
UCD-TW 12.20	
UCD-325 1.40	

Starting Point	Formula
1807 C	
UCD-167 62.90	
UCD-114 21.25	
UCD-TW 11.05	
UCD-325 4.80	

Starting Point	Formula
1817 C	
UCD-167 42.05	
UCD-114 39.20	
UCD-TW 10.65	
UCD-230 8.10	

Starting Point	Formula
182 C	
UCD-TW 95.85	
UCD-167 3.60	
UCD-114 0.55	

UviPak UCD

Starting Point	Formula
183 C	
UCD-TW 87.20	
UCD-167 10.95	
UCD-114 1.85	

Starting Point	Formula
184 C	
UCD-TW 61.40	
UCD-167 32.70	
UCD-114 5.90	

Starting Point	Formula
185 C	
UCD-167 74.30	
UCD-066 25.70	

Starting Point	Formula
186 C	
UCD-167 66.00	
UCD-114 22.65	
UCD-TW 10.85	
UCD-235 0.50	

Starting Point	Formula
187 C	
UCD-167 70.55	
UCD-066 26.95	
UCD-233 2.50	

Starting Point	Formula
188 C	
UCD-167 70.25	
UCD-114 21.80	
UCD-233 7.95	

Starting Point	Formula
189 C	
UCD-TW 92.70	
UCD-167 6.50	
UCD-114 0.80	

Starting Point	Formula
190 C	
UCD-TW 81.15	
UCD-167 16.75	
UCD-114 2.10	

Starting Point	Formula
191 C	
UCD-TW 49.55	
UCD-167 45.80	
UCD-114 4.65	

Starting Point	Formula
192 C	
UCD-167 67.45	
UCD-064 25.00	
UCD-TW 7.55	

Starting Point	Formula
193 C	
UCD-167 67.90	
UCD-TW 17.65	
UCD-114 13.70	
UCD-235 0.75	

Starting Point	Formula
194 C	
UCD-167 63.20	
UCD-TW 17.75	
UCD-114 15.60	
UCD-233 3.45	

Starting Point	Formula
195 C	
UCD-167 46.55	
UCD-TW 25.15	
UCD-114 21.15	
UCD-233 7.15	

Starting Point	Formula
1895 C	
UCD-TW 96.30	
UCD-167 3.55	
UCD-114 0.15	

Starting Point	Formula
1905 C	
UCD-TW 91.90	
UCD-167 7.50	
UCD-114 0.60	

Starting Point	Formula
1915 C	
UCD-TW 60.20	
UCD-167 37.60	
UCD-114 2.20	

UviPak UCD

Starting Point	Formula
1925 C	
UCD-167 73.75	
UCD-064 13.40	
UCD-TW 12.85	

Starting Point	Formula
1935 C	
UCD-167 76.85	
UCD-064 22.65	
UCD-235 0.50	

Starting Point	Formula
1945 C	
UCD-167 73.85	
UCD-062 24.50	
UCD-235 1.65	

Starting Point	Formula
1955 C	
UCD-167 67.70	
UCD-064 22.90	
UCD-SB 9.40	

Starting Point	Formula
196 C	
UCD-TW 94.85	
UCD-165 2.85	
UCD-062 2.30	

Starting Point	Formula
197 C	
UCD-TW 84.30	
UCD-165 9.15	
UCD-062 6.55	

Starting Point	Formula
198 C	
UCD-TW 68.75	
UCD-121 21.50	
UCD-164 9.75	

Starting Point	Formula
199 C	
UCD-121 54.60	
UCD-TW 28.80	
UCD-164 16.60	

Starting Point	Formula
200 C	
UCD-167 52.60	
UCD-064 29.50	
UCD-164 16.35	
UCD-325 1.55	

Starting Point	Formula
201 C	
UCD-167 47.85	
UCD-064 28.45	
UCD-164 19.20	
UCD-325 4.50	

Starting Point	Formula
202 C	
UCD-167 43.95	
UCD-062 37.65	
UCD-164 14.95	
UCD-230 3.45	

Starting Point	Formula
203 C	
UCD-TW 93.15	
UCD-165 5.25	
UCD-062 1.60	

Starting Point	Formula
204 C	
UCD-TW 84.30	
UCD-165 10.60	
UCD-121 5.10	

Starting Point	Formula
205 C	
UCD-TW 47.30	
UCD-167 32.90	
UCD-165 14.15	
UCD-062 5.65	

Starting Point	Formula
206 C	
UCD-167 61.65	
UCD-121 21.20	
UCD-165 17.15	

Starting Point	Formula
207 C	
UCD-167 79.45	
UCD-164 17.85	
UCD-325 2.70	

UviPak UCD

Starting Point	Formula
208 C	
UCD-167 76.25	
UCD-064 12.20	
UCD-SB 11.55	

Starting Point	Formula
209 C	
UCD-167 64.20	
UCD-SB 19.20	
UCD-064 16.60	

Starting Point	Formula
210 C	
UCD-TW 91.95	
UCD-167 8.05	

Starting Point	Formula
211 C	
UCD-TW 82.40	
UCD-167 17.60	

Starting Point	Formula
212 C	
UCD-TW 62.45	
UCD-167 37.55	

Starting Point	Formula
213 C	
UCD-167 62.40	
UCD-TW 37.60	

Starting Point	Formula
214 C	
UCD-167 77.80	
UCD-TW 21.60	
UCD-325 0.60	

Starting Point	Formula
215 C	
UCD-167 83.45	
UCD-TW 12.05	
UCD-325 3.20	
UCD-114 1.30	

Starting Point	Formula
216 C	
UCD-167 70.80	
UCD-064 18.55	
UCD-325 10.65	

Starting Point	Formula
217 C	
UCD-TW 96.75	
UCD-165 3.25	

Starting Point	Formula
218 C	
UCD-TW 77.75	
UCD-165 16.00	
UCD-167 6.25	

Starting Point	Formula
219 C	
UCD-TW 33.40	
UCD-165 30.15	
UCD-167 26.45	
UCD-MX 10.00	

Starting Point	Formula
220 C	
UCD-165 47.15	
UCD-167 46.40	
UCD-164 3.55	
UCD-SB 2.90	

Starting Point	Formula
221 C	
UCD-165 80.85	
UCD-121 14.25	
UCD-SB 4.90	

Starting Point	Formula
222 C	
UCD-167 79.65	
UCD-SB 20.35	

Starting Point	Formula
223 C	
UCD-TW 79.35	
UCD-MX 10.00	
UCD-165 8.45	
UCD-167 2.20	

UviPak UCD

Starting Point	Formula
224 C	
UCD-TW 66.60	
UCD-165 23.40	
UCD-MX 10.00	

Starting Point	Formula
225 C	
UCD-165 49.40	
UCD-TW 40.60	
UCD-MX 10.00	

Starting Point	Formula
226 C	
UCD-165 48.55	
UCD-167 25.75	
UCD-TW 15.70	
UCD-MX 10.00	

Starting Point	Formula
227 C	
UCD-165 48.85	
UCD-167 44.50	
UCD-MX 5.55	
UCD-233 1.10	

Starting Point	Formula
228 C	
UCD-167 92.25	
UCD-164 4.40	
UCD-230 3.35	

Starting Point	Formula
229 C	
UCD-167 77.45	
UCD-066 10.90	
UCD-325 8.55	
UCD-235 3.10	

Starting Point	Formula
230 C	
UCD-TW 93.20	
UCD-167 6.80	

Starting Point	Formula
231 C	
UCD-TW 70.65	
UCD-165 19.35	
UCD-MX 10.00	

Starting Point	Formula
232 C	
UCD-TW 52.05	
UCD-165 37.95	
UCD-MX 10.00	

Starting Point	Formula
233 C	
UCD-165 58.95	
UCD-TW 31.05	
UCD-MX 10.00	

Starting Point	Formula
234 C	
UCD-165 70.45	
UCD-TW 17.75	
UCD-MX 10.00	
UCD-SB 1.80	

Starting Point	Formula
235 C	
UCD-167 85.80	
UCD-MX 7.80	
UCD-325 5.25	
UCD-235 1.15	

Starting Point	Formula
236 C	
UCD-TW 92.40	
UCD-165 7.60	

Starting Point	Formula
237 C	
UCD-TW 74.55	
UCD-165 15.45	
UCD-MX 10.00	

Starting Point	Formula
238 C	
UCD-TW 60.45	
UCD-165 29.55	
UCD-MX 10.00	

Starting Point	Formula
239 C	
UCD-TW 50.55	
UCD-165 39.45	
UCD-MX 10.00	

UviPak UCD

Starting Point	Formula
240 C	
UCD-165 48.45	
UCD-TW 41.35	
UCD-MX 10.00	
UCD-235 0.20	

Starting Point	Formula
241 C	
UCD-165 64.05	
UCD-TW 25.15	
UCD-MX 10.00	
UCD-230 0.80	

Starting Point	Formula
242 C	
UCD-167 84.25	
UCD-064 10.50	
UCD-230 5.25	

Starting Point	Formula
2365 C	
UCD-TW 96.30	
UCD-165 3.70	

Starting Point	Formula
2375 C	
UCD-TW 67.50	
UCD-165 22.50	
UCD-MX 10.00	

Starting Point	Formula
2385 C	
UCD-TW 46.30	
UCD-165 37.05	
UCD-MX 15.00	
UCD-129 1.65	

Starting Point	Formula
2395 C	
UCD-165 44.70	
UCD-TW 39.95	
UCD-MX 15.00	
UCD-127 0.35	

Starting Point	Formula
2405 C	
UCD-165 83.65	
UCD-MX 15.00	
UCD-235 1.35	

Starting Point	Formula
2415 C	
UCD-165 83.05	
UCD-MX 15.00	
UCD-235 1.95	

Starting Point	Formula
2425 C	
UCD-167 77.30	
UCD-MX 12.40	
UCD-127 9.60	
UCD-230 0.70	

Starting Point	Formula
243 C	
UCD-TW 95.35	
UCD-165 4.65	

Starting Point	Formula
244 C	
UCD-TW 89.80	
UCD-165 10.20	

Starting Point	Formula
245 C	
UCD-TW 71.45	
UCD-MX 15.00	
UCD-167 11.15	
UCD-127 2.40	

Starting Point	Formula
246 C	
UCD-165 42.50	
UCD-TW 41.30	
UCD-MX 15.00	
UCD-127 1.20	

Starting Point	Formula
247 C	
UCD-165 43.20	
UCD-TW 40.00	
UCD-MX 15.00	
UCD-127 1.80	

Starting Point	Formula
248 C	
UCD-165 50.60	
UCD-TW 30.75	
UCD-MX 15.00	
UCD-127 3.65	

UviPak UCD

Starting Point	Formula
249 C	
UCD-167 55.50	
UCD-TW 15.30	
UCD-MX 15.00	
UCD-127 8.30	
UCD-SB 5.90	

Starting Point	Formula
250 C	
UCD-TW 96.40	
UCD-165 3.10	
UCD-129 0.50	

Starting Point	Formula
251 C	
UCD-TW 91.50	
UCD-165 7.35	
UCD-127 1.15	

Starting Point	Formula
252 C	
UCD-TW 62.70	
UCD-165 19.30	
UCD-MX 15.00	
UCD-127 3.00	

Starting Point	Formula
253 C	
UCD-TW 43.75	
UCD-165 36.65	
UCD-MX 15.00	
UCD-127 4.60	

Starting Point	Formula
254 C	
UCD-TW 40.90	
UCD-165 38.10	
UCD-MX 15.00	
UCD-127 6.00	

Starting Point	Formula
255 C	
UCD-165 73.05	
UCD-TW 14.75	
UCD-233 6.75	
UCD-062 5.45	

Starting Point	Formula
256 C	
UCD-TW 98.90	
UCD-127 1.10	

Starting Point	Formula
257 C	
UCD-TW 93.45	
UCD-165 5.95	
UCD-235 0.60	

Starting Point	Formula
258 C	
UCD-TW 50.75	
UCD-165 38.60	
UCD-MX 8.05	
UCD-235 2.60	

Starting Point	Formula
259 C	
UCD-165 67.55	
UCD-MX 15.00	
UCD-TW 13.15	
UCD-230 4.30	

Starting Point	Formula
260 C	
UCD-165 72.10	
UCD-325 12.25	
UCD-TW 8.85	
UCD-MX 6.80	

Starting Point	Formula
261 C	
UCD-165 69.15	
UCD-062 14.65	
UCD-MX 10.25	
UCD-230 5.95	

Starting Point	Formula
262 C	
UCD-165 69.80	
UCD-062 23.35	
UCD-230 6.85	

Starting Point	Formula
2562 C	
UCD-TW 97.25	
UCD-127 2.75	

Starting Point	Formula
2572 C	
UCD-TW 79.60	
UCD-MX 15.00	
UCD-127 5.40	

UviPak UCD

Starting Point	Formula
2582 C	
UCD-TW 71.35	
UCD-MX 15.00	
UCD-127 13.65	

Starting Point	Formula
2592 C	
UCD-TW 65.10	
UCD-127 19.90	
UCD-MX 15.00	

Starting Point	Formula
2602 C	
UCD-TW 63.00	
UCD-127 33.25	
UCD-MX 3.75	

Starting Point	Formula
2612 C	
UCD-165 78.75	
UCD-MX 15.00	
UCD-235 6.25	

Starting Point	Formula
2622 C	
UCD-165 67.15	
UCD-TW 18.50	
UCD-SB 10.65	
UCD-235 3.70	

Starting Point	Formula
2563 C	
UCD-TW 96.00	
UCD-127 2.20	
UCD-165 1.80	

Starting Point	Formula
2573 C	
UCD-TW 91.10	
UCD-165 5.10	
UCD-127 3.80	

Starting Point	Formula
2583 C	
UCD-TW 66.40	
UCD-MX 15.00	
UCD-165 11.70	
UCD-127 6.90	

Starting Point	Formula
2593 C	
UCD-TW 65.95	
UCD-127 19.05	
UCD-MX 15.00	

Starting Point	Formula
2603 C	
UCD-165 38.25	
UCD-TW 32.95	
UCD-MX 15.00	
UCD-127 13.80	

Starting Point	Formula
2613 C	
UCD-165 67.00	
UCD-MX 15.00	
UCD-TW 12.30	
UCD-235 5.70	

Starting Point	Formula
2623 C	
UCD-165 81.25	
UCD-TW 10.15	
UCD-230 5.95	
UCD-064 2.65	

Starting Point	Formula
2567 C	
UCD-TW 97.10	
UCD-127 2.90	

Starting Point	Formula
2577 C	
UCD-TW 79.40	
UCD-MX 15.00	
UCD-127 5.60	

Starting Point	Formula
2587 C	
UCD-TW 70.90	
UCD-MX 15.00	
UCD-127 14.10	

Starting Point	Formula
2597 C	
UCD-TW 57.60	
UCD-127 27.40	
UCD-MX 15.00	

UviPak UCD

Starting Point	Formula
2607 C	
UCD-TW 48.50	
UCD-127 36.50	
UCD-MX 15.00	

Starting Point	Formula
2617 C	
UCD-165 76.25	
UCD-MX 15.00	
UCD-235 8.75	

Starting Point	Formula
2627 C	
UCD-165 63.10	
UCD-MX 14.45	
UCD-325 11.60	
UCD-127 10.85	

Starting Point	Formula
263 C	
UCD-TW 99.15	
UCD-127 0.85	

Starting Point	Formula
264 C	
UCD-TW 97.60	
UCD-127 2.40	

Starting Point	Formula
265 C	
UCD-TW 75.15	
UCD-MX 15.00	
UCD-127 9.25	
UCD-235 0.60	

Starting Point	Formula
266 C	
UCD-TW 66.25	
UCD-127 17.90	
UCD-MX 15.00	
UCD-235 0.85	

Starting Point	Formula
267 C	
UCD-TW 59.40	
UCD-127 25.60	
UCD-MX 15.00	

Starting Point	Formula
268 C	
UCD-165 58.90	
UCD-TW 19.30	
UCD-MX 13.30	
UCD-235 8.50	

Starting Point	Formula
269 C	
UCD-165 64.00	
UCD-TW 23.80	
UCD-230 6.55	
UCD-SB 5.65	

Starting Point	Formula
2635 C	
UCD-TW 98.30	
UCD-127 1.35	
UCD-235 0.35	

Starting Point	Formula
2645 C	
UCD-TW 96.20	
UCD-127 3.20	
UCD-235 0.60	

Starting Point	Formula
2655 C	
UCD-TW 77.15	
UCD-MX 15.00	
UCD-127 6.90	
UCD-235 0.95	

Starting Point	Formula
2665 C	
UCD-TW 71.55	
UCD-MX 15.00	
UCD-127 12.15	
UCD-235 1.30	

Starting Point	Formula
2685 C	
UCD-TW 49.60	
UCD-127 35.40	
UCD-MX 15.00	

Starting Point	Formula
2695 C	
UCD-127 49.55	
UCD-165 36.65	
UCD-TW 9.70	
UCD-SB 4.10	

UviPak UCD

Starting Point	Formula
270 C	
UCD-TW 98.10	
UCD-127 1.20	
UCD-235 0.70	

Starting Point	Formula
271 C	
UCD-TW 75.60	
UCD-MX 15.00	
UCD-165 6.90	
UCD-235 2.50	

Starting Point	Formula
272 C	
UCD-TW 70.05	
UCD-MX 15.00	
UCD-165 9.70	
UCD-235 3.95	
UCD-127 1.30	

Starting Point	Formula
273 C	
UCD-165 70.05	
UCD-235 15.10	
UCD-MX 14.85	

Starting Point	Formula
274 C	
UCD-165 50.85	
UCD-129 26.20	
UCD-233 22.95	

Starting Point	Formula
275 C	
UCD-129 42.15	
UCD-165 32.80	
UCD-233 25.05	

Starting Point	Formula
276 C	
UCD-129 50.05	
UCD-121 25.05	
UCD-233 24.90	

Starting Point	Formula
2705 C	
UCD-TW 96.30	
UCD-127 2.45	
UCD-235 1.25	

Starting Point	Formula
2715 C	
UCD-TW 82.05	
UCD-MX 11.25	
UCD-127 4.30	
UCD-235 2.40	

Starting Point	Formula
2725 C	
UCD-TW 67.60	
UCD-MX 15.00	
UCD-127 11.65	
UCD-235 5.75	

Starting Point	Formula
2735 C	
UCD-235 64.30	
UCD-127 20.70	
UCD-MX 15.00	

Starting Point	Formula
2745 C	
UCD-233 68.75	
UCD-127 16.25	
UCD-MX 15.00	

Starting Point	Formula
2755 C	
UCD-165 54.65	
UCD-127 25.35	
UCD-230 13.55	
UCD-MX 6.45	

Starting Point	Formula
2765 C	
UCD-127 86.75	
UCD-325 13.25	

Starting Point	Formula
2706 C	
UCD-TW 99.00	
UCD-235 0.50	
UCD-127 0.50	

Starting Point	Formula
2716 C	
UCD-TW 96.40	
UCD-127 1.85	
UCD-235 1.75	

UviPak UCD

Starting Point	Formula
2726 C	
UCD-TW 65.10	
UCD-MX 15.00	
UCD-235 9.95	
UCD-127 9.95	

Starting Point	Formula
2736 C	
UCD-TW 48.25	
UCD-235 19.30	
UCD-127 17.45	
UCD-MX 15.00	

Starting Point	Formula
2746 C	
UCD-TW 43.00	
UCD-235 21.10	
UCD-127 20.90	
UCD-MX 15.00	

Starting Point	Formula
2756 C	
UCD-165 77.60	
UCD-230 22.40	

Starting Point	Formula
2766 C	
UCD-165 68.55	
UCD-235 18.80	
UCD-SB 12.65	

Starting Point	Formula
2707 C	
UCD-TW 98.85	
UCD-235 0.75	
UCD-127 0.40	

Starting Point	Formula
2717 C	
UCD-TW 97.65	
UCD-235 1.55	
UCD-127 0.80	

Starting Point	Formula
2727 C	
UCD-TW 69.75	
UCD-MX 15.00	
UCD-235 11.50	
UCD-127 3.75	

Starting Point	Formula
2747 C	
UCD-233 53.30	
UCD-235 23.20	
UCD-MX 15.00	
UCD-127 8.50	

Starting Point	Formula
2757 C	
UCD-233 92.35	
UCD-121 7.65	

Starting Point	Formula
2767 C	
UCD-129 68.80	
UCD-325 31.20	

Starting Point	Formula
2708 C	
UCD-TW 97.45	
UCD-165 1.30	
UCD-235 1.25	

Starting Point	Formula
2718 C	
UCD-TW 76.45	
UCD-MX 15.00	
UCD-235 5.90	
UCD-127 2.65	

Starting Point	Formula
2728 C	
UCD-TW 53.50	
UCD-235 22.25	
UCD-MX 15.00	
UCD-127 9.25	

Starting Point	Formula
2738 C	
UCD-TW 45.75	
UCD-235 21.80	
UCD-127 17.45	
UCD-MX 15.00	

Starting Point	Formula
2748 C	
UCD-233 77.75	
UCD-MX 15.00	
UCD-127 7.25	

UviPak UCD

Starting Point 2758 C UCD-233 55.45 UCD-165 41.75 UCD-164 2.80	Formula	Starting Point 2768 C UCD-129 54.65 UCD-233 38.35 UCD-164 7.00	Formula	Starting Point 277 C UCD-TW 98.40 UCD-235 1.20 UCD-127 0.40	Formula	Starting Point 278 C UCD-TW 97.00 UCD-235 2.30 UCD-127 0.70	Formula
Starting Point 279 C UCD-TW 84.70 UCD-235 9.70 UCD-165 5.60	Formula	Starting Point 280 C UCD-233 88.55 UCD-MX 11.45	Formula	Starting Point 281 C UCD-233 96.65 UCD-066 3.35	Formula	Starting Point 282 C UCD-233 81.25 UCD-164 18.75	Formula
Starting Point 283 C UCD-TW 97.40 UCD-235 2.10 UCD-127 0.50	Formula	Starting Point 284 C UCD-TW 94.70 UCD-235 4.35 UCD-127 0.95	Formula	Starting Point 285 C UCD-TW 60.40 UCD-235 21.60 UCD-MX 15.00 UCD-127 3.00	Formula	Starting Point 286 C UCD-TW 39.55 UCD-235 35.10 UCD-MX 15.00 UCD-127 10.35	Formula
Starting Point 287 C UCD-235 76.15 UCD-MX 15.00 UCD-127 8.85	Formula	Starting Point 288 C UCD-233 56.00 UCD-235 44.00	Formula	Starting Point 289 C UCD-233 78.75 UCD-SB 21.25	Formula	Starting Point 290 C UCD-TW 99.15 UCD-235 0.85	Formula

UviPak UCD

Starting Point 291 C UCD-TW 98.10 UCD-235 1.90	Formula	Starting Point 292 C UCD-TW 94.75 UCD-235 4.60 UCD-127 0.65	Formula	Starting Point 293 C UCD-235 46.70 UCD-TW 32.65 UCD-MX 15.00 UCD-127 5.65	Formula	Starting Point 294 C UCD-235 79.00 UCD-129 21.00	Formula
Starting Point 295 C UCD-235 56.45 UCD-233 30.10 UCD-SB 13.45	Formula	Starting Point 296 C UCD-129 42.40 UCD-SB 31.60 UCD-235 26.00	Formula	Starting Point 2905 C UCD-TW 97.80 UCD-235 2.20	Formula	Starting Point 2915 C UCD-TW 95.30 UCD-235 4.70	Formula
Starting Point 2925 C UCD-TW 86.65 UCD-235 13.35	Formula	Starting Point 2935 C UCD-TW 42.60 UCD-235 40.25 UCD-MX 15.00 UCD-127 2.15	Formula	Starting Point 2945 C UCD-235 81.00 UCD-TW 19.00	Formula	Starting Point 2955 C UCD-230 66.10 UCD-233 27.90 UCD-066 6.00	Formula
Starting Point 2965 C UCD-235 46.75 UCD-SB 28.75 UCD-233 24.50	Formula	Starting Point 297 C UCD-TW 96.95 UCD-235 3.05	Formula	Starting Point 298 C UCD-TW 83.50 UCD-MX 11.30 UCD-235 5.20	Formula	Starting Point 299 C UCD-TW 74.00 UCD-MX 15.00 UCD-235 11.00	Formula

UviPak UCD

Starting Point	Formula
300 C	
UCD-235 42.80	
UCD-TW 42.20	
UCD-MX 15.00	

Starting Point	Formula
301 C	
UCD-230 94.15	
UCD-MX 5.85	

Starting Point	Formula
302 C	
UCD-235 88.45	
UCD-066 11.55	

Starting Point	Formula
303 C	
UCD-235 61.80	
UCD-SB 29.50	
UCD-325 8.70	

Starting Point	Formula
2975 C	
UCD-TW 83.70	
UCD-MX 15.00	
UCD-235 1.30	

Starting Point	Formula
2985 C	
UCD-TW 81.35	
UCD-MX 15.00	
UCD-235 3.65	

Starting Point	Formula
2995 C	
UCD-TW 76.20	
UCD-MX 15.00	
UCD-235 8.80	

Starting Point	Formula
3005 C	
UCD-TW 59.75	
UCD-235 25.25	
UCD-MX 15.00	

Starting Point	Formula
3015 C	
UCD-235 42.20	
UCD-TW 32.20	
UCD-MX 15.00	
UCD-325 10.60	

Starting Point	Formula
3025 C	
UCD-230 65.95	
UCD-TW 19.25	
UCD-MX 8.30	
UCD-066 6.50	

Starting Point	Formula
3035 C	
UCD-233 46.35	
UCD-325 23.70	
UCD-064 17.95	
UCD-MX 12.00	

Starting Point	Formula
304 C	
UCD-TW 98.50	
UCD-230 1.50	

Starting Point	Formula
305 C	
UCD-TW 91.05	
UCD-MX 5.05	
UCD-230 3.90	

Starting Point	Formula
306 C	
UCD-TW 75.95	
UCD-MX 15.00	
UCD-230 9.05	

Starting Point	Formula
307 C	
UCD-TW 48.20	
UCD-230 36.80	
UCD-MX 15.00	

Starting Point	Formula
308 C	
UCD-230 80.40	
UCD-325 19.60	

UviPak UCD

Starting Point	Formula
309 C	
UCD-230 78.90	
UCD-066 11.00	
UCD-SB 10.10	

Starting Point	Formula
310 C	
UCD-TW 81.90	
UCD-MX 15.00	
UCD-230 3.10	

Starting Point	Formula
311 C	
UCD-TW 77.55	
UCD-MX 15.00	
UCD-230 5.40	
UCD-325 2.05	

Starting Point	Formula
312 C	
UCD-TW 65.70	
UCD-MX 15.00	
UCD-230 12.65	
UCD-325 6.65	

Starting Point	Formula
313 C	
UCD-TW 69.35	
UCD-230 15.65	
UCD-MX 15.00	

Starting Point	Formula
314 C	
UCD-TW 42.15	
UCD-230 28.60	
UCD-MX 15.00	
UCD-325 14.25	

Starting Point	Formula
315 C	
UCD-230 53.80	
UCD-325 29.35	
UCD-TW 16.85	

Starting Point	Formula
316 C	
UCD-233 41.10	
UCD-064 24.20	
UCD-325 21.20	
UCD-MX 13.50	

Starting Point	Formula
3105 C	
UCD-TW 81.50	
UCD-MX 15.00	
UCD-230 2.85	
UCD-062 0.65	

Starting Point	Formula
3115 C	
UCD-TW 75.90	
UCD-MX 15.00	
UCD-230 4.90	
UCD-325 4.20	

Starting Point	Formula
3125 C	
UCD-TW 64.90	
UCD-MX 15.00	
UCD-230 10.40	
UCD-325 9.70	

Starting Point	Formula
3135 C	
UCD-TW 50.80	
UCD-230 18.70	
UCD-325 15.50	
UCD-MX 15.00	

Starting Point	Formula
3145 C	
UCD-230 31.50	
UCD-TW 27.30	
UCD-325 26.20	
UCD-MX 15.00	

Starting Point	Formula
3155 C	
UCD-325 37.75	
UCD-230 29.65	
UCD-MX 15.00	
UCD-TW 12.30	
UCD-167 5.30	

Starting Point	Formula
3165 C	
UCD-325 60.55	
UCD-233 34.60	
UCD-TW 4.85	

Starting Point	Formula
317 C	
UCD-TW 98.45	
UCD-325 0.85	
UCD-230 0.70	

UviPak UCD

Starting Point	Formula
318 C	
UCD-TW 81.70	
UCD-MX 15.00	
UCD-230 1.70	
UCD-325 1.60	

Starting Point	Formula
319 C	
UCD-TW 77.35	
UCD-MX 15.00	
UCD-325 4.55	
UCD-230 3.10	

Starting Point	Formula
320 C	
UCD-TW 41.85	
UCD-325 28.30	
UCD-MX 15.00	
UCD-230 14.85	

Starting Point	Formula
321 C	
UCD-TW 34.05	
UCD-325 31.30	
UCD-230 19.65	
UCD-MX 15.00	

Starting Point	Formula
322 C	
UCD-230 28.45	
UCD-325 28.20	
UCD-TW 24.70	
UCD-MX 15.00	
UCD-066 3.65	

Starting Point	Formula
323 C	
UCD-230 37.95	
UCD-TW 20.90	
UCD-325 15.50	
UCD-MX 15.00	
UCD-066 10.65	

Starting Point	Formula
324 C	
UCD-TW 97.40	
UCD-325 1.60	
UCD-230 1.00	

Starting Point	Formula
325 C	
UCD-TW 78.80	
UCD-MX 15.00	
UCD-325 4.80	
UCD-235 1.40	

Starting Point	Formula
326 C	
UCD-TW 76.75	
UCD-325 19.55	
UCD-235 3.70	

Starting Point	Formula
327 C	
UCD-325 64.00	
UCD-TW 19.50	
UCD-230 16.50	

Starting Point	Formula
328 C	
UCD-325 33.85	
UCD-230 28.75	
UCD-MX 15.00	
UCD-064 14.15	
UCD-TW 8.25	

Starting Point	Formula
329 C	
UCD-325 37.65	
UCD-230 30.95	
UCD-MX 15.00	
UCD-066 8.40	
UCD-TW 8.00	

Starting Point	Formula
330 C	
UCD-230 39.35	
UCD-TW 32.90	
UCD-066 24.65	
UCD-167 3.10	

Starting Point	Formula
3242 C	
UCD-TW 78.50	
UCD-MX 15.00	
UCD-325 5.80	
UCD-235 0.70	

Starting Point	Formula
3252 C	
UCD-TW 75.75	
UCD-MX 15.00	
UCD-325 7.55	
UCD-230 1.70	

Starting Point	Formula
3262 C	
UCD-TW 59.20	
UCD-325 22.15	
UCD-MX 15.00	
UCD-230 3.65	

UviPak UCD

Starting Point	Formula
3272 C	
UCD-325 43.00	
UCD-TW 34.15	
UCD-MX 15.00	
UCD-230 7.85	

Starting Point	Formula
3282 C	
UCD-325 49.70	
UCD-TW 23.85	
UCD-MX 15.00	
UCD-230 8.50	
UCD-129 2.95	

Starting Point	Formula
3292 C	
UCD-325 57.95	
UCD-129 18.50	
UCD-MX 15.00	
UCD-064 8.55	

Starting Point	Formula
3302 C	
UCD-325 50.45	
UCD-129 24.85	
UCD-MX 15.00	
UCD-066 9.70	

Starting Point	Formula
3245 C	
UCD-TW 78.75	
UCD-MX 15.00	
UCD-325 5.85	
UCD-235 0.40	

Starting Point	Formula
3255 C	
UCD-TW 74.00	
UCD-MX 15.00	
UCD-325 10.05	
UCD-230 0.95	

Starting Point	Formula
3265 C	
UCD-TW 62.40	
UCD-325 20.95	
UCD-MX 15.00	
UCD-230 1.65	

Starting Point	Formula
3275 C	
UCD-325 41.00	
UCD-TW 40.45	
UCD-MX 15.00	
UCD-230 3.55	

Starting Point	Formula
3285 C	
UCD-325 51.50	
UCD-TW 32.45	
UCD-MX 10.70	
UCD-233 5.35	

Starting Point	Formula
3295 C	
UCD-325 69.95	
UCD-TW 22.55	
UCD-129 7.50	

Starting Point	Formula
3305 C	
UCD-325 54.30	
UCD-129 16.70	
UCD-MX 15.00	
UCD-114 7.75	
UCD-TW 6.25	

Starting Point	Formula
3248 C	
UCD-TW 93.45	
UCD-325 4.80	
UCD-064 0.95	
UCD-235 0.80	

Starting Point	Formula
3258 C	
UCD-TW 74.90	
UCD-MX 15.00	
UCD-325 5.35	
UCD-062 2.95	
UCD-235 1.80	

Starting Point	Formula
3268 C	
UCD-TW 55.95	
UCD-MX 15.00	
UCD-325 11.45	
UCD-062 10.25	
UCD-230 7.35	

Starting Point	Formula
3278 C	
UCD-325 64.05	
UCD-TW 32.50	
UCD-233 3.45	

Starting Point	Formula
3288 C	
UCD-325 27.90	
UCD-TW 22.75	
UCD-064 17.60	
UCD-230 16.75	
UCD-MX 15.00	

UviPak UCD

Starting Point	Formula
3298 C	
UCD-325 38.25	
UCD-TW 18.55	
UCD-235 15.10	
UCD-MX 15.00	
UCD-066 13.10	

Starting Point	Formula
3308 C	
UCD-230 47.25	
UCD-064 25.90	
UCD-114 15.10	
UCD-TW 7.10	
UCD-325 4.65	

Starting Point	Formula
331 C	
UCD-TW 94.50	
UCD-325 4.20	
UCD-MX 1.30	

Starting Point	Formula
332 C	
UCD-TW 93.40	
UCD-325 6.60	

Starting Point	Formula
333 C	
UCD-TW 70.15	
UCD-MX 15.00	
UCD-325 14.85	

Starting Point	Formula
334 C	
UCD-325 70.25	
UCD-MX 15.00	
UCD-TW 12.70	
UCD-129 2.05	

Starting Point	Formula
335 C	
UCD-325 74.30	
UCD-MX 15.00	
UCD-167 8.05	
UCD-066 2.65	

Starting Point	Formula
336 C	
UCD-325 74.70	
UCD-MX 10.55	
UCD-066 9.35	
UCD-127 5.40	

Starting Point	Formula
337 C	
UCD-TW 93.55	
UCD-325 3.40	
UCD-064 2.15	
UCD-230 0.90	

Starting Point	Formula
338 C	
UCD-TW 90.30	
UCD-325 4.30	
UCD-062 4.05	
UCD-235 1.35	

Starting Point	Formula
339 C	
UCD-TW 63.55	
UCD-325 26.45	
UCD-064 7.30	
UCD-230 2.70	

Starting Point	Formula
340 C	
UCD-062 30.25	
UCD-TW 24.50	
UCD-325 22.40	
UCD-MX 15.00	
UCD-235 7.85	

Starting Point	Formula
341 C	
UCD-064 32.20	
UCD-TW 30.10	
UCD-325 20.75	
UCD-230 16.05	
UCD-129 0.90	

Starting Point	Formula
342 C	
UCD-325 45.85	
UCD-TW 21.05	
UCD-066 19.05	
UCD-235 14.05	

Starting Point	Formula
343 C	
UCD-062 32.05	
UCD-TW 30.80	
UCD-230 26.15	
UCD-114 11.00	

Starting Point	Formula
3375 C	
UCD-TW 74.70	
UCD-MX 15.00	
UCD-325 8.20	
UCD-062 2.10	

UviPak UCD

Starting Point	Formula
3385 C	
UCD-TW 69.85	
UCD-MX 15.00	
UCD-325 12.10	
UCD-062 3.05	

Starting Point	Formula
3395 C	
UCD-TW 47.10	
UCD-325 29.05	
UCD-MX 15.00	
UCD-062 8.85	

Starting Point	Formula
3405 C	
UCD-325 60.45	
UCD-062 16.30	
UCD-MX 15.00	
UCD-TW 8.25	

Starting Point	Formula
3415 C	
UCD-325 83.50	
UCD-066 10.15	
UCD-165 6.35	

Starting Point	Formula
3425 C	
UCD-325 75.50	
UCD-066 12.75	
UCD-165 11.75	

Starting Point	Formula
3435 C	
UCD-325 67.00	
UCD-SB 29.80	
UCD-114 3.20	

Starting Point	Formula
344 C	
UCD-TW 94.00	
UCD-325 3.70	
UCD-064 2.20	
UCD-165 0.10	

Starting Point	Formula
345 C	
UCD-TW 89.70	
UCD-325 5.20	
UCD-062 4.60	
UCD-129 0.50	

Starting Point	Formula
346 C	
UCD-TW 82.70	
UCD-062 8.95	
UCD-325 7.10	
UCD-233 1.25	

Starting Point	Formula
347 C	
UCD-325 56.60	
UCD-064 25.10	
UCD-TW 17.80	
UCD-165 0.50	

Starting Point	Formula
348 C	
UCD-064 44.30	
UCD-325 33.30	
UCD-TW 13.55	
UCD-235 7.50	
UCD-MX 1.35	

Starting Point	Formula
349 C	
UCD-064 46.75	
UCD-325 21.20	
UCD-233 17.05	
UCD-MX 15.00	

Starting Point	Formula
350 C	
UCD-064 35.00	
UCD-325 31.80	
UCD-129 13.00	
UCD-MX 12.50	
UCD-121 7.70	

Starting Point	Formula
351 C	
UCD-TW 79.89	
UCD-MX 15.33	
UCD-062 3.42	
UCD-325 1.36	

Starting Point	Formula
352 C	
UCD-TW 75.05	
UCD-MX 15.00	
UCD-325 5.15	
UCD-062 4.80	

Starting Point	Formula
353 C	
UCD-TW 70.90	
UCD-MX 15.00	
UCD-325 7.30	
UCD-062 6.80	

UviPak UCD

Starting Point	Formula
354 C	
UCD-062 46.30	
UCD-325 39.40	
UCD-TW 14.30	

Starting Point	Formula
355 C	
UCD-325 48.40	
UCD-062 28.95	
UCD-064 13.50	
UCD-TW 7.85	
UCD-167 1.30	

Starting Point	Formula
356 C	
UCD-325 57.80	
UCD-064 39.70	
UCD-164 2.50	

Starting Point	Formula
357 C	
UCD-062 36.20	
UCD-325 29.85	
UCD-SB 23.10	
UCD-TW 10.85	

Starting Point	Formula
358 C	
UCD-TW 68.10	
UCD-MX 15.00	
UCD-064 12.30	
UCD-325 4.60	

Starting Point	Formula
359 C	
UCD-TW 78.80	
UCD-062 16.70	
UCD-325 4.05	
UCD-129 0.45	

Starting Point	Formula
360 C	
UCD-062 50.75	
UCD-TW 36.90	
UCD-325 11.30	
UCD-129 1.05	

Starting Point	Formula
361 C	
UCD-062 76.95	
UCD-TW 13.10	
UCD-325 6.45	
UCD-235 3.50	

Starting Point	Formula
362 C	
UCD-062 78.30	
UCD-TW 12.90	
UCD-230 6.20	
UCD-SB 2.60	

Starting Point	Formula
363 C	
UCD-062 74.15	
UCD-TW 11.80	
UCD-235 6.00	
UCD-325 4.70	
UCD-114 3.35	

Starting Point	Formula
364 C	
UCD-064 59.70	
UCD-325 17.15	
UCD-MX 13.00	
UCD-165 7.05	
UCD-235 3.10	

Starting Point	Formula
365 C	
UCD-TW 86.60	
UCD-062 11.85	
UCD-325 1.45	
UCD-129 0.10	

Starting Point	Formula
366 C	
UCD-TW 68.60	
UCD-062 15.70	
UCD-MX 15.00	
UCD-230 0.70	

Starting Point	Formula
367 C	
UCD-TW 53.15	
UCD-062 30.55	
UCD-MX 15.00	
UCD-230 1.30	

Starting Point	Formula
368 C	
UCD-062 73.70	
UCD-TW 23.05	
UCD-230 3.25	

Starting Point	Formula
369 C	
UCD-062 79.20	
UCD-MX 15.00	
UCD-230 4.20	
UCD-129 1.60	

UviPak UCD

Starting Point	Formula
370 C	
UCD-062	77.20
UCD-325	10.20
UCD-MX	7.00
UCD-129	5.60

Starting Point	Formula
371 C	
UCD-062	71.30
UCD-SB	14.60
UCD-TW	9.80
UCD-235	2.30
UCD-325	2.00

Starting Point	Formula
372 C	
UCD-TW	73.00
UCD-MX	15.00
UCD-062	11.15
UCD-325	0.85

Starting Point	Formula
373 C	
UCD-TW	68.05
UCD-062	15.80
UCD-MX	15.00
UCD-325	1.15

Starting Point	Formula
374 C	
UCD-TW	56.70
UCD-062	26.45
UCD-MX	15.00
UCD-325	1.85

Starting Point	Formula
375 C	
UCD-062	77.50
UCD-TW	16.85
UCD-325	5.65

Starting Point	Formula
376 C	
UCD-062	65.10
UCD-064	24.20
UCD-325	9.60
UCD-165	1.10

Starting Point	Formula
377 C	
UCD-062	56.30
UCD-064	32.30
UCD-325	9.75
UCD-127	1.65

Starting Point	Formula
378 C	
UCD-062	74.35
UCD-SB	19.65
UCD-325	6.00

Starting Point	Formula
379 C	
UCD-TW	58.60
UCD-062	25.80
UCD-MX	15.00
UCD-325	0.60

Starting Point	Formula
380 C	
UCD-TW	43.00
UCD-062	42.95
UCD-MX	13.05
UCD-325	1.00

Starting Point	Formula
381 C	
UCD-062	76.65
UCD-TW	21.40
UCD-325	1.90
UCD-164	0.05

Starting Point	Formula
382 C	
UCD-062	80.60
UCD-TW	16.95
UCD-325	2.20
UCD-129	0.25

Starting Point	Formula
383 C	
UCD-062	86.30
UCD-MX	7.75
UCD-325	3.35
UCD-129	1.75
UCD-114	0.85

Starting Point	Formula
384 C	
UCD-064	86.65
UCD-325	9.30
UCD-121	4.05

Starting Point	Formula
385 C	
UCD-062	78.75
UCD-SB	14.50
UCD-TW	6.15
UCD-230	0.60

UviPak UCD

Starting Point	Formula
386 C	
UCD-TW 57.00	
UCD-062 27.65	
UCD-MX 15.00	
UCD-325 0.35	

Starting Point	Formula
387 C	
UCD-062 54.65	
UCD-TW 29.55	
UCD-MX 15.00	
UCD-325 0.80	

Starting Point	Formula
388 C	
UCD-062 68.90	
UCD-MX 15.00	
UCD-TW 15.00	
UCD-325 1.10	

Starting Point	Formula
389 C	
UCD-062 90.85	
UCD-MX 7.40	
UCD-325 1.75	

Starting Point	Formula
390 C	
UCD-062 55.20	
UCD-064 40.10	
UCD-325 3.70	
UCD-165 1.00	

Starting Point	Formula
391 C	
UCD-064 68.05	
UCD-062 21.70	
UCD-325 6.20	
UCD-165 4.05	

Starting Point	Formula
392 C	
UCD-062 75.90	
UCD-066 14.45	
UCD-167 5.75	
UCD-230 3.90	

Starting Point	Formula
393 C	
UCD-TW 66.65	
UCD-062 18.35	
UCD-MX 15.00	

Starting Point	Formula
394 C	
UCD-062 43.80	
UCD-TW 40.90	
UCD-MX 15.00	
UCD-325 0.30	

Starting Point	Formula
395 C	
UCD-062 72.35	
UCD-MX 15.00	
UCD-TW 12.05	
UCD-325 0.60	

Starting Point	Formula
396 C	
UCD-062 99.15	
UCD-325 0.85	

Starting Point	Formula
397 C	
UCD-064 96.10	
UCD-325 3.05	
UCD-167 0.85	

Starting Point	Formula
398 C	
UCD-064 93.20	
UCD-325 4.40	
UCD-167 2.40	

Starting Point	Formula
399 C	
UCD-064 90.15	
UCD-325 6.10	
UCD-121 3.75	

Starting Point	Formula
3935 C	
UCD-TW 61.05	
UCD-062 23.95	
UCD-MX 15.00	

Starting Point	Formula
3945 C	
UCD-062 64.05	
UCD-TW 20.95	
UCD-MX 15.00	

UviPak UCD

Starting Point 3955 C UCD-062 100.00	Formula	Starting Point 3965 C UCD-062 99.75 UCD-325 0.25	Formula	Starting Point 3975 C UCD-064 93.60 UCD-325 4.00 UCD-121 2.40	Formula	Starting Point 3985 C UCD-064 86.70 UCD-325 7.70 UCD-121 5.60	Formula
Starting Point 3995 C UCD-062 78.35 UCD-SB 21.45 UCD-167 0.20	Formula	Starting Point 400 C UCD-TW 93.85 UCD-064 3.85 UCD-167 1.15 UCD-233 1.15	Formula	Starting Point 401 C UCD-TW 88.65 UCD-064 7.90 UCD-325 1.85 UCD-127 1.60	Formula	Starting Point 402 C UCD-TW 89.95 UCD-SB 6.60 UCD-064 3.00 UCD-165 0.45	Formula
Starting Point 403 C UCD-TW 80.65 UCD-SB 9.70 UCD-064 8.90 UCD-127 0.75	Formula	Starting Point 404 C UCD-TW 62.05 UCD-066 18.60 UCD-167 13.60 UCD-230 5.75	Formula	Starting Point 405 C UCD-TW 48.90 UCD-066 22.65 UCD-121 19.45 UCD-230 9.00	Formula	Starting Point 406 C UCD-TW 94.30 UCD-064 3.30 UCD-167 1.75 UCD-230 0.65	Formula
Starting Point 407 C UCD-TW 89.55 UCD-064 5.15 UCD-SB 2.70 UCD-165 1.75 UCD-233 0.85	Formula	Starting Point 408 C UCD-TW 78.35 UCD-064 15.80 UCD-127 3.25 UCD-325 2.60	Formula	Starting Point 409 C UCD-TW 74.30 UCD-SB 12.60 UCD-064 10.00 UCD-165 3.10	Formula	Starting Point 410 C UCD-TW 96.70 UCD-SB 1.55 UCD-064 1.50 UCD-114 0.25	Formula

UviPak UCD

Starting Point	Formula
411 C	
UCD-066 34.50	
UCD-165 30.80	
UCD-TW 25.45	
UCD-230 9.25	

Starting Point	Formula
412 C	
UCD-SB 41.10	
UCD-165 22.90	
UCD-066 22.25	
UCD-325 7.75	
UCD-TW 6.00	

Starting Point	Formula
413 C	
UCD-TW 93.90	
UCD-064 3.80	
UCD-233 1.35	
UCD-121 0.95	

Starting Point	Formula
414 C	
UCD-TW 89.00	
UCD-064 6.90	
UCD-325 1.85	
UCD-127 1.20	
UCD-SB 1.05	

Starting Point	Formula
415 C	
UCD-TW 85.50	
UCD-SB 9.55	
UCD-062 4.95	

Starting Point	Formula
416 C	
UCD-TW 76.00	
UCD-SB 15.15	
UCD-062 8.85	

Starting Point	Formula
417 C	
UCD-TW 62.95	
UCD-SB 22.85	
UCD-064 14.20	

Starting Point	Formula
418 C	
UCD-TW 41.50	
UCD-SB 36.60	
UCD-064 21.90	

Starting Point	Formula
419 C	
UCD-SB 93.75	
UCD-066 6.25	

Starting Point	Formula
420 C	
UCD-TW 96.70	
UCD-064 1.90	
UCD-165 0.90	
UCD-235 0.50	

Starting Point	Formula
421 C	
UCD-TW 91.95	
UCD-064 5.80	
UCD-233 1.40	
UCD-127 0.85	

Starting Point	Formula
422 C	
UCD-TW 87.00	
UCD-064 9.35	
UCD-233 2.25	
UCD-127 1.40	

Starting Point	Formula
423 C	
UCD-TW 78.25	
UCD-064 15.85	
UCD-233 3.50	
UCD-127 2.40	

Starting Point	Formula
424 C	
UCD-TW 56.35	
UCD-064 31.55	
UCD-233 7.00	
UCD-127 5.10	

Starting Point	Formula
425 C	
UCD-TW 42.10	
UCD-064 40.80	
UCD-233 9.50	
UCD-127 7.60	

Starting Point	Formula
426 C	
UCD-SB 76.15	
UCD-167 19.45	
UCD-MX 4.40	

UviPak UCD

Starting Point	Formula
427 C	
UCD-TW 97.70	
UCD-064 1.00	
UCD-233 0.75	
UCD-165 0.55	

Starting Point	Formula
428 C	
UCD-TW 96.25	
UCD-064 1.95	
UCD-165 1.15	
UCD-235 0.65	

Starting Point	Formula
429 C	
UCD-TW 90.35	
UCD-064 6.40	
UCD-233 2.15	
UCD-127 1.10	

Starting Point	Formula
430 C	
UCD-TW 75.80	
UCD-064 16.60	
UCD-233 5.00	
UCD-127 2.60	

Starting Point	Formula
431 C	
UCD-TW 52.95	
UCD-064 31.20	
UCD-233 10.35	
UCD-127 5.50	

Starting Point	Formula
432 C	
UCD-064 48.40	
UCD-TW 20.40	
UCD-233 19.70	
UCD-127 11.50	

Starting Point	Formula
433 C	
UCD-SB 46.60	
UCD-165 33.45	
UCD-062 14.55	
UCD-235 5.40	

Starting Point	Formula
434 C	
UCD-TW 96.05	
UCD-167 1.70	
UCD-325 1.55	
UCD-114 0.70	

Starting Point	Formula
435 C	
UCD-TW 91.80	
UCD-167 3.60	
UCD-325 3.10	
UCD-114 1.50	

Starting Point	Formula
436 C	
UCD-TW 88.60	
UCD-167 5.30	
UCD-325 4.15	
UCD-114 1.95	

Starting Point	Formula
437 C	
UCD-TW 65.55	
UCD-167 15.85	
UCD-325 11.60	
UCD-114 7.00	

Starting Point	Formula
438 C	
UCD-114 34.40	
UCD-TW 31.60	
UCD-325 20.20	
UCD-127 13.80	

Starting Point	Formula
439 C	
UCD-SB 52.45	
UCD-TW 25.10	
UCD-114 22.45	

Starting Point	Formula
440 C	
UCD-325 37.00	
UCD-114 35.70	
UCD-127 15.45	
UCD-TW 11.85	

Starting Point	Formula
441 C	
UCD-TW 94.65	
UCD-325 3.00	
UCD-167 1.45	
UCD-114 0.90	

Starting Point	Formula
442 C	
UCD-TW 91.40	
UCD-325 4.60	
UCD-167 2.75	
UCD-114 1.25	

UviPak UCD

Starting Point	Formula
443 C	
UCD-TW 90.40	
UCD-233 5.00	
UCD-114 4.60	

Starting Point	Formula
444 C	
UCD-TW 70.90	
UCD-325 15.40	
UCD-167 9.35	
UCD-114 4.35	

Starting Point	Formula
445 C	
UCD-TW 56.45	
UCD-233 22.15	
UCD-114 21.40	

Starting Point	Formula
446 C	
UCD-TW 43.95	
UCD-SB 29.80	
UCD-114 17.20	
UCD-230 9.05	

Starting Point	Formula
447 C	
UCD-325 40.50	
UCD-114 25.50	
UCD-TW 22.60	
UCD-127 11.40	

Starting Point	Formula
WARM GRAY 1 C	
UCD-TW 99.40	
UCD-SB 0.45	
UCD-064 0.15	

Starting Point	Formula
WARM GRAY 2 C	
UCD-TW 96.45	
UCD-064 2.25	
UCD-165 0.70	
UCD-233 0.60	

Starting Point	Formula
WARM GRAY 3 C	
UCD-TW 94.15	
UCD-064 4.00	
UCD-325 0.95	
UCD-127 0.90	

Starting Point	Formula
WARM GRAY 4 C	
UCD-TW 92.10	
UCD-SB 4.30	
UCD-064 3.00	
UCD-129 0.60	

Starting Point	Formula
WARM GRAY 5 C	
UCD-TW 90.30	
UCD-SB 5.95	
UCD-064 3.20	
UCD-165 0.55	

Starting Point	Formula
WARM GRAY 6 C	
UCD-TW 88.15	
UCD-SB 7.00	
UCD-064 4.10	
UCD-167 0.75	

Starting Point	Formula
WARM GRAY 7 C	
UCD-TW 82.60	
UCD-SB 9.45	
UCD-064 6.75	
UCD-165 1.20	

Starting Point	Formula
WARM GRAY 8 C	
UCD-TW 75.70	
UCD-SB 12.95	
UCD-064 10.35	
UCD-164 1.00	

Starting Point	Formula
WARM GRAY 9 C	
UCD-TW 69.30	
UCD-SB 15.10	
UCD-064 12.70	
UCD-167 2.90	

Starting Point	Formula
WARM GRAY 10 C	
UCD-TW 57.00	
UCD-066 21.00	
UCD-167 15.85	
UCD-230 6.15	

Starting Point	Formula
WARM GRAY 11 C	
UCD-TW 44.25	
UCD-066 26.55	
UCD-167 15.93	
UCD-SB 8.85	
UCD-230 4.42	

UviPak UCD

Starting Point	Formula
COOL GRAY 1 C	
UCD-TW 99.35	
UCD-064 0.20	
UCD-SB 0.45	

Starting Point	Formula
COOL GRAY 2 C	
UCD-TW 98.15	
UCD-129 0.75	
UCD-064 0.60	
UCD-325 0.50	

Starting Point	Formula
COOL GRAY 3 C	
UCD-TW 96.15	
UCD-064 2.10	
UCD-233 0.95	
UCD-165 0.80	

Starting Point	Formula
COOL GRAY 4 C	
UCD-TW 93.60	
UCD-064 3.55	
UCD-233 1.45	
UCD-165 1.40	

Starting Point	Formula
COOL GRAY 5 C	
UCD-TW 90.30	
UCD-064 5.50	
UCD-233 2.20	
UCD-167 2.00	

Starting Point	Formula
COOL GRAY 6 C	
UCD-TW 89.60	
UCD-064 7.30	
UCD-233 1.85	
UCD-127 1.25	

Starting Point	Formula
COOL GRAY 7 C	
UCD-TW 83.50	
UCD-064 11.80	
UCD-233 2.75	
UCD-127 1.95	

Starting Point	Formula
COOL GRAY 8 C	
UCD-TW 76.95	
UCD-064 16.60	
UCD-233 3.70	
UCD-127 2.75	

Starting Point	Formula
COOL GRAY 9 C	
UCD-TW 65.25	
UCD-064 25.05	
UCD-233 5.45	
UCD-127 4.25	

Starting Point	Formula
COOL GRAY 10 C	
UCD-TW 49.05	
UCD-064 36.45	
UCD-233 8.05	
UCD-127 6.45	

Starting Point	Formula
COOL GRAY 11 C	
UCD-064 51.28	
UCD-TW 30.77	
UCD-233 10.26	
UCD-127 7.69	

Starting Point	Formula
448 C	
UCD-062 78.45	
UCD-127 9.20	
UCD-SB 6.85	
UCD-233 5.50	

Starting Point	Formula
449 C	
UCD-062 80.40	
UCD-164 11.40	
UCD-230 8.20	

Starting Point	Formula
450 C	
UCD-062 82.00	
UCD-164 10.30	
UCD-230 7.70	

Starting Point	Formula
451 C	
UCD-TW 58.65	
UCD-062 33.15	
UCD-165 6.30	
UCD-235 1.90	

Starting Point	Formula
452 C	
UCD-TW 78.15	
UCD-062 16.90	
UCD-165 3.85	
UCD-230 1.10	

UviPak UCD

Starting Point	Formula
453 C	
UCD-TW 86.80	
UCD-062 10.45	
UCD-165 2.10	
UCD-235 0.65	

Starting Point	Formula
454 C	
UCD-TW 77.85	
UCD-MX 15.00	
UCD-062 5.65	
UCD-165 1.10	
UCD-235 0.40	

Starting Point	Formula
4485 C	
UCD-062 67.30	
UCD-SB 27.80	
UCD-165 4.90	

Starting Point	Formula
4495 C	
UCD-064 70.15	
UCD-MX 15.00	
UCD-121 10.45	
UCD-230 4.40	

Starting Point	Formula
4505 C	
UCD-064 60.10	
UCD-TW 27.65	
UCD-165 7.95	
UCD-325 2.95	
UCD-230 1.35	

Starting Point	Formula
4515 C	
UCD-TW 50.05	
UCD-064 29.70	
UCD-MX 15.00	
UCD-167 3.75	
UCD-230 1.50	

Starting Point	Formula
4525 C	
UCD-TW 80.60	
UCD-064 16.05	
UCD-325 2.25	
UCD-164 1.10	

Starting Point	Formula
4535 C	
UCD-TW 88.90	
UCD-062 9.30	
UCD-SB 0.90	
UCD-129 0.90	

Starting Point	Formula
4545 C	
UCD-TW 93.00	
UCD-064 6.10	
UCD-165 0.60	
UCD-230 0.30	

Starting Point	Formula
455 C	
UCD-062 72.20	
UCD-233 10.70	
UCD-114 10.20	
UCD-165 6.90	

Starting Point	Formula
456 C	
UCD-064 80.45	
UCD-165 8.30	
UCD-325 6.75	
UCD-TW 4.50	

Starting Point	Formula
457 C	
UCD-064 78.45	
UCD-MX 15.00	
UCD-325 4.25	
UCD-164 2.30	

Starting Point	Formula
458 C	
UCD-TW 65.45	
UCD-062 26.00	
UCD-064 7.80	
UCD-164 0.45	
UCD-235 0.30	

Starting Point	Formula
459 C	
UCD-TW 74.40	
UCD-062 24.65	
UCD-SB 0.75	
UCD-164 0.20	

Starting Point	Formula
460 C	
UCD-TW 82.70	
UCD-062 17.05	
UCD-127 0.25	

Starting Point	Formula
461 C	
UCD-TW 91.60	
UCD-062 8.25	
UCD-SB 0.10	
UCD-164 0.05	

UviPak UCD

Starting Point	Formula
462 C	
UCD-062 64.50	
UCD-SB 20.40	
UCD-165 13.30	
UCD-235 1.80	

Starting Point	Formula
463 C	
UCD-062 84.25	
UCD-164 10.65	
UCD-230 5.10	

Starting Point	Formula
464 C	
UCD-062 87.95	
UCD-164 8.55	
UCD-230 3.50	

Starting Point	Formula
465 C	
UCD-TW 49.40	
UCD-062 42.40	
UCD-165 7.15	
UCD-230 1.05	

Starting Point	Formula
466 C	
UCD-TW 71.80	
UCD-062 23.70	
UCD-165 3.90	
UCD-235 0.60	

Starting Point	Formula
467 C	
UCD-TW 85.30	
UCD-062 12.75	
UCD-129 1.95	

Starting Point	Formula
468 C	
UCD-TW 92.60	
UCD-062 6.40	
UCD-129 1.00	

Starting Point	Formula
4625 C	
UCD-066 43.90	
UCD-325 25.55	
UCD-164 15.55	
UCD-MX 15.00	

Starting Point	Formula
4635 C	
UCD-066 46.55	
UCD-TW 27.40	
UCD-167 19.20	
UCD-325 5.65	
UCD-235 1.20	

Starting Point	Formula
4645 C	
UCD-TW 58.30	
UCD-066 26.05	
UCD-167 11.55	
UCD-325 3.30	
UCD-235 0.80	

Starting Point	Formula
4655 C	
UCD-TW 77.90	
UCD-066 14.60	
UCD-121 6.10	
UCD-230 1.40	

Starting Point	Formula
4665 C	
UCD-TW 87.60	
UCD-066 8.35	
UCD-325 2.10	
UCD-164 1.95	

Starting Point	Formula
4675 C	
UCD-TW 92.95	
UCD-062 3.60	
UCD-066 2.55	
UCD-127 0.90	

Starting Point	Formula
4685 C	
UCD-TW 95.05	
UCD-064 3.45	
UCD-SB 0.90	
UCD-121 0.60	

Starting Point	Formula
469 C	
UCD-066 54.70	
UCD-121 21.00	
UCD-SB 13.85	
UCD-325 10.45	

Starting Point	Formula
470 C	
UCD-062 54.50	
UCD-114 17.40	
UCD-TW 14.00	
UCD-SB 8.35	
UCD-165 5.75	

UviPak UCD

Starting Point	Formula
471 C	
UCD-064 52.60	
UCD-114 25.10	
UCD-TW 14.50	
UCD-325 3.90	
UCD-164 3.90	

Starting Point	Formula
472 C	
UCD-TW 71.25	
UCD-064 19.75	
UCD-114 4.70	
UCD-167 3.10	
UCD-SB 1.20	

Starting Point	Formula
473 C	
UCD-TW 91.20	
UCD-066 6.00	
UCD-167 2.50	
UCD-325 0.30	

Starting Point	Formula
474 C	
UCD-TW 93.55	
UCD-066 4.80	
UCD-165 1.65	

Starting Point	Formula
475 C	
UCD-TW 93.70	
UCD-064 4.80	
UCD-121 0.85	
UCD-114 0.65	

Starting Point	Formula
4695 C	
UCD-062 59.90	
UCD-SB 27.75	
UCD-164 10.10	
UCD-MX 2.25	

Starting Point	Formula
4705 C	
UCD-062 62.60	
UCD-TW 19.45	
UCD-164 13.95	
UCD-230 4.00	

Starting Point	Formula
4715 C	
UCD-TW 40.85	
UCD-064 40.55	
UCD-165 16.30	
UCD-230 2.30	

Starting Point	Formula
4725 C	
UCD-TW 71.95	
UCD-062 21.60	
UCD-164 4.15	
UCD-233 2.30	

Starting Point	Formula
4735 C	
UCD-TW 80.90	
UCD-064 13.35	
UCD-165 4.30	
UCD-233 1.45	

Starting Point	Formula
4745 C	
UCD-TW 88.65	
UCD-062 7.40	
UCD-167 3.40	
UCD-235 0.55	

Starting Point	Formula
4755 C	
UCD-TW 93.30	
UCD-062 4.35	
UCD-165 2.05	
UCD-230 0.30	

Starting Point	Formula
476 C	
UCD-062 57.85	
UCD-SB 33.90	
UCD-164 8.25	

Starting Point	Formula
477 C	
UCD-062 65.55	
UCD-SB 24.30	
UCD-164 10.15	

Starting Point	Formula
478 C	
UCD-062 79.45	
UCD-164 15.85	
UCD-230 4.70	

Starting Point	Formula
479 C	
UCD-TW 46.90	
UCD-062 37.75	
UCD-165 13.95	
UCD-230 1.40	

UviPak UCD

Starting Point	Formula
480 C	
UCD-TW	79.50
UCD-062	14.15
UCD-165	5.75
UCD-230	0.60

Starting Point	Formula
481 C	
UCD-TW	88.05
UCD-062	8.30
UCD-165	3.25
UCD-235	0.40

Starting Point	Formula
482 C	
UCD-TW	92.35
UCD-062	5.45
UCD-165	1.95
UCD-235	0.25

Starting Point	Formula
483 C	
UCD-062	76.35
UCD-164	15.55
UCD-233	8.10

Starting Point	Formula
484 C	
UCD-062	80.95
UCD-164	17.15
UCD-230	1.90

Starting Point	Formula
485 C	
UCD-062	83.05
UCD-164	15.95
UCD-129	1.00

Starting Point	Formula
486 C	
UCD-TW	70.00
UCD-064	21.55
UCD-165	8.45

Starting Point	Formula
487 C	
UCD-TW	87.45
UCD-062	10.25
UCD-164	2.30

Starting Point	Formula
488 C	
UCD-TW	89.90
UCD-064	7.25
UCD-165	2.85

Starting Point	Formula
489 C	
UCD-TW	95.55
UCD-066	2.50
UCD-121	1.75
UCD-SB	0.20

Starting Point	Formula
490 C	
UCD-114	45.30
UCD-165	23.95
UCD-TW	18.25
UCD-233	12.50

Starting Point	Formula
491 C	
UCD-114	37.20
UCD-TW	29.65
UCD-165	29.00
UCD-230	4.15

Starting Point	Formula
492 C	
UCD-TW	37.30
UCD-114	28.80
UCD-165	24.45
UCD-SB	9.45

Starting Point	Formula
493 C	
UCD-TW	85.15
UCD-167	10.90
UCD-114	3.45
UCD-235	0.50

Starting Point	Formula
494 C	
UCD-TW	92.20
UCD-167	6.05
UCD-114	1.20
UCD-325	0.55

Starting Point	Formula
495 C	
UCD-TW	95.85
UCD-167	3.50
UCD-066	0.65

UviPak UCD

Starting Point	Formula
496 C	
UCD-TW 97.45	
UCD-167 2.15	
UCD-114 0.40	

Starting Point	Formula
497 C	
UCD-114 51.25	
UCD-167 21.95	
UCD-TW 13.45	
UCD-230 13.35	

Starting Point	Formula
498 C	
UCD-114 40.70	
UCD-TW 26.90	
UCD-325 18.50	
UCD-164 13.90	

Starting Point	Formula
499 C	
UCD-114 35.10	
UCD-TW 27.45	
UCD-165 25.00	
UCD-325 12.45	

Starting Point	Formula
500 C	
UCD-TW 84.05	
UCD-167 9.80	
UCD-114 5.10	
UCD-230 1.05	

Starting Point	Formula
501 C	
UCD-TW 93.30	
UCD-167 4.10	
UCD-114 1.95	
UCD-233 0.65	

Starting Point	Formula
502 C	
UCD-TW 96.45	
UCD-167 2.30	
UCD-114 0.90	
UCD-233 0.35	

Starting Point	Formula
503 C	
UCD-TW 97.75	
UCD-165 1.60	
UCD-066 0.65	

Starting Point	Formula
4975 C	
UCD-066 51.40	
UCD-167 31.70	
UCD-233 16.90	

Starting Point	Formula
4985 C	
UCD-TW 50.40	
UCD-167 24.45	
UCD-SB 13.80	
UCD-114 11.35	

Starting Point	Formula
4995 C	
UCD-TW 70.30	
UCD-167 15.30	
UCD-114 10.15	
UCD-233 4.25	

Starting Point	Formula
5005 C	
UCD-TW 90.50	
UCD-114 6.05	
UCD-127 3.45	

Starting Point	Formula
5015 C	
UCD-TW 95.85	
UCD-114 2.30	
UCD-127 1.50	
UCD-SB 0.35	

Starting Point	Formula
5025 C	
UCD-TW 96.55	
UCD-167 2.05	
UCD-114 1.05	
UCD-230 0.35	

Starting Point	Formula
5035 C	
UCD-TW 98.15	
UCD-167 1.00	
UCD-114 0.50	
UCD-233 0.35	

Starting Point	Formula
504 C	
UCD-114 41.85	
UCD-165 25.00	
UCD-TW 20.05	
UCD-233 13.10	

UviPak UCD

Starting Point	Formula
505 C	
UCD-167 39.25	
UCD-114 26.50	
UCD-TW 25.50	
UCD-233 8.75	

Starting Point	Formula
506 C	
UCD-167 38.05	
UCD-TW 37.40	
UCD-114 20.65	
UCD-235 3.90	

Starting Point	Formula
507 C	
UCD-TW 89.15	
UCD-167 8.85	
UCD-114 1.50	
UCD-235 0.50	

Starting Point	Formula
508 C	
UCD-TW 94.40	
UCD-167 4.75	
UCD-114 0.60	
UCD-235 0.25	

Starting Point	Formula
509 C	
UCD-TW 96.10	
UCD-165 3.45	
UCD-114 0.45	

Starting Point	Formula
510 C	
UCD-TW 97.00	
UCD-165 2.60	
UCD-114 0.40	

Starting Point	Formula
511 C	
UCD-167 68.30	
UCD-325 15.40	
UCD-064 13.00	
UCD-233 3.30	

Starting Point	Formula
512 C	
UCD-167 66.65	
UCD-MX 15.00	
UCD-TW 13.15	
UCD-235 5.20	

Starting Point	Formula
513 C	
UCD-165 54.75	
UCD-TW 27.85	
UCD-MX 15.00	
UCD-235 2.40	

Starting Point	Formula
514 C	
UCD-TW 88.00	
UCD-165 11.00	
UCD-127 1.00	

Starting Point	Formula
515 C	
UCD-TW 94.75	
UCD-165 4.70	
UCD-127 0.55	

Starting Point	Formula
516 C	
UCD-TW 96.55	
UCD-165 3.20	
UCD-127 0.25	

Starting Point	Formula
517 C	
UCD-TW 97.45	
UCD-165 2.55	

Starting Point	Formula
5115 C	
UCD-165 62.05	
UCD-325 20.30	
UCD-066 17.65	

Starting Point	Formula
5125 C	
UCD-165 46.75	
UCD-062 17.90	
UCD-TW 15.50	
UCD-MX 15.00	
UCD-230 4.85	

Starting Point	Formula
5135 C	
UCD-TW 42.80	
UCD-165 27.00	
UCD-MX 15.00	
UCD-062 12.20	
UCD-230 3.00	

UviPak UCD

Starting Point	Formula
5145 C	
UCD-TW 60.90	
UCD-MX 15.00	
UCD-165 13.20	
UCD-064 8.90	
UCD-230 2.00	

Starting Point	Formula
5155 C	
UCD-TW 91.25	
UCD-165 5.05	
UCD-062 2.95	
UCD-235 0.75	

Starting Point	Formula
5165 C	
UCD-TW 97.35	
UCD-129 2.00	
UCD-062 0.65	

Starting Point	Formula
5175 C	
UCD-TW 96.65	
UCD-165 1.65	
UCD-064 1.35	
UCD-235 0.35	

Starting Point	Formula
518 C	
UCD-165 60.95	
UCD-062 31.20	
UCD-230 7.85	

Starting Point	Formula
519 C	
UCD-165 64.85	
UCD-325 17.15	
UCD-MX 9.40	
UCD-062 8.60	

Starting Point	Formula
520 C	
UCD-165 55.00	
UCD-TW 17.95	
UCD-MX 15.00	
UCD-325 12.05	

Starting Point	Formula
521 C	
UCD-TW 70.10	
UCD-MX 15.00	
UCD-165 11.60	
UCD-062 1.80	
UCD-230 1.50	

Starting Point	Formula
522 C	
UCD-TW 76.85	
UCD-MX 15.00	
UCD-165 6.40	
UCD-230 0.95	
UCD-062 0.80	

Starting Point	Formula
523 C	
UCD-TW 95.40	
UCD-165 3.55	
UCD-235 0.55	
UCD-062 0.50	

Starting Point	Formula
524 C	
UCD-TW 85.55	
UCD-MX 12.20	
UCD-165 1.90	
UCD-235 0.35	

Starting Point	Formula
5185 C	
UCD-TW 40.00	
UCD-114 25.90	
UCD-127 19.75	
UCD-SB 14.35	

Starting Point	Formula
5195 C	
UCD-TW 55.40	
UCD-127 18.25	
UCD-114 17.15	
UCD-165 4.75	
UCD-SB 4.45	

Starting Point	Formula
5205 C	
UCD-TW 81.20	
UCD-114 8.50	
UCD-127 7.65	
UCD-325 2.65	

Starting Point	Formula
5215 C	
UCD-TW 92.85	
UCD-114 3.40	
UCD-127 2.45	
UCD-233 1.30	

Starting Point	Formula
5225 C	
UCD-TW 96.00	
UCD-066 2.10	
UCD-127 1.45	
UCD-233 0.45	

UviPak UCD

Starting Point	Formula
5235 C	
UCD-TW	97.50
UCD-066	1.30
UCD-127	0.90
UCD-233	0.30

Starting Point	Formula
5245 C	
UCD-TW	98.85
UCD-121	0.85
UCD-235	0.30

Starting Point	Formula
525 C	
UCD-165	62.50
UCD-TW	14.40
UCD-062	11.70
UCD-233	11.40

Starting Point	Formula
526 C	
UCD-165	54.55
UCD-TW	24.45
UCD-MX	15.00
UCD-235	6.00

Starting Point	Formula
527 C	
UCD-TW	51.55
UCD-165	20.62
UCD-127	12.37
UCD-MX	15.46

Starting Point	Formula
528 C	
UCD-TW	79.75
UCD-MX	15.00
UCD-127	5.25

Starting Point	Formula
529 C	
UCD-TW	82.75
UCD-MX	15.00
UCD-127	2.25

Starting Point	Formula
530 C	
UCD-TW	98.50
UCD-127	1.50

Starting Point	Formula
531 C	
UCD-TW	98.70
UCD-127	0.70
UCD-165	0.60

Starting Point	Formula
5255 C	
UCD-127	44.64
UCD-325	26.79
UCD-165	17.86
UCD-114	10.71

Starting Point	Formula
5265 C	
UCD-TW	48.70
UCD-164	22.95
UCD-235	20.80
UCD-127	7.55

Starting Point	Formula
5275 C	
UCD-TW	63.25
UCD-121	21.75
UCD-235	11.60
UCD-127	3.40

Starting Point	Formula
5285 C	
UCD-TW	83.05
UCD-064	9.85
UCD-127	4.85
UCD-230	2.25

Starting Point	Formula
5295 C	
UCD-TW	94.75
UCD-167	2.35
UCD-SB	1.85
UCD-235	1.05

Starting Point	Formula
5305 C	
UCD-TW	97.40
UCD-121	1.65
UCD-235	0.85
UCD-230	0.10

Starting Point	Formula
5315 C	
UCD-TW	99.02
UCD-SB	0.66
UCD-127	0.16
UCD-230	0.16

UviPak UCD

Starting Point	Formula
532 C	
UCD-121 46.15	
UCD-230 29.30	
UCD-MX 12.80	
UCD-062 11.75	

Starting Point	Formula
533 C	
UCD-325 47.30	
UCD-165 26.10	
UCD-129 15.20	
UCD-121 11.40	

Starting Point	Formula
534 C	
UCD-165 45.60	
UCD-325 40.05	
UCD-MX 14.00	
UCD-235 0.35	

Starting Point	Formula
535 C	
UCD-TW 88.20	
UCD-165 6.00	
UCD-062 3.25	
UCD-230 2.55	

Starting Point	Formula
536 C	
UCD-TW 77.80	
UCD-MX 15.00	
UCD-165 3.55	
UCD-062 2.00	
UCD-230 1.65	

Starting Point	Formula
537 C	
UCD-TW 96.60	
UCD-165 1.70	
UCD-230 0.90	
UCD-062 0.80	

Starting Point	Formula
538 C	
UCD-TW 98.30	
UCD-233 0.85	
UCD-165 0.50	
UCD-062 0.35	

Starting Point	Formula
539 C	
UCD-233 50.65	
UCD-230 36.90	
UCD-114 12.45	

Starting Point	Formula
540 C	
UCD-235 63.60	
UCD-129 21.10	
UCD-064 15.30	

Starting Point	Formula
541 C	
UCD-230 79.65	
UCD-MX 15.00	
UCD-164 5.35	

Starting Point	Formula
542 C	
UCD-TW 91.25	
UCD-235 4.45	
UCD-165 3.05	
UCD-062 1.25	

Starting Point	Formula
543 C	
UCD-TW 97.50	
UCD-235 1.50	
UCD-165 1.00	

Starting Point	Formula
544 C	
UCD-TW 98.80	
UCD-235 0.90	
UCD-127 0.30	

Starting Point	Formula
545 C	
UCD-TW 99.50	
UCD-230 0.30	
UCD-1278 0.20	

Starting Point	Formula
5395 C	
UCD-129 47.25	
UCD-SB 38.20	
UCD-233 14.55	

Starting Point	Formula
5405 C	
UCD-TW 54.65	
UCD-064 19.85	
UCD-165 13.95	
UCD-235 11.55	

UviPak UCD

Starting Point	Formula
5415 C	
UCD-TW 67.80	
UCD-064 11.60	
UCD-165 10.35	
UCD-235 5.85	
UCD-325 4.40	

Starting Point	Formula
5425 C	
UCD-TW 85.10	
UCD-062 6.25	
UCD-167 5.00	
UCD-235 3.65	

Starting Point	Formula
5435 C	
UCD-TW 93.85	
UCD-062 2.45	
UCD-165 2.20	
UCD-235 1.50	

Starting Point	Formula
5445 C	
UCD-TW 97.35	
UCD-129 1.25	
UCD-062 0.75	
UCD-230 0.65	

Starting Point	Formula
5455 C	
UCD-TW 98.55	
UCD-129 0.70	
UCD-230 0.45	
UCD-062 0.30	

Starting Point	Formula
546 C	
UCD-235 42.55	
UCD-064 31.50	
UCD-121 25.95	

Starting Point	Formula
547 C	
UCD-235 75.85	
UCD-066 24.15	

Starting Point	Formula
548 C	
UCD-235 61.25	
UCD-064 29.75	
UCD-SB 9.00	

Starting Point	Formula
549 C	
UCD-TW 86.25	
UCD-062 5.40	
UCD-235 4.60	
UCD-129 3.75	

Starting Point	Formula
550 C	
UCD-TW 93.70	
UCD-064 2.65	
UCD-235 2.40	
UCD-165 1.25	

Starting Point	Formula
551 C	
UCD-TW 96.65	
UCD-235 1.25	
UCD-062 1.25	
UCD-129 0.85	

Starting Point	Formula
552 C	
UCD-TW 98.25	
UCD-235 0.90	
UCD-064 0.70	
UCD-164 0.15	

Starting Point	Formula
5463 C	
UCD-235 44.60	
UCD-SB 41.50	
UCD-325 13.90	

Starting Point	Formula
5473 C	
UCD-TW 53.85	
UCD-230 29.85	
UCD-066 13.70	
UCD-164 2.60	

Starting Point	Formula
5483 C	
UCD-TW 81.60	
UCD-SB 7.35	
UCD-230 6.85	
UCD-064 4.20	

Starting Point	Formula
5493 C	
UCD-TW 88.75	
UCD-233 5.55	
UCD-064 5.55	
UCD-325 0.15	

UviPak UCD

Starting Point	Formula
5503 C	
UCD-TW 94.80	
UCD-064 2.50	
UCD-230 2.05	
UCD-164 0.65	

Starting Point	Formula
5513 C	
UCD-TW 97.20	
UCD-064 1.15	
UCD-230 1.00	
UCD-165 0.65	

Starting Point	Formula
5523 C	
UCD-TW 98.95	
UCD-230 0.55	
UCD-SB 0.50	

Starting Point	Formula
5467 C	
UCD-064 54.65	
UCD-230 26.00	
UCD-164 19.35	

Starting Point	Formula
5477 C	
UCD-TW 38.00	
UCD-062 34.10	
UCD-121 14.85	
UCD-235 13.05	

Starting Point	Formula
5487 C	
UCD-TW 58.35	
UCD-064 25.30	
UCD-165 9.80	
UCD-230 6.55	

Starting Point	Formula
5497 C	
UCD-TW 79.80	
UCD-064 12.35	
UCD-165 4.75	
UCD-230 3.10	

Starting Point	Formula
5507 C	
UCD-TW 90.25	
UCD-064 5.65	
UCD-165 2.45	
UCD-230 1.65	

Starting Point	Formula
5517 C	
UCD-TW 95.00	
UCD-064 2.75	
UCD-165 1.30	
UCD-230 0.95	

Starting Point	Formula
5527 C	
UCD-TW 97.60	
UCD-064 1.25	
UCD-233 0.90	
UCD-165 0.25	

Starting Point	Formula
553 C	
UCD-062 60.05	
UCD-129 15.90	
UCD-230 12.75	
UCD-121 11.30	

Starting Point	Formula
554 C	
UCD-062 58.25	
UCD-165 15.70	
UCD-MX 14.40	
UCD-235 11.65	

Starting Point	Formula
555 C	
UCD-062 52.90	
UCD-MX 15.00	
UCD-TW 13.65	
UCD-235 9.25	
UCD-165 9.20	

Starting Point	Formula
556 C	
UCD-TW 76.20	
UCD-062 17.60	
UCD-235 3.30	
UCD-165 2.90	

Starting Point	Formula
557 C	
UCD-TW 86.50	
UCD-062 10.00	
UCD-235 1.90	
UCD-165 1.60	

Starting Point	Formula
558 C	
UCD-TW 92.85	
UCD-062 5.20	
UCD-235 1.15	
UCD-165 0.80	

UviPak UCD

Starting Point	Formula
559 C	
UCD-TW 95.60	
UCD-062 3.30	
UCD-235 0.70	
UCD-165 0.40	

Starting Point	Formula
5535 C	
UCD-325 39.10	
UCD-233 30.70	
UCD-114 21.90	
UCD-TW 8.30	

Starting Point	Formula
5545 C	
UCD-TW 48.70	
UCD-325 34.35	
UCD-066 10.45	
UCD-164 6.50	

Starting Point	Formula
5555 C	
UCD-TW 67.10	
UCD-325 17.05	
UCD-165 8.20	
UCD-066 7.65	

Starting Point	Formula
5565 C	
UCD-TW 86.05	
UCD-SB 5.05	
UCD-325 4.95	
UCD-064 3.30	
UCD-165 0.65	

Starting Point	Formula
5575 C	
UCD-TW 92.60	
UCD-SB 3.60	
UCD-325 2.60	
UCD-062 1.20	

Starting Point	Formula
5585 C	
UCD-TW 94.50	
UCD-064 2.70	
UCD-325 2.25	
UCD-127 0.55	

Starting Point	Formula
5595 C	
UCD-TW 97.30	
UCD-066 1.33	
UCD-325 1.00	
UCD-127 0.37	

Starting Point	Formula
560 C	
UCD-325 68.35	
UCD-114 14.95	
UCD-127 8.45	
UCD-TW 8.25	

Starting Point	Formula
561 C	
UCD-325 53.70	
UCD-TW 28.30	
UCD-129 9.85	
UCD-114 8.15	

Starting Point	Formula
562 C	
UCD-TW 44.70	
UCD-325 43.60	
UCD-SB 11.70	

Starting Point	Formula
563 C	
UCD-TW 89.25	
UCD-325 7.90	
UCD-SB 2.85	

Starting Point	Formula
564 C	
UCD-TW 93.60	
UCD-325 5.55	
UCD-114 0.50	
UCD-127 0.35	

Starting Point	Formula
565 C	
UCD-TW 96.85	
UCD-325 2.85	
UCD-127 0.15	
UCD-114 0.15	

Starting Point	Formula
566 C	
UCD-TW 98.25	
UCD-325 1.55	
UCD-165 0.20	

Starting Point	Formula
5605 C	
UCD-SB 49.25	
UCD-062 44.95	
UCD-230 5.80	

UviPak UCD

Starting Point	Formula
5615 C	
UCD-064 38.40	
UCD-TW 27.15	
UCD-MX 15.00	
UCD-165 11.95	
UCD-230 7.50	

Starting Point	Formula
5625 C	
UCD-TW 55.75	
UCD-064 28.75	
UCD-165 8.05	
UCD-230 5.05	
UCD-MX 2.40	

Starting Point	Formula
5635 C	
UCD-TW 65.15	
UCD-MX 15.00	
UCD-064 13.35	
UCD-165 3.95	
UCD-230 2.55	

Starting Point	Formula
5645 C	
UCD-TW 88.55	
UCD-064 7.70	
UCD-165 2.25	
UCD-230 1.50	

Starting Point	Formula
5655 C	
UCD-TW 77.80	
UCD-MX 15.00	
UCD-064 4.80	
UCD-165 1.40	
UCD-230 1.00	

Starting Point	Formula
5665 C	
UCD-TW 95.05	
UCD-064 3.35	
UCD-165 0.90	
UCD-230 0.70	

Starting Point	Formula
567 C	
UCD-325 50.65	
UCD-SB 32.55	
UCD-TW 14.80	
UCD-114 2.00	

Starting Point	Formula
568 C	
UCD-325 61.40	
UCD-TW 29.95	
UCD-114 5.50	
UCD-127 3.05	
UCD-MX 0.10	

Starting Point	Formula
569 C	
UCD-325 44.20	
UCD-TW 35.50	
UCD-MX 15.00	
UCD-066 3.05	
UCD-127 2.25	

Starting Point	Formula
570 C	
UCD-TW 90.95	
UCD-325 8.40	
UCD-114 0.35	
UCD-127 0.30	

Starting Point	Formula
571 C	
UCD-TW 95.90	
UCD-325 3.90	
UCD-127 0.20	

Starting Point	Formula
572 C	
UCD-TW 97.20	
UCD-325 2.60	
UCD-129 0.20	

Starting Point	Formula
573 C	
UCD-TW 97.98	
UCD-325 1.44	
UCD-062 0.58	

Starting Point	Formula
574 C	
UCD-062 74.15	
UCD-SB 20.65	
UCD-235 4.10	
UCD-164 1.10	

Starting Point	Formula
575 C	
UCD-062 78.60	
UCD-TW 8.50	
UCD-233 7.50	
UCD-129 5.40	

Starting Point	Formula
576 C	
UCD-062 65.90	
UCD-MX 14.80	
UCD-TW 11.55	
UCD-165 3.80	
UCD-235 3.95	

UviPak UCD

Starting Point	Formula
577 C	
UCD-TW	79.50
UCD-062	18.50
UCD-235	1.10
UCD-165	0.90

Starting Point	Formula
578 C	
UCD-TW	84.35
UCD-062	14.15
UCD-165	0.65
UCD-235	0.85

Starting Point	Formula
579 C	
UCD-TW	88.10
UCD-062	10.85
UCD-235	0.60
UCD-165	0.45

Starting Point	Formula
580 C	
UCD-TW	93.40
UCD-062	5.95
UCD-233	0.65

Starting Point	Formula
5743 C	
UCD-062	68.65
UCD-SB	21.95
UCD-167	5.15
UCD-235	4.25

Starting Point	Formula
5753 C	
UCD-064	65.40
UCD-MX	15.00
UCD-167	12.30
UCD-230	7.30

Starting Point	Formula
5763 C	
UCD-064	58.75
UCD-TW	27.60
UCD-165	8.85
UCD-230	4.80

Starting Point	Formula
5773 C	
UCD-TW	48.80
UCD-064	33.55
UCD-MX	9.70
UCD-165	5.10
UCD-230	2.85

Starting Point	Formula
5783 C	
UCD-TW	78.15
UCD-064	17.80
UCD-233	2.60
UCD-165	1.45

Starting Point	Formula
5793 C	
UCD-TW	68.90
UCD-MX	15.00
UCD-064	12.90
UCD-165	2.00
UCD-230	1.20

Starting Point	Formula
5803 C	
UCD-TW	91.50
UCD-064	7.30
UCD-230	0.75
UCD-164	0.45

Starting Point	Formula
5747 C	
UCD-066	49.95
UCD-325	40.45
UCD-164	9.60

Starting Point	Formula
5757 C	
UCD-064	72.40
UCD-MX	12.15
UCD-325	10.90
UCD-127	4.55

Starting Point	Formula
5767 C	
UCD-064	51.80
UCD-TW	32.00
UCD-325	9.15
UCD-165	7.05

Starting Point	Formula
5777 C	
UCD-TW	59.30
UCD-064	31.25
UCD-325	5.40
UCD-165	4.05

Starting Point	Formula
5787 C	
UCD-TW	67.10
UCD-MX	15.00
UCD-064	13.20
UCD-325	2.75
UCD-165	1.95

UviPak UCD

Starting Point	Formula
5797 C	
UCD-TW 87.60	
UCD-064 10.85	
UCD-165 0.85	
UCD-230 0.70	

Starting Point	Formula
5807 C	
UCD-TW 95.10	
UCD-062 3.95	
UCD-SB 0.75	
UCD-233 0.20	

Starting Point	Formula
581 C	
UCD-062 73.35	
UCD-SB 24.85	
UCD-325 1.80	

Starting Point	Formula
582 C	
UCD-064 92.25	
UCD-121 4.15	
UCD-230 3.60	

Starting Point	Formula
583 C	
UCD-062 92.05	
UCD-MX 5.30	
UCD-235 1.45	
UCD-167 1.20	

Starting Point	Formula
584 C	
UCD-062 46.60	
UCD-TW 37.75	
UCD-MX 15.00	
UCD-235 0.40	
UCD-129 0.25	

Starting Point	Formula
585 C	
UCD-TW 71.15	
UCD-062 28.45	
UCD-230 0.25	
UCD-129 0.15	

Starting Point	Formula
586 C	
UCD-TW 79.45	
UCD-062 20.30	
UCD-233 0.25	

Starting Point	Formula
587 C	
UCD-TW 86.30	
UCD-062 13.60	
UCD-235 0.10	

Starting Point	Formula
5815 C	
UCD-062 64.60	
UCD-SB 33.25	
UCD-325 2.15	

Starting Point	Formula
5825 C	
UCD-062 71.65	
UCD-TW 14.75	
UCD-SB 13.60	

Starting Point	Formula
5835 C	
UCD-064 48.90	
UCD-TW 44.60	
UCD-121 4.05	
UCD-230 2.45	

Starting Point	Formula
5845 C	
UCD-TW 61.20	
UCD-062 33.15	
UCD-SB 4.80	
UCD-129 0.85	

Starting Point	Formula
5855 C	
UCD-TW 66.30	
UCD-064 16.20	
UCD-MX 15.00	
UCD-165 1.60	
UCD-230 0.90	

Starting Point	Formula
5865 C	
UCD-TW 75.25	
UCD-MX 15.00	
UCD-062 7.80	
UCD-SB 1.95	

Starting Point	Formula
5875 C	
UCD-TW 92.15	
UCD-062 6.55	
UCD-SB 1.20	
UCD-129 0.10	

UviPak UCD

Starting Point	Formula
600 C	
UCD-TW 77.35	
UCD-MX 15.00	
UCD-062 7.65	

Starting Point	Formula
601 C	
UCD-TW 74.10	
UCD-MX 15.00	
UCD-062 10.90	

Starting Point	Formula
602 C	
UCD-TW 83.20	
UCD-062 16.80	

Starting Point	Formula
603 C	
UCD-TW 58.60	
UCD-062 41.40	

Starting Point	Formula
604 C	
UCD-062 60.10	
UCD-TW 39.75	
UCD-129 0.10	
UCD-230 0.05	

Starting Point	Formula
605 C	
UCD-062 57.85	
UCD-064 41.65	
UCD-233 0.50	

Starting Point	Formula
606 C	
UCD-064 97.80	
UCD-325 1.45	
UCD-121 0.75	

Starting Point	Formula
607 C	
UCD-TW 90.85	
UCD-062 9.10	
UCD-127 0.05	

Starting Point	Formula
608 C	
UCD-TW 86.90	
UCD-062 12.80	
UCD-SB 0.30	

Starting Point	Formula
609 C	
UCD-TW 80.70	
UCD-062 18.95	
UCD-129 0.35	

Starting Point	Formula
610 C	
UCD-TW 65.10	
UCD-062 34.00	
UCD-SB 0.90	

Starting Point	Formula
611 C	
UCD-062 65.35	
UCD-TW 32.95	
UCD-SB 1.70	

Starting Point	Formula
612 C	
UCD-064 65.25	
UCD-062 29.65	
UCD-325 2.80	
UCD-165 2.30	

Starting Point	Formula
613 C	
UCD-064 92.90	
UCD-325 4.10	
UCD-121 3.00	

Starting Point	Formula
614 C	
UCD-TW 92.30	
UCD-062 6.85	
UCD-129 0.50	
UCD-066 0.20	
UCD-325 0.15	

Starting Point	Formula
615 C	
UCD-TW 87.95	
UCD-062 6.25	
UCD-064 4.90	
UCD-165 0.60	
UCD-235 0.30	

UviPak UCD

Starting Point	Formula
616 C	
UCD-TW 82.30	
UCD-062 16.05	
UCD-SB 1.15	
UCD-129 0.50	

Starting Point	Formula
617 C	
UCD-TW 71.05	
UCD-062 24.65	
UCD-066 2.05	
UCD-165 1.55	
UCD-235 0.70	

Starting Point	Formula
618 C	
UCD-TW 41.65	
UCD-064 29.65	
UCD-062 24.10	
UCD-233 2.35	
UCD-167 2.25	

Starting Point	Formula
619 C	
UCD-062 77.55	
UCD-TW 14.05	
UCD-SB 8.15	
UCD-164 0.25	

Starting Point	Formula
620 C	
UCD-062 76.60	
UCD-066 12.60	
UCD-121 6.85	
UCD-230 3.95	

Starting Point	Formula
621 C	
UCD-TW 98.10	
UCD-064 1.25	
UCD-230 0.50	
UCD-165 0.15	

Starting Point	Formula
622 C	
UCD-TW 95.05	
UCD-325 2.35	
UCD-064 2.15	
UCD-127 0.45	

Starting Point	Formula
623 C	
UCD-TW 89.20	
UCD-064 5.25	
UCD-325 4.55	
UCD-127 1.00	

Starting Point	Formula
624 C	
UCD-TW 81.75	
UCD-325 6.90	
UCD-SB 6.75	
UCD-062 4.40	
UCD-129 0.20	

Starting Point	Formula
625 C	
UCD-TW 61.20	
UCD-325 15.95	
UCD-SB 13.50	
UCD-062 9.35	

Starting Point	Formula
626 C	
UCD-325 61.05	
UCD-TW 25.20	
UCD-114 8.45	
UCD-164 5.30	

Starting Point	Formula
627 C	
UCD-325 47.50	
UCD-SB 47.30	
UCD-230 5.20	

Starting Point	Formula
628 C	
UCD-TW 99.25	
UCD-230 0.75	

Starting Point	Formula
629 C	
UCD-TW 98.65	
UCD-230 1.35	

Starting Point	Formula
630 C	
UCD-TW 97.20	
UCD-230 2.60	
UCD-114 0.20	

Starting Point	Formula
631 C	
UCD-TW 92.05	
UCD-230 6.30	
UCD-064 1.35	
UCD-SB 0.30	

UviPak UCD

Starting Point	Formula
632 C	
UCD-TW 68.20	
UCD-230 14.30	
UCD-MX 14.15	
UCD-064 3.35	

Starting Point	Formula
633 C	
UCD-TW 50.55	
UCD-230 34.85	
UCD-325 14.60	

Starting Point	Formula
634 C	
UCD-230 66.90	
UCD-325 19.20	
UCD-MX 13.90	

Starting Point	Formula
635 C	
UCD-TW 98.70	
UCD-230 1.30	

Starting Point	Formula
636 C	
UCD-TW 97.90	
UCD-230 2.10	

Starting Point	Formula
637 C	
UCD-TW 82.70	
UCD-MX 12.85	
UCD-230 4.45	

Starting Point	Formula
638 C	
UCD-TW 75.30	
UCD-MX 15.00	
UCD-230 9.70	

Starting Point	Formula
639 C	
UCD-TW 67.85	
UCD-230 17.15	
UCD-MX 15.00	

Starting Point	Formula
640 C	
UCD-TW 55.95	
UCD-230 29.05	
UCD-MX 15.00	

Starting Point	Formula
641 C	
UCD-TW 44.85	
UCD-230 40.15	
UCD-MX 15.00	

Starting Point	Formula
642 C	
UCD-TW 99.40	
UCD-235 0.40	
UCD-127 0.20	

Starting Point	Formula
643 C	
UCD-TW 98.50	
UCD-235 0.75	
UCD-165 0.75	

Starting Point	Formula
644 C	
UCD-TW 93.85	
UCD-165 2.60	
UCD-235 2.15	
UCD-062 1.40	

Starting Point	Formula
645 C	
UCD-TW 88.40	
UCD-165 4.85	
UCD-235 3.80	
UCD-062 2.95	

Starting Point	Formula
646 C	
UCD-TW 78.05	
UCD-235 8.10	
UCD-165 8.00	
UCD-064 5.85	

Starting Point	Formula
647 C	
UCD-TW 52.30	
UCD-235 24.25	
UCD-129 17.40	
UCD-064 6.05	

UviPak UCD

Starting Point	Formula
648 C	
UCD-235 60.95	
UCD-129 34.75	
UCD-114 4.30	

Starting Point	Formula
649 C	
UCD-TW 99.45	
UCD-235 0.35	
UCD-127 0.20	

Starting Point	Formula
650 C	
UCD-TW 99.10	
UCD-235 0.55	
UCD-127 0.35	

Starting Point	Formula
651 C	
UCD-TW 95.15	
UCD-165 2.25	
UCD-235 1.95	
UCD-066 0.65	

Starting Point	Formula
652 C	
UCD-TW 84.90	
UCD-165 6.00	
UCD-235 4.90	
UCD-064 4.20	

Starting Point	Formula
653 C	
UCD-TW 56.75	
UCD-235 19.80	
UCD-129 16.70	
UCD-064 6.75	

Starting Point	Formula
654 C	
UCD-235 55.80	
UCD-129 31.45	
UCD-064 12.75	

Starting Point	Formula
655 C	
UCD-233 79.70	
UCD-SB 20.30	

Starting Point	Formula
656 C	
UCD-TW 99.40	
UCD-235 0.40	
UCD-127 0.20	

Starting Point	Formula
657 C	
UCD-TW 99.00	
UCD-235 0.65	
UCD-127 0.35	

Starting Point	Formula
658 C	
UCD-TW 97.85	
UCD-235 1.40	
UCD-127 0.75	

Starting Point	Formula
659 C	
UCD-TW 76.60	
UCD-MX 15.00	
UCD-165 4.20	
UCD-235 4.20	

Starting Point	Formula
660 C	
UCD-TW 73.60	
UCD-235 15.80	
UCD-165 10.60	

Starting Point	Formula
661 C	
UCD-235 85.50	
UCD-MX 7.25	
UCD-127 7.25	

Starting Point	Formula
662 C	
UCD-233 77.60	
UCD-235 22.40	

Starting Point	Formula
663 C	
UCD-TW 99.50	
UCD-127 0.30	
UCD-235 0.20	

UviPak UCD

Starting Point	Formula
664 C	
UCD-TW 99.35	
UCD-127 0.50	
UCD-230 0.15	

Starting Point	Formula
665 C	
UCD-TW 82.30	
UCD-MX 15.00	
UCD-167 2.05	
UCD-235 0.65	

Starting Point	Formula
666 C	
UCD-TW 90.65	
UCD-064 5.10	
UCD-127 3.35	
UCD-235 0.90	

Starting Point	Formula
667 C	
UCD-TW 72.60	
UCD-167 18.30	
UCD-235 5.90	
UCD-114 3.20	

Starting Point	Formula
668 C	
UCD-TW 67.00	
UCD-121 17.25	
UCD-127 9.95	
UCD-235 5.80	

Starting Point	Formula
669 C	
UCD-127 26.75	
UCD-TW 23.05	
UCD-165 19.40	
UCD-SB 15.80	
UCD-MX 15.00	

Starting Point	Formula
670 C	
UCD-TW 98.00	
UCD-165 1.80	
UCD-325 0.20	

Starting Point	Formula
671 C	
UCD-TW 84.15	
UCD-MX 12.90	
UCD-165 2.50	
UCD-129 0.45	

Starting Point	Formula
672 C	
UCD-TW 91.55	
UCD-165 7.35	
UCD-062 0.75	
UCD-325 0.35	

Starting Point	Formula
673 C	
UCD-TW 84.50	
UCD-165 13.55	
UCD-062 1.70	
UCD-230 0.25	

Starting Point	Formula
674 C	
UCD-TW 56.55	
UCD-165 25.90	
UCD-MX 14.55	
UCD-062 2.25	
UCD-325 0.75	

Starting Point	Formula
675 C	
UCD-165 57.60	
UCD-TW 22.70	
UCD-MX 15.00	
UCD-062 3.45	
UCD-325 1.25	

Starting Point	Formula
676 C	
UCD-165 48.45	
UCD-167 42.85	
UCD-062 5.35	
UCD-325 3.35	

Starting Point	Formula
677 C	
UCD-TW 83.00	
UCD-MX 15.00	
UCD-165 1.65	
UCD-325 0.35	

Starting Point	Formula
678 C	
UCD-TW 82.90	
UCD-MX 15.00	
UCD-165 1.95	
UCD-235 0.15	

Starting Point	Formula
679 C	
UCD-TW 82.30	
UCD-MX 15.00	
UCD-165 2.50	
UCD-235 0.20	

UviPak UCD

Starting Point	Formula
680 C	
UCD-TW 87.75	
UCD-165 8.70	
UCD-062 3.00	
UCD-235 0.55	

Starting Point	Formula
681 C	
UCD-TW 60.10	
UCD-165 18.30	
UCD-MX 15.00	
UCD-062 5.65	
UCD-230 0.95	

Starting Point	Formula
682 C	
UCD-165 39.45	
UCD-TW 33.45	
UCD-MX 15.00	
UCD-062 8.10	
UCD-325 4.00	

Starting Point	Formula
683 C	
UCD-165 55.95	
UCD-064 18.15	
UCD-MX 15.00	
UCD-325 7.05	
UCD-TW 3.85	

Starting Point	Formula
684 C	
UCD-TW 97.65	
UCD-167 1.80	
UCD-114 0.35	
UCD-230 0.20	

Starting Point	Formula
685 C	
UCD-TW 96.45	
UCD-167 2.60	
UCD-SB 0.95	

Starting Point	Formula
686 C	
UCD-TW 96.35	
UCD-121 2.70	
UCD-127 0.95	

Starting Point	Formula
687 C	
UCD-TW 84.40	
UCD-167 11.70	
UCD-066 2.30	
UCD-233 1.60	

Starting Point	Formula
688 C	
UCD-TW 74.25	
UCD-167 20.25	
UCD-SB 5.50	

Starting Point	Formula
689 C	
UCD-TW 48.70	
UCD-167 42.40	
UCD-SB 8.90	

Starting Point	Formula
690 C	
UCD-167 71.35	
UCD-114 12.55	
UCD-TW 9.85	
UCD-230 6.25	

Starting Point	Formula
691 C	
UCD-TW 98.90	
UCD-165 1.00	
UCD-325 0.10	

Starting Point	Formula
692 C	
UCD-TW 98.05	
UCD-121 1.75	
UCD-235 0.20	

Starting Point	Formula
693 C	
UCD-TW 91.05	
UCD-167 4.65	
UCD-064 3.90	
UCD-230 0.40	

Starting Point	Formula
694 C	
UCD-TW 88.95	
UCD-121 7.85	
UCD-SB 3.20	

Starting Point	Formula
695 C	
UCD-TW 75.80	
UCD-167 14.90	
UCD-SB 5.50	
UCD-114 3.80	

UviPak UCD

Starting Point	Formula
696 C	
UCD-167	40.95
UCD-TW	28.75
UCD-MX	15.00
UCD-114	12.00
UCD-230	3.30

Starting Point	Formula
697 C	
UCD-167	47.60
UCD-TW	17.65
UCD-114	15.70
UCD-MX	15.00
UCD-230	4.05

Starting Point	Formula
698 C	
UCD-TW	98.95
UCD-165	1.05

Starting Point	Formula
699 C	
UCD-TW	97.35
UCD-167	2.05
UCD-064	0.60

Starting Point	Formula
700 C	
UCD-TW	93.85
UCD-167	4.75
UCD-066	1.15
UCD-325	0.25

Starting Point	Formula
701 C	
UCD-TW	70.40
UCD-MX	15.00
UCD-167	11.05
UCD-066	2.85
UCD-325	0.70

Starting Point	Formula
702 C	
UCD-TW	53.35
UCD-167	25.35
UCD-MX	15.00
UCD-114	4.80
UCD-325	1.50

Starting Point	Formula
703 C	
UCD-167	51.70
UCD-TW	22.40
UCD-MX	15.00
UCD-114	8.15
UCD-325	2.75

Starting Point	Formula
704 C	
UCD-167	66.45
UCD-MX	14.50
UCD-114	13.90
UCD-325	5.15

Starting Point	Formula
705 C	
UCD-TW	98.95
UCD-165	1.05

Starting Point	Formula
706 C	
UCD-TW	97.95
UCD-167	1.90
UCD-114	0.15

Starting Point	Formula
707 C	
UCD-TW	94.40
UCD-167	4.60
UCD-066	1.00

Starting Point	Formula
708 C	
UCD-TW	73.60
UCD-MX	15.00
UCD-167	9.55
UCD-114	1.85

Starting Point	Formula
709 C	
UCD-TW	72.15
UCD-167	23.40
UCD-114	4.45

Starting Point	Formula
710 C	
UCD-167	41.05
UCD-TW	36.65
UCD-MX	15.00
UCD-114	7.00
UCD-325	0.30

Starting Point	Formula
711 C	
UCD-167	58.40
UCD-062	25.80
UCD-MX	15.00
UCD-325	0.80

UviPak UCD

Starting Point	Formula
712 C	
UCD-TW 95.55	
UCD-114 2.50	
UCD-064 1.95	

Starting Point	Formula
713 C	
UCD-TW 92.30	
UCD-114 3.95	
UCD-064 3.65	
UCD-SB 0.10	

Starting Point	Formula
714 C	
UCD-TW 82.10	
UCD-064 9.85	
UCD-114 7.75	
UCD-SB 0.30	

Starting Point	Formula
715 C	
UCD-TW 59.70	
UCD-114 15.90	
UCD-064 15.50	
UCD-066 8.55	
UCD-233 0.35	

Starting Point	Formula
716 C	
UCD-066 41.40	
UCD-TW 31.35	
UCD-114 26.60	
UCD-233 0.65	

Starting Point	Formula
717 C	
UCD-114 47.20	
UCD-062 36.50	
UCD-MX 15.00	
UCD-233 1.30	

Starting Point	Formula
718 C	
UCD-114 84.05	
UCD-MX 12.50	
UCD-325 3.45	

Starting Point	Formula
719 C	
UCD-TW 96.65	
UCD-066 2.30	
UCD-167 0.75	
UCD-SB 0.30	

Starting Point	Formula
720 C	
UCD-TW 93.65	
UCD-114 2.75	
UCD-064 2.65	
UCD-SB 0.95	

Starting Point	Formula
721 C	
UCD-TW 85.60	
UCD-064 8.35	
UCD-114 5.30	
UCD-127 0.45	
UCD-230 0.30	

Starting Point	Formula
722 C	
UCD-TW 71.10	
UCD-066 13.20	
UCD-114 12.05	
UCD-SB 3.65	

Starting Point	Formula
723 C	
UCD-TW 42.60	
UCD-066 28.90	
UCD-114 22.50	
UCD-SB 6.00	

Starting Point	Formula
724 C	
UCD-114 39.30	
UCD-066 33.80	
UCD-MX 15.00	
UCD-SB 11.90	

Starting Point	Formula
725 C	
UCD-114 80.20	
UCD-MX 14.20	
UCD-230 5.60	

Starting Point	Formula
726 C	
UCD-TW 96.20	
UCD-066 2.60	
UCD-121 0.95	
UCD-230 0.25	

Starting Point	Formula
727 C	
UCD-TW 92.00	
UCD-066 5.15	
UCD-SB 1.55	
UCD-167 1.30	

UviPak UCD

Starting Point	Formula
728 C	
UCD-TW 85.55	
UCD-066 10.15	
UCD-167 3.15	
UCD-233 1.15	

Starting Point	Formula
729 C	
UCD-TW 70.35	
UCD-064 14.00	
UCD-114 10.35	
UCD-SB 5.30	

Starting Point	Formula
730 C	
UCD-TW 48.60	
UCD-066 29.80	
UCD-114 16.65	
UCD-230 2.50	
UCD-164 2.45	

Starting Point	Formula
731 C	
UCD-114 73.95	
UCD-064 15.70	
UCD-233 10.35	

Starting Point	Formula
732 C	
UCD-114 89.95	
UCD-230 10.05	

Starting Point	Formula
7401 C	
UCD-TW 96.10	
UCD-064 3.90	

Starting Point	Formula
7402 C	
UCD-TW 88.80	
UCD-062 10.90	
UCD-164 0.30	

Starting Point	Formula
7403 C	
UCD-TW 74.15	
UCD-062 24.25	
UCD-165 1.55	
UCD-230 0.05	

Starting Point	Formula
7404 C	
UCD-062 75.85	
UCD-TW 23.30	
UCD-167 0.85	

Starting Point	Formula
7405 C	
UCD-062 64.80	
UCD-064 26.80	
UCD-TW 6.95	
UCD-121 1.00	
UCD-325 0.45	

Starting Point	Formula
7406 C	
UCD-064 69.95	
UCD-062 27.80	
UCD-167 1.70	
UCD-325 0.55	

Starting Point	Formula
7407 C	
UCD-064 45.40	
UCD-TW 43.45	
UCD-121 4.65	
UCD-066 4.10	
UCD-325 2.40	

Starting Point	Formula
7408 C	
UCD-062 87.30	
UCD-TW 8.15	
UCD-114 2.85	
UCD-165 1.55	
UCD-325 0.15	

Starting Point	Formula
7409 C	
UCD-062 89.55	
UCD-TW 8.85	
UCD-164 1.60	

Starting Point	Formula
7410 C	
UCD-TW 86.05	
UCD-114 9.25	
UCD-066 4.30	
UCD-129 0.40	

Starting Point	Formula
7411 C	
UCD-TW 47.10	
UCD-062 46.60	
UCD-165 6.20	
UCD-230 0.10	

UviPak UCD

Starting Point	Formula
7412 C	
UCD-TW 39.65	
UCD-064 33.05	
UCD-114 25.50	
UCD-233 1.80	

Starting Point	Formula
7413 C	
UCD-062 83.20	
UCD-165 9.55	
UCD-MX 5.20	
UCD-129 2.05	

Starting Point	Formula
7414 C	
UCD-066 51.35	
UCD-114 23.45	
UCD-TW 17.90	
UCD-SB 5.95	
UCD-167 1.35	

Starting Point	Formula
7415 C	
UCD-TW 86.85	
UCD-062 9.30	
UCD-165 3.50	
UCD-129 0.35	

Starting Point	Formula
7416 C	
UCD-062 49.95	
UCD-TW 41.45	
UCD-164 8.60	

Starting Point	Formula
7417 C	
UCD-062 67.75	
UCD-TW 20.40	
UCD-164 11.85	

Starting Point	Formula
7418 C	
UCD-TW 34.85	
UCD-167 34.50	
UCD-MX 15.00	
UCD-114 13.35	
UCD-325 2.30	

Starting Point	Formula
7419 C	
UCD-TW 45.75	
UCD-167 38.05	
UCD-114 13.35	
UCD-233 2.85	

Starting Point	Formula
7420 C	
UCD-167 69.05	
UCD-064 27.55	
UCD-233 3.40	

Starting Point	Formula
7421 C	
UCD-167 66.65	
UCD-SB 16.75	
UCD-114 14.80	
UCD-235 1.80	

Starting Point	Formula
7422 C	
UCD-TW 84.05	
UCD-MX 14.75	
UCD-167 1.20	

Starting Point	Formula
7423 C	
UCD-TW 59.80	
UCD-167 22.00	
UCD-MX 15.00	
UCD-114 2.95	
UCD-235 0.25	

Starting Point	Formula
7424 C	
UCD-167 53.00	
UCD-TW 46.60	
UCD-SB 0.40	

Starting Point	Formula
7425 C	
UCD-167 61.65	
UCD-TW 17.75	
UCD-MX 15.00	
UCD-114 4.15	
UCD-233 1.45	

Starting Point	Formula
7426 C	
UCD-167 78.75	
UCD-TW 11.55	
UCD-066 8.55	
UCD-230 1.15	

Starting Point	Formula
7427 C	
UCD-165 37.40	
UCD-062 31.80	
UCD-121 25.50	
UCD-SB 5.30	

UviPak UCD

Starting Point	Formula
7428 C	
UCD-165 59.25	
UCD-062 36.65	
UCD-230 4.10	

Starting Point	Formula
7429 C	
UCD-TW 96.25	
UCD-165 2.60	
UCD-062 0.95	
UCD-233 0.20	

Starting Point	Formula
7430 C	
UCD-TW 92.65	
UCD-165 4.95	
UCD-062 2.15	
UCD-235 0.25	

Starting Point	Formula
7431 C	
UCD-TW 80.05	
UCD-165 13.25	
UCD-062 6.25	
UCD-230 0.45	

Starting Point	Formula
7432 C	
UCD-TW 84.65	
UCD-164 13.60	
UCD-233 1.75	

Starting Point	Formula
7433 C	
UCD-165 45.80	
UCD-TW 23.55	
UCD-MX 15.00	
UCD-062 13.50	
UCD-325 2.15	

Starting Point	Formula
7434 C	
UCD-165 56.70	
UCD-062 19.40	
UCD-MX 15.00	
UCD-TW 5.20	
UCD-325 3.70	

Starting Point	Formula
7435 C	
UCD-165 73.60	
UCD-062 20.70	
UCD-325 5.70	

Starting Point	Formula
7436 C	
UCD-TW 99.45	
UCD-127 0.55	

Starting Point	Formula
7437 C	
UCD-TW 95.10	
UCD-165 3.90	
UCD-062 0.50	
UCD-235 0.50	

Starting Point	Formula
7438 C	
UCD-TW 92.60	
UCD-165 5.65	
UCD-127 1.75	

Starting Point	Formula
7439 C	
UCD-TW 86.90	
UCD-165 9.40	
UCD-233 1.90	
UCD-062 1.80	

Starting Point	Formula
7440 C	
UCD-TW 77.95	
UCD-165 15.95	
UCD-062 4.30	
UCD-235 1.80	

Starting Point	Formula
7441 C	
UCD-TW 74.90	
UCD-MX 15.00	
UCD-127 10.10	

Starting Point	Formula
7442 C	
UCD-TW 66.95	
UCD-127 18.05	
UCD-MX 15.00	

Starting Point	Formula
7443 C	
UCD-TW 99.45	
UCD-127 0.30	
UCD-235 0.25	

UviPak UCD

Starting Point	Formula
7444 C	
UCD-TW 98.40	
UCD-127 0.95	
UCD-235 0.65	

Starting Point	Formula
7445 C	
UCD-TW 94.95	
UCD-064 2.10	
UCD-127 1.95	
UCD-235 1.00	

Starting Point	Formula
7446 C	
UCD-TW 74.15	
UCD-MX 15.00	
UCD-165 8.15	
UCD-235 2.70	

Starting Point	Formula
7447 C	
UCD-TW 68.10	
UCD-164 14.65	
UCD-127 8.80	
UCD-235 8.45	

Starting Point	Formula
7448 C	
UCD-121 45.65	
UCD-TW 35.90	
UCD-235 14.20	
UCD-127 4.25	

Starting Point	Formula
7449 C	
UCD-164 55.90	
UCD-233 23.90	
UCD-TW 20.20	

Starting Point	Formula
7450 C	
UCD-TW 97.85	
UCD-165 1.40	
UCD-235 0.75	

Starting Point	Formula
7451 C	
UCD-TW 96.40	
UCD-235 2.30	
UCD-127 1.30	

Starting Point	Formula
7452 C	
UCD-TW 93.45	
UCD-127 3.55	
UCD-230 3.00	

Starting Point	Formula
7453 C	
UCD-TW 82.55	
UCD-MX 13.10	
UCD-235 3.05	
UCD-127 1.30	

Starting Point	Formula
7454 C	
UCD-TW 85.70	
UCD-235 5.30	
UCD-165 4.55	
UCD-064 4.45	

Starting Point	Formula
7455 C	
UCD-TW 69.65	
UCD-165 17.40	
UCD-235 12.95	

Starting Point	Formula
7456 C	
UCD-TW 81.30	
UCD-165 12.05	
UCD-235 5.60	
UCD-SB 1.05	

Starting Point	Formula
7457 C	
UCD-TW 99.40	
UCD-235 0.60	

Starting Point	Formula
7458 C	
UCD-TW 94.55	
UCD-235 2.80	
UCD-325 1.65	
UCD-121 1.00	

Starting Point	Formula
7459 C	
UCD-TW 84.15	
UCD-230 8.90	
UCD-064 3.60	
UCD-129 3.35	

UviPak UCD

Starting Point	Formula
7460 C	
UCD-TW 62.00	
UCD-230 23.00	
UCD-MX 15.00	

Starting Point	Formula
7461 C	
UCD-TW 74.50	
UCD-230 24.65	
UCD-164 0.85	

Starting Point	Formula
7462 C	
UCD-TW 47.05	
UCD-235 26.30	
UCD-233 17.60	
UCD-064 9.05	

Starting Point	Formula
7463 C	
UCD-233 70.65	
UCD-064 27.10	
UCD-235 2.25	

Starting Point	Formula
7464 C	
UCD-TW 81.90	
UCD-MX 15.00	
UCD-064 1.60	
UCD-230 1.50	

Starting Point	Formula
7465 C	
UCD-TW 85.90	
UCD-325 10.40	
UCD-064 1.90	
UCD-235 1.80	

Starting Point	Formula
7466 C	
UCD-TW 59.70	
UCD-325 16.95	
UCD-MX 15.00	
UCD-230 8.35	

Starting Point	Formula
7467 C	
UCD-TW 53.85	
UCD-325 20.90	
UCD-MX 15.00	
UCD-230 10.25	

Starting Point	Formula
7468 C	
UCD-TW 64.25	
UCD-230 32.60	
UCD-114 3.15	

Starting Point	Formula
7469 C	
UCD-230 59.10	
UCD-TW 33.55	
UCD-066 4.80	
UCD-MX 2.55	

Starting Point	Formula
7470 C	
UCD-TW 37.50	
UCD-235 34.95	
UCD-064 25.60	
UCD-129 1.95	

Starting Point	Formula
7471 C	
UCD-TW 94.25	
UCD-325 4.95	
UCD-230 0.80	

Starting Point	Formula
7472 C	
UCD-TW 88.75	
UCD-325 4.15	
UCD-064 4.05	
UCD-235 2.80	
UCD-165 0.25	

Starting Point	Formula
7473 C	
UCD-TW 72.00	
UCD-064 17.55	
UCD-230 9.25	
UCD-233 1.20	

Starting Point	Formula
7474 C	
UCD-TW 46.05	
UCD-230 24.05	
UCD-MX 15.00	
UCD-325 9.05	
UCD-066 5.85	

Starting Point	Formula
7475 C	
UCD-TW 70.95	
UCD-064 10.25	
UCD-SB 9.85	
UCD-230 8.95	

UviPak UCD

Starting Point	Formula
7476 C	
UCD-230	38.50
UCD-TW	24.25
UCD-066	19.60
UCD-MX	15.00
UCD-127	2.65

Starting Point	Formula
7477 C	
UCD-233	40.10
UCD-064	30.65
UCD-TW	29.25

Starting Point	Formula
7478 C	
UCD-TW	79.35
UCD-MX	15.00
UCD-325	3.60
UCD-062	2.05

Starting Point	Formula
7479 C	
UCD-TW	58.10
UCD-062	16.25
UCD-325	13.80
UCD-MX	11.85

Starting Point	Formula
7480 C	
UCD-TW	40.70
UCD-325	25.60
UCD-062	18.70
UCD-MX	15.00

Starting Point	Formula
7481 C	
UCD-062	35.40
UCD-325	30.20
UCD-TW	19.40
UCD-MX	15.00

Starting Point	Formula
7482 C	
UCD-062	48.70
UCD-TW	31.80
UCD-325	11.85
UCD-230	7.65

Starting Point	Formula
7483 C	
UCD-062	37.95
UCD-325	27.30
UCD-SB	18.95
UCD-TW	15.80

Starting Point	Formula
7484 C	
UCD-325	71.85
UCD-066	11.30
UCD-TW	10.60
UCD-164	6.25

Starting Point	Formula
7485 C	
UCD-TW	98.45
UCD-062	0.95
UCD-325	0.60

Starting Point	Formula
7486 C	
UCD-TW	90.65
UCD-062	7.65
UCD-325	1.60
UCD-SB	0.10

Starting Point	Formula
7487 C	
UCD-TW	57.50
UCD-062	23.10
UCD-MX	15.00
UCD-325	4.40

Starting Point	Formula
7488 C	
UCD-TW	41.35
UCD-062	40.10
UCD-MX	10.95
UCD-325	7.60

Starting Point	Formula
7489 C	
UCD-TW	46.65
UCD-062	32.20
UCD-064	16.20
UCD-230	3.65
UCD-165	1.30

Starting Point	Formula
7490 C	
UCD-062	76.80
UCD-TW	16.00
UCD-235	3.90
UCD-165	3.30

Starting Point	Formula
7491 C	
UCD-064	40.90
UCD-062	26.95
UCD-TW	22.90
UCD-121	4.70
UCD-230	4.55

UviPak UCD

Starting Point	Formula
7492 C	
UCD-TW 82.80	
UCD-062 16.00	
UCD-129 0.80	
UCD-230 0.40	

Starting Point	Formula
7493 C	
UCD-TW 84.75	
UCD-064 9.65	
UCD-062 3.40	
UCD-165 1.20	
UCD-230 1.00	

Starting Point	Formula
7494 C	
UCD-TW 80.70	
UCD-064 12.15	
UCD-325 5.75	
UCD-164 1.40	

Starting Point	Formula
7495 C	
UCD-062 68.80	
UCD-TW 24.60	
UCD-SB 5.40	
UCD-235 1.20	

Starting Point	Formula
7496 C	
UCD-064 78.20	
UCD-325 15.95	
UCD-121 5.85	

Starting Point	Formula
7497 C	
UCD-TW 46.80	
UCD-064 33.55	
UCD-SB 18.45	
UCD-165 1.20	

Starting Point	Formula
7498 C	
UCD-064 52.65	
UCD-062 23.45	
UCD-233 14.65	
UCD-121 9.25	

Starting Point	Formula
7499 C	
UCD-TW 97.10	
UCD-062 2.90	

Starting Point	Formula
7500 C	
UCD-TW 94.60	
UCD-064 4.55	
UCD-325 0.55	
UCD-164 0.30	

Starting Point	Formula
7501 C	
UCD-TW 91.35	
UCD-064 6.65	
UCD-165 1.20	
UCD-325 0.80	

Starting Point	Formula
7502 C	
UCD-TW 86.05	
UCD-064 11.70	
UCD-325 1.30	
UCD-164 0.95	

Starting Point	Formula
7503 C	
UCD-TW 62.40	
UCD-062 30.50	
UCD-165 5.70	
UCD-235 1.40	

Starting Point	Formula
7504 C	
UCD-064 42.35	
UCD-TW 41.85	
UCD-167 12.65	
UCD-230 3.15	

Starting Point	Formula
7505 C	
UCD-TW 44.70	
UCD-066 37.40	
UCD-325 9.70	
UCD-164 7.75	
UCD-235 0.45	

Starting Point	Formula
7506 C	
UCD-TW 95.70	
UCD-062 3.70	
UCD-167 0.60	

Starting Point	Formula
7507 C	
UCD-TW 93.80	
UCD-064 4.95	
UCD-114 1.25	

UviPak UCD

Starting Point	Formula
7508 C	
UCD-TW 83.15	
UCD-064 14.70	
UCD-121 1.15	
UCD-SB 1.00	

Starting Point	Formula
7509 C	
UCD-TW 69.00	
UCD-064 25.55	
UCD-121 3.00	
UCD-325 1.40	
UCD-114 1.05	

Starting Point	Formula
7510 C	
UCD-TW 40.75	
UCD-062 34.90	
UCD-066 15.65	
UCD-165 6.60	
UCD-325 2.10	

Starting Point	Formula
7511 C	
UCD-062 73.50	
UCD-114 10.05	
UCD-TW 8.45	
UCD-167 6.35	
UCD-230 1.65	

Starting Point	Formula
7512 C	
UCD-062 72.70	
UCD-114 17.85	
UCD-121 6.85	
UCD-230 2.60	

Starting Point	Formula
7513 C	
UCD-TW 93.85	
UCD-066 3.45	
UCD-167 2.25	
UCD-233 0.45	

Starting Point	Formula
7514 C	
UCD-TW 87.20	
UCD-066 7.35	
UCD-165 4.30	
UCD-325 1.15	

Starting Point	Formula
7515 C	
UCD-TW 76.60	
UCD-066 15.35	
UCD-167 7.05	
UCD-230 1.00	

Starting Point	Formula
7516 C	
UCD-064 30.75	
UCD-114 27.50	
UCD-TW 26.50	
UCD-SB 10.00	
UCD-121 5.25	

Starting Point	Formula
7517 C	
UCD-062 41.25	
UCD-114 23.65	
UCD-MX 14.55	
UCD-167 13.50	
UCD-233 7.05	

Starting Point	Formula
7518 C	
UCD-TW 45.75	
UCD-SB 23.10	
UCD-066 17.70	
UCD-121 13.45	

Starting Point	Formula
7519 C	
UCD-064 37.50	
UCD-TW 27.75	
UCD-SB 24.30	
UCD-165 10.45	

Starting Point	Formula
7520 C	
UCD-TW 95.40	
UCD-066 2.15	
UCD-167 1.90	
UCD-SB 0.55	

Starting Point	Formula
7521 C	
UCD-TW 79.80	
UCD-062 13.65	
UCD-165 5.95	
UCD-235 0.60	

Starting Point	Formula
7522 C	
UCD-062 41.80	
UCD-TW 39.15	
UCD-165 18.15	
UCD-230 0.90	

Starting Point	Formula
7523 C	
UCD-TW 58.00	
UCD-066 18.90	
UCD-167 14.45	
UCD-325 4.60	
UCD-164 4.05	

UviPak UCD

Starting Point	Formula
7524 C	
UCD-TW 46.35	
UCD-121 27.85	
UCD-066 20.65	
UCD-325 4.95	
UCD-235 0.20	

Starting Point	Formula
7525 C	
UCD-062 49.05	
UCD-TW 30.30	
UCD-165 13.10	
UCD-129 4.50	
UCD-325 3.05	

Starting Point	Formula
7526 C	
UCD-114 34.45	
UCD-064 21.00	
UCD-165 20.70	
UCD-MX 15.00	
UCD-325 8.85	

Starting Point	Formula
7527 C	
UCD-TW 97.35	
UCD-064 1.75	
UCD-167 0.60	
UCD-235 0.30	

Starting Point	Formula
7528 C	
UCD-TW 96.65	
UCD-066 1.80	
UCD-233 1.05	
UCD-164 0.50	

Starting Point	Formula
7529 C	
UCD-TW 94.50	
UCD-066 3.20	
UCD-164 1.25	
UCD-230 1.05	

Starting Point	Formula
7530 C	
UCD-TW 88.75	
UCD-066 7.00	
UCD-164 2.35	
UCD-230 1.90	

Starting Point	Formula
7531 C	
UCD-TW 62.00	
UCD-066 21.25	
UCD-167 9.60	
UCD-233 7.15	

Starting Point	Formula
7532 C	
UCD-TW 39.10	
UCD-SB 25.85	
UCD-066 25.85	
UCD-165 6.50	
UCD-062 2.70	

Starting Point	Formula
7533 C	
UCD-SB 41.65	
UCD-066 36.60	
UCD-TW 15.55	
UCD-167 6.20	

Starting Point	Formula
7534 C	
UCD-TW 97.00	
UCD-064 2.15	
UCD-233 0.60	
UCD-164 0.25	

Starting Point	Formula
7535 C	
UCD-TW 87.15	
UCD-064 9.05	
UCD-167 2.00	
UCD-233 1.80	

Starting Point	Formula
7536 C	
UCD-TW 82.15	
UCD-064 11.10	
UCD-SB 4.70	
UCD-165 1.55	
UCD-230 0.50	

Starting Point	Formula
7537 C	
UCD-TW 93.05	
UCD-SB 4.65	
UCD-062 2.00	
UCD-230 0.30	

Starting Point	Formula
7538 C	
UCD-TW 87.45	
UCD-SB 6.20	
UCD-064 5.05	
UCD-233 1.30	

Starting Point	Formula
7539 C	
UCD-TW 89.30	
UCD-066 5.60	
UCD-230 2.80	
UCD-164 2.30	

UviPak UCD

Starting Point	Formula
7540 C	
UCD-TW 49.30	
UCD-064 37.05	
UCD-127 8.70	
UCD-230 4.95	

Starting Point	Formula
7541 C	
UCD-TW 99.60	
UCD-235 0.40	

Starting Point	Formula
7542 C	
UCD-TW 94.60	
UCD-062 2.45	
UCD-167 1.60	
UCD-235 1.35	

Starting Point	Formula
7543 C	
UCD-TW 92.30	
UCD-064 3.80	
UCD-233 3.00	
UCD-164 0.90	

Starting Point	Formula
7544 C	
UCD-TW 85.05	
UCD-064 7.80	
UCD-233 5.45	
UCD-164 1.70	

Starting Point	Formula
7545 C	
UCD-TW 55.20	
UCD-064 22.25	
UCD-233 17.35	
UCD-164 5.20	

Starting Point	Formula
7546 C	
UCD-TW 39.05	
UCD-121 26.95	
UCD-235 17.45	
UCD-062 16.55	

Starting Point	Formula
7547 C	
UCD-121 48.50	
UCD-235 32.40	
UCD-064 12.25	
UCD-MX 6.85	