

DIRASOL RAPID

Diazo Sensitized Direct Emulsion

Features

- ▶ Fast Drying
- ▶ Humidity Resistant
- ▶ Fast Exposure Speed
- ▶ Wide Exposure Latitude
- ▶ Excellent Solvent and U.V. Ink Resistance
- ▶ Outstanding Mechanical/ Abrasion Resistance
- ▶ Easily Reclaimed
- ▶ Economical
- ▶ Solids Content (sensitized) 29%
- ▶ Sensitized viscosity at 77°F: 6,000 mPas

Application

Graphic Printing

Industrial Printing

Textile Printing

DIRASOL RAPID

Diazo Sensitized Direct Emulsion

Safelighting

Dirasol Rapid is a light green emulsion, and is sensitive to light once the diazo is added. Handling of Dirasol Rapid must be carried out in light of low blue and UV content. A photographic safelight is not essential, but it is suggested to use yellow safe lighting. The preferred form of light for the workroom is yellow fluorescent tubes. Daylight must be excluded or filtered by a yellow or UV spectrum filtering film applied over the windows.

Sensitizer Mixing Instructions

The diazo sensitizer must be added prior to use. Fill the sensitizer bottle to the shoulder or approximately 3/4 full with warm distilled water. Seal the lid tightly and shake vigorously to disperse completely.

Add to emulsion and mix thoroughly. Let the sensitized emulsion stand for one to two hours to degas.

Preparing the Screen

Degrease using Xtend Mesh Preps. Wet the screen and apply with a soft bristle brush, rubbing the mesh with a light circular motion. Ensure that both sides of the screen are thoroughly treated. Let stand for a minute and rinse with cold water to remove all traces of the mesh prep. Xtend™ Mesh Preps not only degrease the mesh but also enhance emulsion adhesion. Allow the mesh to dry before coating.

Automatic Coating

When using an automatic coating machine, apply a simultaneous single coat to each side of the screen, followed by a second coat in the same manner. If a higher build is required, extra coats should be applied to the squeegee side of the screen, or dried first, then an additional coat applied to the print or substrate side of the screen.

Hand Coating

Stand the screen on edge slightly inclined away from the operator and process the screen as follows:

Depending on the stencil build required, apply two coats, wet on wet, to the print side of the screen followed by two coats applied, wet on wet, to the squeegee side of the screen. The use of the Sericol Coating Trough is particularly recommended. Troughs made of mild steel, copper, or zinc should not be used.

Drying

The coated screen must be dried in darkness, safelight, or subdued yellow light, ideally in a horizontal position, squeegee side up. A warm air fan or heated cabinet up to 100°F (38°C) may be used but care should be taken not to blow dust on the drying screen. For maximum stencil durability, the screen must be thoroughly dry before exposure. Dried Dirasol Rapid screens may be stored in the dark at cool room temperatures for up to one month prior to exposure.

Exposure

Correct exposure time is essential to obtain optimum definition/resolution and stencil life. Determine the proper exposure time using the Dirasol Exposure Calculator. The correct exposure is the longest exposure time that can be given while still obtaining optimum stencil resolution and print definition and which results in no color change between the chosen exposure factor and the surrounding emulsion. The following guide can be used as the basis of an initial test exposure.

DIRASOL RAPID

Diazo Sensitized Direct Emulsion

EXPOSURE GUIDE

305.40 (120 cm) white mesh (2+2 coats)

	CM	INCHES	SECONDS
50 Amp Open Carbon Arc	120	48	360 – 420
1000W Metal Halide	120	48	180 – 220
2000W Metal Halide	120	48	90 – 110
3000W Metal Halide	120	48	55 – 75
5000W Metal Halide	120	48	35 – 45
6000W Metal Halide	120	48	30 – 40

The exposure values quoted are estimated times required to fully cure and completely harden the sensitized emulsion on a 305.40 white monofilament polyester mesh screen, using a 2+2 coating technique.

These through-cure exposure values prevent emulsion being washed away from the inside of the stencil during development and ensure stencils of optimum definition, durability, and reclaimability. Where the prime requirement is stencil resolution, the exposure time may be slightly reduced.

Multifilament, stainless steel, different colored mesh, and multicoat stencils may require longer exposure; white mesh requires a shorter exposure.

Factors Affecting Exposure Times

- Light source and age of bulb.
- Distance from light source to screen.
- Transparency of the background of the positive.
- Mesh count and/or color and coating technique.

Developing

Gently spray both sides with cool or warm water (not above 105°F/40°C). After one or two minutes, the spray pressure can be increased slightly. Continue developing until all parts of the image appear clean and sharp. With thick, heavily coated stencils, let them stand for additional time before beginning spray development.

Final Drying and Touch Up

Dry the stencil using a warm air fan. Small blemishes or pinholes, usually caused by dust specks or spots on the positive, can be touched up with a brush containing Dirasol Rapid Emulsion or Xtend™ Blockout. After drying and touch up, the screen is ready for printing.

Reclaiming the Screen

In automatic screen cleaning machines or by hand, remove all traces of ink with Xtend™ Ink Degradant. Rinse the screen with water and apply Xtend™ Stencil Remover to both sides of the stencil. Let stand for one to three minutes. Remove the stencil with a strong waterjet or high pressure washer.

Safety and Handling

Diazo sensitizer: diazo sensitizer is acidic. Contact with eyes and skin should be avoided; if splashes do occur, the affected area should be washed thoroughly with water. Normal industrial practices regarding protective wear in handling chemicals should be observed.

Prior to use, consult Material Safety Data Sheet for proper safety, handling, and disposal information.

DIRASOL RAPID

Diazo Sensitized Direct Emulsion

Storage

Unsensitized Dirasol Rapid should be stored in its original container with the lid firmly sealed in a cool location between 35°F (2°C) and 95°F (35°C). The product will then remain stable for up to 12 months from the date of manufacture.

Sensitized Dirasol Rapid should be stored in similar conditions, in its original container and with the lid firmly sealed. The product will then remain stable for up to two months. This life can be extended by storage between 35°F (2°C) and 40°F (5°C).

The information and recommendations contained in this Technical Data Sheet, as well as technical advice otherwise given by representatives of our Company, whether verbally or in writing, are based on our present knowledge and believed to be accurate. However, no guarantee regarding their accuracy is given as we cannot cover or anticipate every possible application of our products and because manufacturing methods, printing stocks and other materials vary. For the same reason, our products are sold without warranty and on condition that users shall make their own tests to satisfy themselves that they will meet fully their particular requirements. Our policy of continuous product improvement might make some of the information contained in this Technical Data Sheet out of date and users are requested to ensure that they follow current recommendations.

FUJIFILM North America Corporation, Graphic Systems Division
1101 W. Cambridge Drive
Kansas City, KS 66103 USA
1-800-255-4562/(913) 342-4060 Fax: (913) 342-4752
Last Revised: March 31, 2010